

**MAIN PLANES  
FLAPS, INNER (INBOARD PORTION)**

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M.	Place No.
69	S10-20 WF 1	<b>FLAP</b> , inner, inboard portion, Port (Special spares assembly, complete with attachments)	1	—	P	LC1
70	S10-20 WF 2	<b>FLAP</b> , inner, inboard portion, Starboard (Special assembly, complete with attachments)	1	—	P	LC1
	10-20 WF 951A/1	<b>FLAP</b> , inner, inboard portion, Port, assembly ... (Mod. 598)	1	—	—	LC1
	10-20 WF 952A/1	<b>FLAP</b> , inner, inboard portion, Starboard, assembly... (Mod. 598)	1	—	—	LC1
	10 WF 237	Spares for :— <b>ANGLE</b> , spar attachment, at rib No. 5, Port, 22 SWG	1	L.72	LM	LC1
	10 WF 239	<b>ANGLE</b> , spar attachment, at rib No. 5, Starboard, 22 SWG	1	L.72	LM	LC1
	10 WF 143	<b>BLOCK</b> , trailing edge, rib No. 1 ...	1	LFS.23	LM	LC1
	10 WF 583	<b>BLOCK</b> , trailing edge, rib No. 5, Port ...	1	LFS.23	LM	LC1
	10 WF 584	<b>BLOCK</b> , trailing edge, rib No. 5, Starboard ...	1	LFS.23	LM	LC1
		Attachments for 10 WF 583 or 10 WF 584, Block :—				
1654	DHS.358/2C	Bolt, 2 BA ...	1	S.96	C	LC1
3815	DHS.358/4C	Bolt, 2 BA ...	1	S.98	C	LC1
28M/10288	AGS.2001/C/1	Nut, 2 BA ...	2	—	C	
	—	<b>BOLT</b> , striker, flap up micro switch, on leading edge, group	1	—	—	
6828	10-20 WF 969	<b>BOLT</b> ...	1	S.96	C	LC1
28M/1006473	A27/CT	<b>NUT</b> , 2 BA ...	1	—	C	LC1
	10-20 WF 961A	<b>PLATE</b> , Port, assembly ...	1	—	—	LC1
	10-20 WF 962A	<b>PLATE</b> , Starboard, assembly ...	1	—	—	LC1
	10 WF 251	<b>BRACKET</b> , attachment, rear intercostal to ribs Nos. 1, 2 and 3, 22 SWG	3	L.72	LM	LC1
	10-20 WF 1063A	<b>BRACKET</b> , mounting, inner flap lever, Port, assembly (Mod. 40) (For spares use 10-20 WF 1229A/ND)	1	—	—	LC1
12469	10-20 WF 1229A/ND	<b>BRACKET</b> , mounting, inner flap lever, Port, assembly (Spares condition)	1	—	P	
	10-20 WF 1064A	<b>BRACKET</b> , mounting, inner flap lever, Starboard, assembly (Mod. 40) (For spares use 10-20 WF 1230A/ND)	1	—	—	LC1
12470	10-20 WF 1230A/ND	<b>BRACKET</b> , mounting, inner flap lever, Starboard, assembly (Spares condition)	1	—	P	
6924	10 WF 457	Spares for :— <b>BUSH</b> ...	1	S.96	C	LC1
		Attachments for 10-20 WF 1063A or 10-20 WF 1064A, Bracket :—				
28D/9133011	A25/2C	Bolt, 2 BA ...	6	—	C	
28D/9133012	A25/3C	Bolt, 2 BA ...	8	—	C	
1655	DHS.358/3C	Bolt, 2 BA ...	4	S.96	C	LC1
1660	DHS.358/4C	Bolt, 2 BA ...	1	S.96	C	LC1
28M/1006473	A27/CT	Nut, 2 BA ...	14	—	C	
28M/10328	AGS.2002/C/1	Nut, 2 BA ...	5	—	C	
28VV/9419475	SP.15/C	Washer ...	14	—	C	
	DHS.32/39	Washer, tapered ...	2	S.96	LM	LC1
1648	DHS.770/C	Washer, cup ...	2	DTD.571	C	LC1

MAIN PLANES  
FLAPS, INNER (INBOARD PORTION)

Ref. No.	Part No.	Description	No. off						Material Specification	Class of Store or L.M	Place No.
			1	2	3	4	5	6			
	10-20 WF 563	<b>BRACKET</b> , mounting, leading edge, Port... (For spares use 10-20 WF 1323ND) (Mod. 40)	1						DTD.304	—	LC1
13733	10-20 WF 1323ND	<b>BRACKET</b> , mounting, leading edge, Port (Spares condition)	1						DTD.304	C	
	10-20 WF 564	<b>BRACKET</b> , mounting, leading edge, Starboard ... (For Spares use 10-20 WF 1324ND) (Mod. 40)	1						DTD.304	—	LC1
13734	10-20 WF 1324ND	<b>BRACKET</b> , mounting, leading edge, Starboard... (Spares condition)	1						DTD.340	C	
		Attachments for 10-20 WF 563 or 10-20 WF 564, Bracket :—									
28D/9133011	A25/2C	Bolt, 2 BA	6						—	C	
1092	DHS.365/2C	Bolt, 2 BA	2						S.96	C	LC1
28M/1006473	A27/CT	Nut, 2 BA	6						—	C	
28M/10288	AGS.2001/C/1	Nuc, 2 BA	2						—	C	
28VV/9419402	SP.13/C	Washer	8						—	C	
6816	10 WF 89	<b>BRACKET</b> , mounting, swinging link, Port ...	1						—	C	LC1
6817	10 WF 90	<b>BRACKET</b> , mounting, swinging link, Starboard Spares for :	1						—	C	LC1
	10 WF 67	<b>BUSH</b>	2						DTD.197	—	LC1
		Attachments for 10 WF 89 or 10 WF 90, Bracket :—									
28D/1010031	A25/8E	Bolt, 1/2" BSF	1						—	C	
28D/1011244	A25/9E	Bolt, 1/2" BSF	1						—	C	
1654	DHS.358/2C	Bolt, 2 BA	1						S.96	C	LC1
28M/12931	A27/ET	Nut, 1/2" BSF	2						—	C	
28M/1006473	A27/CT	Nut, 2 BA	1						—	C	
1648	DHS.770/C	Washer, cup	1						DTD.571	C	LC1
	10-20 WF 509	<b>DIAPHRAGM</b> , nose, at rib No. 5, Port (For spares use 10-20 WF 1605ND)	1						—	—	LC1
18865	10-20 WF 1605ND	<b>DIAPHRAGM</b> , nose, at rib No. 5, Port	1						—	C	
	10-20 WF 510	<b>DIAPHRAGM</b> , nose, at rib No. 5, Starboard ... (For spares use 10-20 WF 1606ND)	1						—	—	LC1
18866	10-20 WF 1606ND	<b>DIAPHRAGM</b> , nose, at rib No. 5, Starboard ...	1						—	C	
	—	<b>HOOK &amp; SPOOL</b> , inboard, between ribs No. 2 and 2A, group	1						—	—	
6811	10-20 WF 565	<b>HOOK</b> , flap (Mod. 40)	1						L.65	C	LC1
		Attachments for 10-20 WF 565, Hook :—									
28D/1011242	A25/7E	Bolt, 1/2" BSF	1						—	C	
9435068	AGS.2008/E/1	<b>NUT</b> , 1/2" BSF	1						—	C	
28M/10218	10 WF 273	<b>PACKING</b> , wedge	1						L.64	LM	LC1
	10 WF 274	<b>PACKING</b> , wedge	1						L.64	LM	LC1
6812	10 WF 269	<b>PAD</b> , serrated	1						L.64	C	LC1
6813	10 WF 270	<b>PAD</b> , serrated	1						L.64	C	LC1
	10 WF 241	<b>SPOOL</b>	1						L.64	LM	LC1
		Attachments for 10 WF 241, Spool :—									
28D/1011022	A25/18C	Bolt, 2 BA	1						—	C	
28M/1006473	A27/CT	Nut, 2 BA	1						—	C	
	—	<b>HOOK &amp; SPOOL</b> , outboard, between ribs No. 4 and 5, group	1						—	—	
6811	10-20 WF 565	<b>HOOK</b> , flap (Mod. 40)	1						L.65	C	LC1
		Attachments for 10-20 WF 565, Hook :—									
28D/1011242	A25/7E	Bolt, 1/2" BSF	1						—	C	

**MAIN PLANES  
FLAPS, INNER (INBOARD PORTION)**

Ref. No.	Part No.	Description	No off	Material Specification	Class of Store or L.M	Place No.
28M/9435068	AGS.2008/E/1	<b>NUT</b> , 1/4" BSF	1	—	C	
	10 WF 275	<b>PACKING</b> , wedge	2	L.64	LM	LC1
6814	10 WF 271	<b>PAD</b> , serrated	1	—	C	LC1
6815	10 WF 272	<b>PAD</b> , serrated	1	—	C	LC1
	10 WF 241	<b>SPOOL</b>	1	L.64	LM	LC1
		Attachments for 10 WF 241. Spool :—				
28D/1011022	A25/18C	Bolt, 2 BA	1	—	C	
28M/1006473	A27/CT	Nut, 2 BA	1	—	C	
	10 WF 223	<b>INTERCOSTAL</b> , Part No. 1, Port (For spares use 10-20 WF 1223A/ND)	1	—	—	LC1
13676	10-20 WF 1223A/ND	<b>INTERCOSTAL</b> , Part No. 1, Port (Spares condition)	1	—	C	
	10 WF 224	<b>INTERCOSTAL</b> , Part No. 1, Starboard... (For spares use 10-20 WF 1224A/ND)	1	—	—	LC1
13677	10-20 WF 1224A/ND	<b>INTERCOSTAL</b> , Part No. 1, Starboard... (Spares condition)	1	—	C	
	10 WF 225	<b>INTERCOSTAL</b> , Part No. 2, Port (For spares use 10-20 WF 1225ND)	1	—	—	LC1
13678	10-20 WF 1225ND	<b>INTERCOSTAL</b> , Part No. 2, Port (Spares condition)	1	—	C	
	10 WF 226	<b>INTERCOSTAL</b> , Part No. 2, Starboard... (For spares use 10-20 WF 1226ND)	1	—	—	LC1
13679	10-20 WF 1226ND	<b>INTERCOSTAL</b> , Part No. 2, Starboard... (Spares condition)	1	—	C	
	10 WF 227	<b>INTERCOSTAL</b> , Part No. 3, Port (For spares use 10-20 WF 1227ND)	1	—	—	LC1
13680	10-20 WF 1227ND	<b>INTERCOSTAL</b> , Part No. 3, Port (Spares condition)	1	—	C	
	10 WF 228	<b>INTERCOSTAL</b> , Part No. 3, Starboard (For spares use 10-20 WF 1228ND)	1	—	—	LC1
13681	10-20 WF 1228ND	<b>INTERCOSTAL</b> , Part No. 3, Starboard... (Spares condition)	1	—	C	
	10 WF 555	<b>INTERCOSTAL</b> , Part No. 4, Port (For spares use 10-20 WF 1305ND)	1	—	—	LC1
13750	10-20 WF 1306ND	<b>INTERCOSTAL</b> , Part No. 4, Port (Spares condition)	1	—	C	
	10 WF 556	<b>INTERCOSTAL</b> , Part No. 4, Starboard... (For spares use 10-20 WF 1306ND)	1	—	—	LC1
13751	10-20 WF 1306ND	<b>INTERCOSTAL</b> , Part No. 4, Starboard... (Spares condition)	1	—	C	
	10 WF 245	<b>INTERCOSTAL</b> , rear, between ribs Nos. 1 and 2, Port (For spares use 10-20 WF 1301ND)	1	—	—	LC1
13752	10-20 WF 1301ND	<b>INTERCOSTAL</b> , rear, between ribs Nos. 1 and 2, Port (Spares condition)	1	—	C	
	10 WF 246	<b>INTERCOSTAL</b> , rear, between ribs Nos. 1 and 2, Starboard (For spares use 10-20 WF 1302ND)	1	—	—	LC1
13753	10-20 WF 1302ND	<b>INTERCOSTAL</b> , rear, between ribs Nos. 1 and 2, Starboard (Spares condition)	1	—	C	
	10 WF 247	<b>INTERCOSTAL</b> , rear, between ribs Nos. 2 and 3, and 3 and 4, Port (For spares use 10-20 WF 1303ND)	2	—	—	LC1

**MAIN PLANES  
FLAPS, INNER (INBOARD PORTION)**

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M	Place No.
13754	10-20 WF 1303ND	<b>INTERCOSTAL</b> , rear, between ribs Nos. 2 and 3, and 3 and 4, Port (Spares condition)	2	—	C	
	10 WF 248	<b>INTERCOSTAL</b> , rear, between ribs Nos. 2 and 3, and 3 and 4, Starboard (For spares use 10-20 WF 1304ND)	2	—	—	LC1
13755	10-20 WF 1304ND	<b>INTERCOSTAL</b> , rear, between ribs Nos. 2 and 3, and 3 and 4, Starboard (Spares condition)	2	—	C	
	10-20 WF 1061A	<b>LUG</b> , top inner flap lever, Port, assembly ... (Mod. 40) (For spares use 10-20 WF 1331A/ND)	1	—	—	LC1
13711	10-20 WF 1331A/ND	<b>LUG</b> , top inner flap lever, Port, assembly ... (Mod. 40) (Spares condition)	1	—	C	
	10-20 WF 1062A	<b>LUG</b> , top inner flap lever, Starboard assembly (Mod. 40) (For spares use 10-20 WF 1332A/ND)	1	—	—	LC1
13712	10-20 WF 1332A/ND	<b>LUG</b> , top inner flap lever, Starboard assembly (Mod. 40) (Spares condition)	1	—	C	
6924	10 WF 457	<b>BUSH</b> ... ..	1	—	C	LC1
6820	10-20 WF 567	<b>LUG</b> , Port ... ..	1	—	C	LC1
6821	10-20 WF 568	<b>LUG</b> , Starboard ... ..	1	—	C	LC1
		Attachments for 10-20 WF 1061A or 10-20 WF 1062A, Lug :—				
1655	DHS.358/3C	Bolt, 2 BA ... ..	3	—	C	LC1
28M/10328	AGS.2002/C/1	Nut 2 BA ... ..	3	—	C	
	10 WF 585ND	<b>MEMBER</b> , trailing edge, Port (Make from standard section J.833, Ref. No. 7051)	1	—	LM	LC1
	10 WF 586ND	<b>MEMBER</b> , trailing edge, Starboard (Make from standard section J.833, Ref. No. 7051)	1	—	LM	LC1
	10 WF 173	<b>RIB</b> , No. 2A, Port (For spares use 10-20 WF 1307A/ND)	1	—	—	LC1
13741	10-20 WF 1307A/ND	<b>RIB</b> , No. 2A, Port (Spares condition) ... ..	1	—	C	
	10 WF 174	<b>RIB</b> , No. 2A, Starboard (For spares use 10-20 WF 1308A/ND)	1	—	—	LC1
13742	10-20 WF 1308A/ND	<b>RIB</b> , No. 2A, Starboard (Spares condition) ... Spares for :—	1	—	C	
	10-20 WC 15423	<b>DISC</b> , reinforcing ... ..	1	L.72	LM	LC1
	10 WF 527A/1	<b>RIB</b> , No. 5; Port, assembly (Mod. 598) ... .. (For spares use 10-20 WF 1543A/ND)	1	—	—	LC1
16373	10-20 WF 1543A/ND	<b>RIB</b> , No. 5; Port, assembly (Spares condition) ...	1	—	C	
	10 WF 528A/1	<b>RIB</b> , No. 5; Starboard, assembly (Mod. 598) ... (For spares use 10-20 WF 1544A/ND)	1	—	—	LC1
16374	10-20 WF 1544A/ND	<b>RIB</b> , No. 5, Starboard, assembly (Spares condition) Spares for :—	1	—	C	
	10 WF 139	<b>BLOCK</b> , trailing edge ... ..	1	LFS.23	LM	LC1
	10 WF 531	<b>BRACKET</b> , channel, Port, 18 SWG ... ..	1	L.72	LM	LC1
	10 WF 532	<b>BRACKET</b> , channel, Starboard, 18 SWG ... ..	1	L.72	LM	LC1
	10 WF 205	<b>BRACKET</b> , flange, 20 SWG ... ..	1	L.72	LM	LC1

**MAIN PLANES  
FLAPS, INNER (INBOARD PORTION)**

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M.	Plate No.
	10 WF 135	<b>RIB</b> , forward portion, No. 2 and No. 3, Port ...	2	L.72	—	LC1
	10 WF 136	<b>RIB</b> , forward portion, No. 2 and No. 3, Starboard	2	L.72	—	LC1
	10 WF 519	<b>RIB</b> forward portion, No. 4, Port ...	1	L.72	—	LC1
	10 WF 520	<b>RIB</b> , forward portion, No. 4, Starboard ...	1	L.72	—	LC1
	10 WF 277A	<b>RIB</b> , trailing portion, No. 2, Port, assembly ... (For spares use 10-20 WF 1449A/ND)	1	—	—	LC1
14527	10-20 WF 1449A/ND	<b>RIB</b> , trailing portion, No. 2, Port, assembly ... (Spares condition)	1	—	C	
	10 WF 278A	<b>RIB</b> , trailing portion, No. 2, Starboard assembly... (For spares use 10-20 WF 1450A/ND)	1	—	—	LC1
14528	10-20 WF 1450A/ND	<b>RIB</b> , trailing portion, No. 2, Starboard, assembly (Spares condition)	1	—	C	
	10 WF 137A	<b>RIB</b> , trailing portion, No. 3, Port, assembly ... (For spares use 10-20 WF 1311A/ND)	1	—	—	LC1
14300	10-20 WF 1311A/ND	<b>RIB</b> , trailing portion, No. 3, Port, assembly ... (Spares condition)	1	—	C	
	10 WF 138A	<b>RIB</b> , trailing portion, No. 3, Starboard, assembly (For spares use 10-20 WF 1312A/ND)	1	—	—	LC1
14301	10-20 WF 1312A/ND	<b>RIB</b> , trailing portion, No. 3, Starboard, assembly (Spares condition) Spares for :—	1	—	C	
	10 WF 139	<b>BLOCK</b> , trailing edge ...	1	LFS.23	LM	LC1
	10 WF 521A	<b>RIB</b> , trailing portion, No. 4, Port, assembly ... (For spares use 10-20 WF 1319A/ND)	1	—	—	LC1
13764	10-20 WF 1319A/ND	<b>RIB</b> , trailing portion, No. 4, Port, assembly ... (Spares condition)	1	—	C	
	10 WF 522A	<b>RIB</b> , trailing portion, No. 4, Starboard, assembly (For spares use 10-20 WF 1320A/ND)	1	—	—	LC1
13765	10-20 WF 1320A/ND	<b>RIB</b> , trailing portion, No. 4, Starboard, assembly (Spares condition) Spares for :—	1	—	C	
	10 WF 139	<b>BLOCK</b> , trailing edge ...	1	LFS.23	LM	LC1
	10-20 WC 15423	<b>DISC</b> , reinforcing, 20 SWG ...	1	L.72	LM	LC1
	10 WF 535A	<b>SKIN</b> , bottom, Port, assembly ... (For spares use 10-20 WF 1437A/ND)	1	—	—	LC1
14505	10-20 WF 1437A/ND	<b>SKIN</b> , bottom, Port, assembly ... (Spares condition)	1	—	C	
	10 WF 536A	<b>SKIN</b> , bottom, Starboard, assembly ... (For spares use 10-20 WF 1438A/ND)	1	—	—	LC1
14505	10-20 WF 1438A/ND	<b>SKIN</b> , bottom, Starboard, assembly ... (Spares condition) Spares for :—	1	—	C	
	10 WF 149A	<b>RIB</b> , Port, assembly ... (For spares use 10-20 WF 4061A/ND)	1	—	—	LC1

**MAIN PLANES**  
**FLAPS, INNER (INBOARD PORTION)**

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M	Place No.
18867	10-20 WF 4061A/ND	RIB, Port. assembly (Spares condition) ...	1	—	C	LC1
	10 WF 150A	RIB, Starboard. assembly ... (For spares use 10-20 WF 4062A/ND)	1	—	—	
18868	10-20 WF 4062A/ND	RIB, Starboard. assembly (Spares condition) ...	1	—	C	LC1
	10 WF 569A/ND	SKIN, top. Port. assembly ... (For spares use 10-20 WF 1431A/ND)	1	—	—	
14489	10-20 WF 1431A/ND	SKIN, top. Port. assembly (Spares condition) ...	1	—	C	LC1
	10 WF 570A/ND	SKIN, top. Starboard. assembly ... (For spares use 10-20 WF 1432A/ND)	1	—	—	
14490	10-20 WF 1432A/ND	SKIN, top. Starboard. assembly (Spares condition)	1	—	C	LC1
	10 WF 551A	SPAR, Port. assembly ...	1	—	—	
	10 WF 552A	SPAR, Starboard. assembly ...	1	—	—	
Attachments for 10-20 WF 951A or 10-20 WF 952A/1, Flap:—						
12646	10-20 WF 1233	Bolt, 1/4" BSF ...	1	S.96	C	LC1
16788	10-20 WF 1523	Bolt, 1/4" BSF (Mod. 939) ...	1	S.96	C	LC1
28D/15056	A25/41G	Bolt, 3/8" BSF ...	1	—	C	LC1
	6951	Bush, serrated (Mod. 939)	1	S.1	C	
16789	10-20 WF 1515	Bush, serrated (Mod. 939)	1	S.92	C	LC1
	OR					
16790	10-20 WF 1517	Bush, serrated (Mod. 939)	1	S.92	C	LC1
	OR					
16791	10-20 WF 1519	Bush, serrated (Mod. 939)	1	S.92	C	LC1
NOTE:—Select one bush which is the most suitable.						
28M/1011467	A27/E5	Nut, 1/4" BSF ...	1	—	C	LC1
28M/13122	A27/GS	Nut, 5/16" BSF ...	1	—	C	
28P/1007741	SP.9/C8	Pin, split: ...	2	—	C	LC1
	6952	Shim ...	5	L.72	C	
28VV/9419487	SP.16/E	Washer ...	1	—	C	LC1
16787	10-20 WF 1521	Washer, special (Mod. 939) ...	1	S.92	C	
	28VV/9419455	SP.10/G	Washer ...	1	—	

LC.1

SIO 2OWF1 FLAP INNER INBOARD PORTION L.H.  
SIO 2OWF2 FLAP INNER INBOARD PORTION R.H.

IO.2OWF951A/1 L.H. IO.2OWF952A/1,R.H.

\*IOWF245 L.H.  
\*IOWF246 R.H.

\*IOWF277A L.H.  
\*IOWF278A R.H.

\*IOWF225 L.H.  
\*IOWF226 R.H.

SEE TEXT FOR SPARES CONDITION  
OF ITEMS MARKED THUS: \*

IOWF 251 (3 OFF)

IOWF143

\*IOWF227 L.H.  
\*IOWF228 R.H.

\*IOWF247 L.H.  
\*IOWF248 R.H.

IOWF585 ND L.H.  
IOWF586 ND R.H.

\*IOWF223 L.H.  
\*IOWF224 R.H.

\*IOWF137A L.H.  
\*IOWF138A R.H.

\*IOWF521A L.H.  
\*IOWF522A R.H.  
IO.2OWC15423

SKIN TOP ASSY  
IOWF569A/ND L.H.  
IOWF570A/ND R.H.

IOWF551A L.H.  
IOWF552A R.H.

\*IOWF173 L.H.  
\*IOWF174 R.H.  
IO.2OWC15423

IOWF139

\*IOWF149A L.H.  
\*IOWF150A R.H.  
ASSEMBLED WITH BOTTOM SKIN

IOWF583 L.H.  
IOWF584 R.H.  
DHS.358/2C  
DHS.358/4 1/2 C

IOWF89 L.H.  
IOWF90 R.H.  
IOWF67 BUSH  
DHS.358/2C  
DHS.770/C

HOOK & SPOOL ASSY.  
See Detail Below

IOWF205

IO.2OWF1233

IOWF457

IOWF473

\*IO.2OWF1061A L.H. MOD.40  
\*IO.2OWF1062A R.H. MOD.40  
IO.2OWF567 L.H. (BARE)  
IO.2OWF568 R.H. (BARE)  
DHS.358/3C

IOWF135 L.H.  
IOWF136 R.H.

\*IO.2OWF1063A L.H. MOD.40  
\*IO.2OWF1064A R.H. MOD.40

SKIN BOTTOM ASSY.  
\*IOWF535A L.H.  
\*IOWF536A R.H.

IOWF519 L.H.  
IOWF520 R.H.

IOWF457  
DHS.358/3C  
DHS.358/4C  
DHS.770/C  
DHS.32/39

IO.2OWF969  
IO.2OWF961A L.H.  
IO.2OWF962A R.H.

\*IOWF527A/1 L.H.  
\*IOWF528A/1 R.H.

IOWF239 R.H.  
IOWF237 L.H.

\*IOWF509 L.H.  
\*IOWF510 R.H.

IO.2OWF565  
(INBOARD & OUTBOARD)

PORT AS DRAWN

IOWF241  
INBOARD & OUTBOARD

IOWF271 L.H.  
IOWF272 R.H.  
OUTBOARD ASSY.  
IOWF269 L.H.  
IOWF270 R.H.  
INBOARD ASSY.

IO.WF1523 BOLT

IOWF473 SHIM

IOWF1521

IOWF471  
OR  
IO.2OWF1515  
OR  
IO.2OWF1517  
OR  
IO.2OWF1519  
BUSH.SERRATED

SECTION  
OF  
FLAP LEVER

\*IO.2OWF563 L.H. MOD 40  
\*IO.2OWF564 R.H. MOD 40

DHS.365/2C

IOWF531 L.H.  
IOWF532 R.H.  
OUTBOARD ASSY.

IOWF275 L.H. & R.H.  
OUTBOARD ASSY.

IOWF273 L.H.  
IOWF274 R.H.  
INBOARD ASSY.

HOOK & SPOOL ASSEMBLIES

FLAPS INNER INBOARD PORTION

MAIN PLANE

RESTRICTED

See Viren Mk.1

RESTRICTED

Plate LC1

LC.1  
[A.L.66]

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

