

MAIN PLANES
FLAPS, INNER (OUTBOARD PORTION)

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M	Plate No.
123	S10-20 WF 9	FLAP, INNER, OUTBOARD PORTION, Port (Special spares assembly complete with attachments) (Mod. 484)	1	—	P	LD1
124	S10-20 WF 10	FLAP, INNER, OUTBOARD PORTION, Starboard (Special spares assembly complete with attachments) (Mod. 484)	1	—	P	LD1
	10-20 WF 953A/3	FLAP, inner, outboard portion, Port, assembly ... (Mod. 516)	1	—	—	LD1
	10-20 WF 954A/3	FLAP, inner, outboard portion, Starboard, assembly (Mod. 516)	1	—	—	LD1
	10-20 WF 125	BLOCK, trailing edge, at rib No. 8, Port ...	1	LFS.21	LM	LD1
	10-20 WF 126	BLOCK, trailing edge, at rib No. 8, Starboard ...	1	LFS.21	LM	LD1
	10-20 WF 107A	CHANNEL, rear, between ribs Nos. 6 and 10, Port, assembly (For spares use 10-20 WF 1329A/ND)	1	—	—	LD1
13729	10-20 WF 1329A/ND	CHANNEL, rear, between ribs Nos. 6 and 10, Port, assembly (Spares condition)	1	—	C	
	10-20 WF 108A	CHANNEL, rear, between ribs Nos. 6 and 10, Starboard, assembly (For spares use 10-20 WF 1330A/ND)	1	—	—	LD1
13730	10-20 WF 1330A/ND	CHANNEL, rear, between ribs Nos. 6 and 10, Starboard, assembly (Spares condition)	1	—	C	
	10-20 WF 121ND	MEMBER, trailing edge, between ribs Nos. 6 and 10 (Make from Section J.2249, Ref. No. 6872)	1	L.64	LM	LD1
	10-20 WF 109	MEMBER, trailing edge, locking, Port ... (For spares use 10-20 WF 1325ND)	1	—	—	LD1
13731	10-20 WF 1325ND	MEMBER, trailing edge, locking, Port ... (Spares condition)	1	—	C	
	10-20 WF 110	MEMBER, trailing edge, locking, Starboard ... (For spares use 10-20 WF 1326ND)	1	—	—	LD1
13732	10-20 WF 1326ND	MEMBER, trailing edge, locking, Starboard ... (Spares condition)	1	—	C	
		Attachments for 10-20 WF 109 or 10-20 WF 110, Member:—				
1789	DHS.358/7C	Bolt, 2 BA	3	—	C	LD1
28M/10328	AGS.2002/C/1	Nut, 2 BA	3	—	C	
	—	RIB, No. 6, Port and Starboard, group ... (Drg. No. 10-20 WF 473)	1	—	—	
	10-20 WF 477	ANGLE, reinforcing, bottom skin, at rib No. 6, Port (For spares use 10-20 WF 1357ND)	1	L.73	—	LD1
13687	10-20 WF 1357ND	ANGLE, reinforcing, bottom skin, at rib No. 6, (Port (Spares condition)	1	—	C	
	10-20 WF 478	ANGLE, reinforcing, bottom skin, at rib No. 6, Starboard (For spares use 10-20 WF 1358ND)	1	L.73	—	LD1
13688	10-20 WF 1358ND	ANGLE, reinforcing, bottom skin, at rib No. 6, Starboard (Spares condition)	1	—	C	
	10-20 WF 323	BLOCK, trailing edge, Port ...	1	LFS.21	LM	LD1
	10-20 WF 324	BLOCK, trailing edge, Starboard ...	1	LFS.21	LM	LD1
	10-20 WF 483	BRACKET, Port, 20 SWG ...	1	L.73	LM	LD1
	10-20 WF 484	BRACKET, Starboard, 20 SWG ...	1	L.73	LM	LD1
	10-20 WF 1037	DIAPHRAGM, between ribs No. 6 and 8, aft, Port (For spares use 10-20 WF 1341ND)	1	L.73	—	LD1
13713	10-20 WF 1341ND	DIAPHRAGM, between ribs No. 6 and 8, aft, Port (Spares condition)	1	—	C	

**MAIN PLANES
FLAPS, INNER (OUTBOARD PORTION)**

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M	Plate No.
	10-20 WF 1038	DIAPHRAGM , between ribs No. 6 and 8, aft, Starboard (For spares use 10-20 WF 1342ND)	1	L.73	—	LD1
13714	10-20 WF 1342ND	DIAPHRAGM , between ribs No. 6 and 8, aft, Starboard (Spares condition)	1	—	C	
	10-20 WF 1035	DIAPHRAGM , between ribs No. 6 and 8, forward, Port (For spares use 10-20 WF 1333ND)	1	L.73	—	LD1
13715	10-20 WF 1333ND	DIAPHRAGM , between ribs No. 6 and 8, forward, Port (Spares condition)	1	—	C	
	10-20 WF 1036	DIAPHRAGM , between ribs No. 6 and 8, forward, Starboard (For spares use 10-20 WF 1334ND)	1	L.73	—	LD1
13716	10-20 WF 1334ND	DIAPHRAGM , between ribs No. 6 and 8, forward, Starboard (Spares condition)	1	—	C	
	10-20 WF 1045	DIAPHRAGM , between ribs No. 8 and 9, aft, Port	1	L.73	LM	LD1
	10-20 WF 1046	DIAPHRAGM , between ribs No. 8 and 9, aft, Starboard	1	L.73	LM	LD1
	10-20 WF 1043	DIAPHRAGM , between ribs No. 8 and 9, forward, Port	1	L.73	LM	LD1
	10-20 WF 1044	DIAPHRAGM , between ribs No. 8 and 9, forward, Starboard	1	L.73	LM	LD1
	10-20 WF 475	MEMBER , aft portion, Port (For spares use 10-20 WF 1231ND)	1	L.73	—	LD1
12412	10-20 WF 1231ND	MEMBER , aft portion, Port (Spares condition)	1	—	C	
	10-20 WF 476	MEMBER , aft portion, Starboard (For spares use 10-20 WF 1232ND)	1	L.73	—	LD1
12413	10-20 WF 1232ND	MEMBER , aft portion, Starboard (Spares condition)	1	—	C	
	10-20 WF 555A	MEMBER , forward portion, Port, assembly (Mod. 40) (For spares use 10-20 WF 1343A, ND)	1	—	—	LD1
13721	10-20 WF 1343A, ND	MEMBER , forward portion, Port, assembly ... (Spares condition)	1	—	P	
	10-20 WF 556A	MEMBER , forward portion, Starboard, assembly (For spares use 10-20 WF 1344A, ND) (Mod. 40)	1	—	—	LD1
13722	10-20 WF 1344A, ND	MEMBER , forward portion, Starboard, assembly (Spares condition)	1	—	P	
	10 WF 459	BUSH	2	S.96	—	LD1
6840	10 WF 595	BUSH , serrated	1	—	C	LD1
28M/13481	AGS.2020/C,1	NUT , 2 BA	2	—	C	
		Attachments for 10-20 WF 555A or 10-20 WF 556A, Member :—				
1654	DHS.358/2C	Bolt, 2 BA	10	—	C	LD1
1655	DHS.358/3C	Bolt, 2 BA	9	—	C	LD1
2727	DHS.901/2E	Bolt, shear, 1/2" BSF	16	—	C	LD1
2364	DHS.901/2E	Bolt, shear, 1/2" BSF	3	—	C	LD1
2732	DHS.901/3E	Bolt, shear, 1/2" BSF	1	—	C	LD1
28D/9133011	A25/2C	Bolt, 2 BA	2	—	C	
28M/1006473	A27/CT	Nut, 2 BA	19	—	C	
2227	DHS.983/E	Nut, 1/2" BSF	20	—	C	LD1
28W/9419475	SP.15/C	Washer	19	—	C	

**MAIN PLANES
FLAPS, INNER (OUTBOARD PORTION)**

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M	Plate No.
28M/9435067	AGS.2008/C/1 10-20 WF 1031A	NUT , 2 BA 9	9	—	C	
		RIB , No. 8, Port, assembly 1 (For spares use 10-20 WF 1441A/ND)	1	—	—	LD1
14523	10-20 WF 1441A/ND 10-20 WF 1032A	RIB , No. 8, Port, assembly (Spares condition) ... 1	1	—	C	
		RIB , No. 8, Starboard, assembly 1 (For spares use 10-20 WF 1442A/ND)	1	—	—	LD1
14524	10-20 WF 1442A/ND	RIB , No. 8, Starboard, assembly (Spares condition) 1	1	—	C	
		Spares for :—				
	10-20 WF 341	BLOCK , packing, Port 1	1	LFS.21	LM	LD1
	10-20 WF 342	BLOCK , packing, Starboard 1	1	LFS.21	LM	LD1
	10-20 WF 1033A	RIB , No. 9, Port, assembly 1 (For spares use 10-20 WF 1445A/ND)	1	—	—	LD1
14525	10-20 WF 1445A/ND 10-20 WF 1034A	RIB , No. 9, Port, assembly (Spares condition) ... 1	1	—	C	
		RIB , No. 9, Starboard, assembly 1 (For spares use 10-20 WF 1446A/ND)	1	—	—	LD1
14526	10-20 WF 1446A/ND	RIB , No. 9, Starboard, assembly (Spares condition) 1	1	—	C	
		Spares for :—				
	10-20 WF 341	BLOCK , packing, Port 1	1	LFS.21	LM	LD1
	10-20 WF 342	BLOCK , packing, Starboard 1	1	LFS.21	LM	LD1
	—	RIBS , Nos. 10 and 11, group 1 (Drg. No. 10-20 WF 1243) (Mod. 516)	1	—	—	
	10-20 WF 1285	ANGLE , fairing, outboard, Port 1 (For spares use 10-20 WF 1503ND)	1	—	—	LD1
15942	10-20 WF 1503ND	ANGLE , fairing, outboard, Port 1 (Spares condition)	1	—	C	
	10-20 WF 1286	ANGLE , fairing, outboard, Starboard... .. 1 (For spares use 10-20 WF 1504ND)	1	—	—	LD1
15943	10-20 WF 1504ND	ANGLE , fairing, outboard, Starboard... .. 1 (Spares condition)	1	—	C	
	10-20 WF 533	BLOCK , nose rib No. 10 1	1	—	—	LD1
	10-20 WF 451A	BRACKET , roller, assembly 1	1	—	—	LD1
6865	10-20 WF 449ND	BRACKET , bare 1	1	—	C	LD1
6866	10 WC 8849	ROLLER 1	1	—	C	LD1
		Attachments for 10 WC 8849, Roller :—				
28D/1013173	AS.1242/10C	Bolt , 2 BA 1	1	—	C	
28M/1006473	A27/CT	Nut , 2 BA 1	1	—	C	
28P/1007741	SP.9/C8	Pin , split 1	1	—	C	
6867	10-20 WF 455	Tube , distance 1	1	—	C	LD1
28W/9419402	SP.13/C	Washer 1	1	—	C	
		Attachments for 10-20 WF 451A, Bracket :—				
	10-20 WF 535	Block , packing 1	1	L.72	LM	LD1
26FN/3002	A25/5E/DHS.514/D	Bolt , 1/4" BSF 2	2	—	C	LD1
28D/9133014	A25/13C	Bolt , 2 BA 2	2	—	C	
28M/1006473	A27/CT	Nut , 2 BA 2	2	—	C	
	10-20 WF 459A	Pad , serrated, assembly 1	1	—	—	LD1
28W/9419475	SP.15/C	Washer 2	2	—	C	
28W/9419405	SP.15/E	Washer 2	2	—	C	

**MAIN PLANES
FLAPS, INNER (OUTBOARD PORTION)**

Ref. No.	Part No.	Description						No. off	Material Specification	Class of Store or L.M.	Place No.
		1	2	3	4	5	6				
1092	10-20 WF 531	COVER , at roller bracket, 16 SWG ...						1	L.73	LM	LD1
	DHS.365/2C	Attachments for 10-20 WF 531, Cover :— Bolt, 2 BA ...						6	—	C	LD1
12300	10-20 WF 1047	DIAPHRAGM , between ribs No. 9 and 10, aft, Port						1	L.73	LM	LD1
	10-20 WF 1048	DIAPHRAGM , between ribs No. 9 and 10, aft, Starboard						1	L.73	LM	LD1
12301	10-20 WF 1041	DIAPHRAGM , between ribs No. 10 and 11, aft, Port (For spares use 10-20 WF 1219ND)						1	—	—	LD1
	10-20 WF 1219ND	DIAPHRAGM , between ribs No. 10 and 11, aft, Port (Spares condition)						1	—	C	
12302	10-20 WF 1042	DIAPHRAGM , between ribs No. 10 and 11, aft, Starboard (For spares use 10-20 WF 1220ND)						1	—	—	LD1
	10-20 WF 1220ND	DIAPHRAGM , between ribs No. 10 and 11, aft, Starboard (Spares condition)						1	—	C	
12303	10-20 WF 1039	DIAPHRAGM , between ribs No. 10 and 11, forward, Port (Spares use 10-20 WF 1221ND)						1	—	—	LD1
	10-20 WF 1221ND	DIAPHRAGM , between ribs No. 10 and 11, forward, Port (Spares condition)						1	—	C	
6849	10-20 WF 1040	DIAPHRAGM , between ribs No. 10 and 11, forward, Starboard (For spares use 10-20 WF 1222ND)						1	—	—	LD1
	10-20 WF 1222ND	DIAPHRAGM , between ribs No. 10 and 11, forward, Starboard (Spares condition)						1	—	C	
6850	10-20 WF 199	DIAPHRAGM , between ribs No. 10 and 11, aft, Port						1	—	C	
6845	10-20 WF 200	DIAPHRAGM , between ribs No. 10 and 11, aft, Starboard						1	—	C	
6846	10-20 WF 193	DIAPHRAGM , between ribs No. 10 and 11, forward, Port						1	—	C	
13725	10-20 WF 194	DIAPHRAGM , between ribs No. 10 and 11, forward, Starboard						1	—	C	
	10-20 WF 215	DIAPHRAGM , hook, Port ... (For spares use 10-20 WF 1347A/ND)						1	—	—	LD1
13726	10-20 WF 1347A/ND	DIAPHRAGM , hook, Port (Spares condition)						1	—	C	
	10-20 WF 216	DIAPHRAGM , hook, Starboard ... (For spares use 10-20 WF 1348A/ND)						1	—	—	LD1
15867	10-20 WF 1348A/ND	DIAPHRAGM , hook, Starboard ... (Spares condition)						1	—	C	
	10-20 WF 1247A	FAIRING , rear, Port, assembly (For spares use 10-20 WF 1511ND (Mod. 516))						1	—	—	LD1
15868	10-20 WF 1511ND	FAIRING , rear, Port, assembly (Spares condition)						1	—	C	
	10-20 WF 1248A	FAIRING , rear, Starboard, assembly (For spares use 10-20 WF 1512ND (Mod. 516))						1	—	—	LD1
28D/1007975 15286	10-20 WF 1512ND	FAIRING , rear, Starboard, assembly ... (Spares condition)						1	—	C	
	AS.1242/1C	Attachments for 10-20 WF 1247A or 10-20 WF 1248A, Fairing :—									
	DHS.365/7C	Bolt, 2 BA ...						6	—	C	
		Bolt, 2 BA ...						1	—	C	LD1

**MAIN PLANES
FLAPS, INNER (OUTBOARD PORTION)**

Ref. No.	Part No.	Description						No. off	Material Specification	Class of Store or L.M.	Plate No.
		1	2	3	4	5	6				
17456	10-20 WF 4041	FITTING , interlock, at rib No. 11 and trailing edge, Port (Mod. 1168)						1	—	C	LD1
17457	10-20 WF 4042	FITTING , interlock, at rib No. 11 and trailing edge, Starboard (Mod. 1168)						1	—	C	LD1
		Attachments for 10-20 WF 4041 or 10-20 WF 4042, Fitting :—									
28D/9140202	AS.1246/1C	Bolt, 2 BA						2	—	C	
28D/9133011	A25/2C	Bolt, 2 BA						3	—	C	
1654	DHS.358/2C	Bolt, 2 BA						2	—	C	LD1
28M/10328	AGS.2002/C/1	Nut, 2 BA						2	—	C	
	10-20 WF 95A	HOUSING , rotating link, mounting, Port, assembly (For spares use 10-20 WF 1359A/ND)						1	—	—	LD1
14043	10-20 WF 1359A/ND	HOUSING , rotating link, mounting, Port, assembly (Spares condition)						1	—	P	
	10-20 WF 96A	HOUSING , rotating link, mounting, Starboard, assembly (For spares use 10-20 WF 1360A/ND)						1	—	—	LD1
14044	10-20 WF 1360A/ND	HOUSING , rotating link, mounting, Starboard, assembly (Spares condition)						1	—	P	
		Spares for :—									
6863	10-20 WF 497	BUSH						1	—	C	LD1
		Attachments for 10-20 WF 497, Bush :—									
28S/15773	A41/B10	Screw, 4 BA						2	—	C	
6864	10-20 WF 97	BUSH						1	—	C	LD1
		Attachments for 10-20 WF 97, Bush :—									
28D/9133011	A25/2C	Bolt, 2 BA						2	—	C	
28M/9403520	A27/CP	Nut, 2 BA						2	—	C	
		Attachments for 10-20 WF 95A or 10-20 WF 96A, Housing :—									
28D/9133011	A25/2C	Bolt, 2 BA						6	—	C	
28D/9140648	A25/19C	Bolt, 2 BA						2	—	C	
28D/9709461	AS.1242/3C	Bolt, 2 BA						2	—	C	
28D/1007976	AS.1242/4C	Bolt, 2 BA						2	—	C	
20076 1092	DHS.365/2C DHS 825/2C	Bolt, 2 BA						7	—	C	LD1
28M/1006473	A27/CT	Nut, 2 BA						12	—	C	
28M/10328	AGS.2002/C/1	Nut, 2 BA						7	—	C	
26FN/3285	DHS.180 Mk. 3/X	Tag, locking						1	—	C	
28W/9419475	SP.15/C	Washer						17	—	C	
28W/9419404	SP.16/C	Washer						2	—	C	

MAIN PLANES
FLAPS, INNER (OUTBOARD PORTION)


Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M	Plate No.
	10-20 WF 539	MEMBER , trailing edge, between ribs Nos. 10 and 11, Port (For spares use 10-20 WF 1355ND)	1	—	—	LD1
13685	10-20 WF 1355ND	MEMBER , trailing edge, between ribs Nos. 10 and 11, Port (Spares condition)	1	—	C	
	10-20 WF 540	MEMBER , trailing edge, between ribs Nos. 10 and 11, Starboard (For spares use 10-20 WF 1356ND)	1	—	—	LD1
13686	10-20 WF 1356ND	MEMBER , trailing edge, between ribs Nos. 10 and 11, Starboard (Spares condition)	1	—	C	
28M/9993192	AGS.2009/C/1	NUT , 2 BA, faired block attachment on rib No. 11 (2 off); inspection cover attachment on rib Nos. 10 and 10A (6 off)	8	—	C	
	10-20 WF 367	PAD , angled, under anchor nuts, faired block attachment on rib No. 11	2	L.72	LM	LD1
9173	10-20 WF 1057ND	PLATE , bottom reinforcing	2	—	C	LD1
	10-20 WF 147A	RIB , No. 10, Port, assembly (For spares use 10-20 WF 1335A/ND)	1	—	—	LD1
13717	10-20 WF 1335A/ND	RIB , No. 10, Port, assembly (Spares condition)	1	—	C	
	10-20 WF 148A	RIB , No. 10, Starboard, assembly (For spares use 10-20 WF 1336A/ND)	1	—	—	LD1
13718	10-20 WF 1336A/ND	RIB , No. 10, Starboard, assembly (Spares condition) Spares for :—	1	—	C	
	10-20 WF 151	BLOCK , packing, Port	1	LFS.21	LM	LD1
	10-20 WF 152	BLOCK , packing, Starboard	1	LFS.21	LM	LD1
	10-20 WF 153	RIB , No. 10A, Port (For spares use 10-20 WF 1351ND)	1	—	—	LD1
13719	10-20 WF 1351ND	RIB , No. 10A, Port (Spares condition)	1	—	C	
	10-20 WF 154	RIB , No. 10A, Starboard (For spares use 10-20 WF 1352ND)	1	—	—	LD1
13720	10-20 WF 1352ND	RIB , No. 10A, Starboard (Spares condition)	1	—	C	
	10-20 WF 1245A	RIB , No. 11, Port, assembly (For spares use 10-20 WF 1485A/ND) (Mod. 516)	1	—	—	LD1
15865	10-20 WF 1485A/ND	RIB , No. 11, Port, assembly (Spares condition)	1	—	C	
	10-20 WF 1246A	RIB , No. 11, Starboard, assembly (For spares use 10-20 WF 1486A/ND) (Mod. 516)	1	—	—	LD1
15866	10-20 WF 1486A/ND	RIB , No. 11, Starboard, assembly (Spares condition) Spares for :—	1	—	C	
	10-20 WF 1291ND	FAIRING , forward, Port (For spares use 10-20 WF 1499ND)	1	—	—	LD1
16618	10-20 WF 1499ND	FAIRING , forward, Port (Spares condition)	1	—	C	
	10-20 WF 1292ND	FAIRING , forward, Starboard (For spares use 10-20 WF 1500ND)	1	—	—	LD1
16619	10-20 WF 1500ND	FAIRING , forward, Starboard (Spares condition)	1	—	C	
28M/9993192	AGS.2009/C/1	NUT , 2 BA	4	—	C	

**MAIN PLANES
FLAPS, INNER (OUTBOARD PORTION)**

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M	Plate No.
	10-20 WF 1261A	SKIN, bottom, Port. assembly (Mod. 516) ... (For spares use 10-20 WF 1509A/ND)	1	—	—	LD1
15869	10-20 WF 1509A/ND	SKIN, bottom, Port. assembly (Spares condition)	1	—	C	
	10-20 WF 1262A	SKIN, bottom, Starboard, assembly (Mod. 516) (For spares use 10-20 WF 1510A/ND)	1	—	—	LD1
15870	10-20 WF 1510A/ND	SKIN, bottom, Starboard, assembly ... (Spares condition)	1	—	C	
	10-20 WF 1265A	SKIN, top, forward, Port. assembly (Mod. 516) (For spares use 10-20 WF 1505A/ND)	1	—	—	LD1
15944	10-20 WF 1505A/ND	SKIN, top, forward, Port. assembly ... (Spares condition)	1	—	C	
	10-20 WF 1266A	SKIN, top, forward, Starboard, assembly (Mod. 516) (For spares use 10-20 WF 1506A/ND)	1	—	—	LD1
15945	10-20 WF 1506A/ND	SKIN, top, forward, Starboard, assembly ... (Spares condition)	1	—	C	
	10-20 WF 1263A	SKIN, top, rear, Port. assembly (Mod. 516) ... (For spares use 10-20 WF 1507A/ND)	1	—	—	LD1
15946	10-20 WF 1507A/ND	SKIN, top, rear, Port. assembly ... (Spares condition)	1	—	C	
	10-20 WF 1264A	SKIN, top, rear, Starboard assembly (Mod. 516) (For spares use 10-20 WF 1508A/ND)	1	—	—	LD1
15947	10-20 WF 1508A/ND	SKIN, top, rear, Starboard, assembly ... (Spares condition)	1	—	C	
	10-20 WF 117ND	SKIN, trailing edge, Port. 24 SWG ...	1	L.73	LM	LD1
	10-20 WF 118ND	SKIN, trailing edge, Starboard, 24 SWG ...	1	L.73	LM	LD1
	10-20 WF 217	SPAR, between rib Nos. 6 and 11, Port...	1	L.73	—	LD1
	10-20 WF 218	SPAR, between rib Nos. 6 and 11, Starboard ...	1	L.73	—	LD1

MAIN PLANES
FLAPS, INNER (OUTBOARD PORTION)

Ref. No.	Part No.	Description	No. off						Material Specification	Class of Store or L.M.	Place No.
			1	2	3	4	5	6			
		Attachments for 10-20 WF 953A/3 or 10-20 WF 954A/3, Flap :-									
28D/13050	A25/40J	Bolt, $\frac{3}{8}$ " BSF						1	—	C	
16792	10-20 WF 1525	Bolt, $\frac{5}{16}$ " BSF (Mod. 939)						1	—	C	LD1
6884	10-20 WF 65	Bolt, $\frac{1}{2}$ " BSF						1	—	C	LD1
6963	10 WF 761	Bush, serrated (Mod. 939)						1	—	C	LD1
16794	10-20 WF 1535	Bush, serrated (Mod. 939)						1	—	C	LD1
16795	10-20 WF 1537	Bush, serrated (Mod. 939)						1	—	C	LD1
16796	10-20 WF 1539	Bush, serrated (Mod. 939)						1	—	C	LD1
28M/13412	A24/JS	Nut, $\frac{3}{8}$ " BSF						1	—	C	
28M/13122	A27/GS	Nut, $\frac{1}{8}$ " BSF						1	—	C	
28P/1007741	SP.9/C8	Pin, split						2	—	C	
28W/9138816	SP.11/J	Washer						10	—	C	
28W/9419466	SP.13/J	Washer						1	—	C	
6964	10 WF 763	Washer, shim (Mod. 939)						5	—	C	LD1
16793	10-20 WF 1527	Washer, special (Mod. 939)						1	—	C	LD1
6885	10-20 WF 81	Washer, tab						1	—	C	LD1
10305	10-20 WF 1067	PLATE , interlocking, at rib No. 12, outer flap, Port						1	—	C	LD1
10306	10-20 WF 1068	PLATE , interlocking, at rib No. 12, outer flap, Starboard						1	—	C	LD1
		Attachments for 10-20 WF 1067 or 10-20 WF 1068, Plate :-									
28D/10472	AS.1248/12C	Bolt, 2 BA						1	—	C	
1655	DHS.358/3C	Bolt, 2 BA						1	—	C	LD1
2339	DHS.358/5C	Bolt, 2 BA						1	—	C	LD1
1788	DHS.358/6C	Bolt, 2 BA						1	—	C	LD1
8473	DHS.358/12C	Bolt, 2 BA						1	—	C	LD1
17716	10-20 WF 1601	Packing, tapered, between interlock fitting and plate (Mod. 1027)						1	—	C	LD1
	10-20 WF 1467ND	Plate, packing, between interlock fitting and skin, Port, 18 SWG						1	L.73	—	LD1
	10-20 WF 1468ND	Plate, packing, between interlock fitting and skin, Starboard, 18 SWG						1	L.73	—	LD1
10307	10-20 WF 1109ND	Washer, tapered						1	—	C	LD1



LD.1

MAIN PLANE

LD.1

FLAPS INNER OUTBOARD PORTION

[AL.63]

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm
Please see site for usage terms,
and more aircraft documents.

