

**ACCESSORY AIR-INTAKE FAIRING PANEL**

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or LM	Place No.
	—	<b>INSTALLATION OF HEAT EXCHANGER AND ACCESSORY COOLING AIR-INTAKE FAIRING PANEL, PORT</b> (Drg. No. 10-20 EC 5841)	1	—	—	ML1
	—	<b>INSTALLATION OF HEAT EXCHANGER AND ACCESSORY COOLING AIR-INTAKE FAIRING PANEL, STARBOARD</b> (Drg. No. 10-20 EC 5842)	1	—	—	ML1
165	S.10-20 EC 41	<b>AIR-INTAKE</b> , between bottom spars, Port (Special spares assembly c/w attachments) (Mod. 846)	1	—	—	ML1
166	S.10-20 EC 42	<b>AIR-INTAKE</b> , between bottom spars, Starboard (Special spares assembly c/w attachments) (Mod. 846)	1	—	—	ML1
	10-20 EC 10193A	<b>AIR-INTAKE</b> , between bottom spars, Port, assembly (Mod. 846)	1	—	—	ML1
	10-20 EC 10194A	<b>AIR-INTAKE</b> , between bottom spars, Starboard, assembly (Mod. 846)	1	—	—	ML1
	10-20 E 5739	<b>AIR-INTAKE</b> , accessory de-icing, Port ... (Mod. 846)	1	—	—	ML1
	10-20 E 5740	<b>AIR-INTAKE</b> , accessory de-icing, Starboard (Mod. 846)	1	—	—	ML1
		Attachments for 10-20 EC 10193A, or 10-20 EC 10194A, Air-intake :—				
28D/9133011	A25/2C	Bolt, 2 BA ... ..	4	—	C	
28D/13461	AS.3297/2C	Bolt, 2 BA ... ..	26	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA ... ..	2	—	C	
28VV/9419402	SP.13/C	Washer ... ..	2	—	C	
8293	10-20 E 2763	<b>RING</b> , sealing, silicone rubber ... ..	1	—	C	ML1
	10-20 EC 9405A	<b>ANGLE</b> , attachment, fairing to shear panel, Port, assembly (For spares use 10-20 EC 9789A/ND)	1	—	—	ML1
14495	10-20 EC 9789A/ND	<b>ANGLE</b> , attachment, fairing to shear panel, Port, assembly (Spares condition)	1	—	—	
	10-20 EC 9406A	<b>ANGLE</b> , attachment, fairing to shear panel, Starboard, assembly (For spares use 10-20 EC 9790A/ND)	1	—	—	ML1
14496	10-20 EC 9790A/ND	<b>ANGLE</b> , attachment, fairing to shear panel, Starboard, assembly (Spares condition)	1	—	—	
		Attachments for 10-20 EC 9405A or 10-20 EC 9406A, Angle :—				
28D/9133011	A25/2C	Bolt, 2 BA ... ..	4	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA ... ..	3	—	C	
28VV/9419402	SP.13/C	Washer ... ..	3	—	C	
	10-20 EC 911ND	Washer, 0"6 x 0"50 x 18 SWG ... ..	3	L.72	LM	ML1

**POWER INSTALLATION**  
**ACCESSORY AIR-INTAKE FAIRING PANEL**

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or LM	Plate No.
14497	10-20 EC 9409A	<b>ANGLE</b> , attachment, fairing to wing, Port, assembly (For spares use 10-20 EC 9791A/ND)	1	—	—	ML1
	10-20 EC 9791A/ND	<b>ANGLE</b> , attachment, fairing to wing, Port, assembly (Spares condition)	1	—	—	
	10-20 EC 9410A	<b>ANGLE</b> , attachment, fairing to wing, Starboard, assembly (For spares use 10-20 EC 9792A/ND)	1	—	—	ML1
14498	10-20 EC 9792A/ND	<b>ANGLE</b> , attachment, fairing to wing, Starboard, assembly (Spares condition) Attachments for 10-20 EC 9409A or 10-20 EC 9410A, Angle :—	1	—	—	
28D/9133012	A25/3C	Bolt, 2 BA ... ..	5	—	C	
	10-20 EC 913ND	Washer, 0"6 x 0"50 x 14 SWG ... ..	5	L.72	LM	ML1
	10-20 EC 829A	<b>BRACKET</b> , rear fairing attachment, stn. 209"-25, Port, assembly	1	—	—	ML1
	10-20 EC 830A	<b>BRACKET</b> , rear fairing attachment, stn. 209"-25, Starboard, assembly	1	—	—	ML1
28M/11957	10-20 EC 835ND	<b>BRACKET</b> , bare, 16 SWG, Port ... ..	1	L.72	LM	ML1
	10-20 EC 836ND	<b>BRACKET</b> , bare, 16 SWG, Starboard ... ..	1	L.72	LM	ML1
	AGS.2007/C/1	<b>NUT</b> , anchor, 2 BA ... ..	2	—	C	
	10-20 EC 841ND	<b>PLATE</b> , throat, 18 SWG ... ..	1	L.72	LM	ML1
	10-20 EC 831A	<b>BRACKET</b> , rear fairing attachment, stn. 218"-50, Port, assembly	1	—	—	ML1
	10-20 EC 832A	<b>BRACKET</b> , rear fairing attachment, stn. 218"-50, Starboard, assembly	1	—	—	ML1
28M/11957	10-20 EC 837ND	<b>BRACKET</b> , bare, 16 SWG, Port ... ..	1	L.72	LM	ML1
	10-20 EC 838ND	<b>BRACKET</b> , bare, 16 SWG, Starboard ... ..	1	L.72	LM	ML1
	AGS.2007/C/1	<b>NUT</b> , anchor, 2 BA ... ..	2	—	C	
	10-20 EC 841ND	<b>PLATE</b> , throat, 18 SWG ... ..	1	L.72	LM	ML1
	10-20 EC 833A	<b>BRACKET</b> , rear fairing attachment, stn. 227"-56 Port, assembly	1	—	—	ML1
	10-20 EC 834A	<b>BRACKET</b> , rear fairing attachment, stn. 227"-56 Starboard, assembly	1	—	—	ML1
28M/11957	10-20 EC 839ND	<b>BRACKET</b> , bare, 16 SWG, Port ... ..	1	L.72	LM	ML1
	10-20 EC 840ND	<b>BRACKET</b> , bare, 16 SWG, Starboard ... ..	1	L.72	LM	ML1
	AGS.2007/C/1	<b>NUT</b> , anchor, 2 BA ... ..	2	—	C	
	10-20 EC 841ND	<b>PLATE</b> , throat, 18 SWG ... ..	1	L.72	LM	LM1


**ACCESSORY AIR-INTAKE FAIRING PANEL**

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M	Place No.
		Attachments for 10-20 EC 829A, 10-20 EC 830A, 10-20 EC 831A, 10-20 EC 832A, 10-20 EC 833A or 10-20 EC 834A, Bracket :-				
28D/9133011	A25/2C	Bolt, 2 BA	2	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA	2	—	C	
28W/9419402	SP.13/C	Washer	2	—	C	
	10-20 EC 8699A	<b>BRACKET</b> , rear fairing attachment to wing, station 218"-50, Port, assembly	1	—	—	ML1
	10-20 EC 8700A	<b>BRACKET</b> , rear fairing attachment to wing, station 218"-50, Starboard, assembly	1	—	—	ML1
	10-20 EC 8701ND	<b>BRACKET</b> , bare, 12 SWG, Port	1	L.72	LM	ML1
	10-20 EC 8702ND	<b>BRACKET</b> , bare, 12 SWG, Starboard	1	L.72	LM	ML1
28M/11957	AGS.2007/C/1	<b>NUT</b> , anchor, 2 BA	2	—	C	
	10-20 EC 847ND	<b>PLATE</b> , throat, 14 SWG	1	L.72	LM	ML1
	10-20 EC 849ND	<b>PLATE</b> , throat, 18 SWG	2	L.72	LM	ML1
		Attachments for 10-20 EC 8699A or 10-20 EC 8700A, Bracket :-				
28D/1200119	A25/4C	Bolt, 2 BA	2	—	C	
28W/9419402	SP.13/C	Washer	2	—	C	
	10-20 EC 2921A	<b>BRACKET</b> , rear fairing attachment to wing, station 227"-56, Port, assembly	1	—	—	ML1
	10-20 EC 2922A	<b>BRACKET</b> , rear fairing attachment to wing, station 227"-56, Starboard, assembly	1	—	—	ML1
	10-20 EC 2925ND	<b>BRACKET</b> , bare, 12 SWG, Port	1	L.72	LM	ML1
	10-20 EC 2926ND	<b>BRACKET</b> , bare, 12 SWG, Starboard	1	L.72	LM	ML1
28M/11957	AGS.2007/C/1	<b>NUT</b> , anchor, 2 BA	2	—	C	
	10-20 EC 847ND	<b>PLATE</b> , throat, 14 SWG	1	L.72	LM	ML1
	10-20 EC 849ND	<b>PLATE</b> , throat, 18 SWG	2	L.72	LM	ML1
		Attachments for 10-20 EC 2921A or 10-20 EC 2922A, Bracket :-				
28D/9133012	A25/3C	Bolt, 2 BA	2	—	C	
42	S10-20 EC 17	<b>FAIRING</b> , rear, air-intake between bottom spars, Port (Special spares assembly c/w attachments)	1	—	P	ML1
43	S10-20 EC 18	<b>FAIRING</b> , rear, air-intake between bottom spars, Starboard (Special spares assembly c/w attachments)	1	—	P	ML1
	10-20 EC 5837A/1	<b>FAIRING</b> , rear, between bottom spars, Port, assembly (Mod. 461)	1	—	—	ML1
	10-20 EC 5838A/1	<b>FAIRING</b> , rear, between bottom spars, Starboard, assembly (Mod. 461)	1	—	—	ML1
		Spares for :-				
	10-20 EC 5875ND	<b>SEAL</b> , accelerator hook cut out, $\frac{1}{16}$ " thick x 0"-60 wide, rubber, 30-40° Shore hardness	QR	—	LM	ML1



MLI

POWER INSTALLATION  
ACCESSORY AIR INTAKE FAIRING PANEL



RESTRICTED

RESTRICTED

MLI  
[44-57]

PLATE MLI

SEC VIXEN MK.1