

INSTALLATION OF AUTO-TONE TRANSMISSION (MOD. 1183)

Ref. No.	Part No.	Description	No. of	Material Specification	Class of Store or L.M.	Plate No.
	—	INSTALLATION OF AUTO-TONE TRANSMISSION (Mod. 1183) (Drg. No. 19-20 R 9241)	1	—	—	
	—	INSTALLATION AT LOWER PANEL, CODED "H" (Drg. Nos. 10-20 N 15833A, Pre Mod. 803 ; 10-20 N 15709A and 10-20 R 3687)	1	—	—	
	—	BLOCK, fuse, coded "CS," group	1	—	—	
	—	BLOCK, fuse, 12-way (See sub-section EBV)	—	—	—	
10H/23864	—	FUSE, 5 amp.	1	—	C	
	10-20 R 2547/Mk. 145	CABLE, coded "24.CS.H.RTA-AF.H.7," assembly	1	—	ECC	
	—	INSTALLATION AT PANEL, CODED "AHW" ON EQUIPMENT DECK AFT OF NAVIGATOR'S SEAT (Drg. No. 10-20 R 3687)	—	—	—	
	—	BLOCK, terminal, coded "AHW," group ...	1	—	—	
5CZ/6582	WARD BROOKE WB.1110/D/10/B	BLOCK, terminal, 10-way double, assembly ...	1	—	C	
5CZ/7659 5CZ/6482	WARD BROOKE WB.1110/10/B	COVER, terminal block	1	—	C	
	—	PANEL, mounting, coded "AHW" (See sub-section KQ)	—	—	—	
5CZ/6424	WARD BROOKE WB.1114/28	PILLAR, fixing	2	—	C	
	10-22 N 1238	PLATE, identification, between terminal block and mounting panel, 22 SWG	1	L72	LM	NL1
28S/15846	A40/B10	SCREW, 4 BA	2	—	C	
28W/9419465	SP.13/B	WASHER	2	—	C	
28W/9416642	SP.47/B	WASHER, spring... ..	2	—	C	
	10-20 R 4147A	CABLE, coded "8.AHW-3.C3," assembly ...	1	—	ECC	
	10-20 R 4065A	CABLE, coded "AHW-AF-AHX," assembly ...	1	—	ECC	
	10-20 R 9283A	CABLE, coded "AJJ-AHW," assembly ...	1	—	ECC	
	PLESSEY 2Z.139597	RING, packing, under socket at pull off bracket coded "AJJ" on panel coded "AHW"	—	—	—	
	—	INSTALLATION AT NAVIGATOR'S EJECTOR SEAT GUN AND REAR PRESSURE BULKHEAD, CODED "Q" (Drg. Nos. 10-20 N 10635, 10-20 FS 18327 and 10-20 R 4121)	1	—	—	
28E/1201809	AS.3180/6B	CLIP, "P," cable attachment at auto-tone switch Attachments for AS.3180/6B, Clip :—	1	—	C	
28S/1200040	A31/B20	Screw, 4 BA	1	—	C	
19973	10-20 FS 21273	LEVER, striker	1	—	C	NL1
20075	10-20 FS 21285A/ND	MOUNTING, auto-tone switch and striker lever to seat gun, assembly Spares for :—	1	—	C	NL1
28D/12635	A25/24E	BOLT, 1/2" BSF, striker lever attachment ...	1	—	C	
28M/10290	AGS.2001/E/1	NUT, 1/2" BSF, striker lever attachment ...	1	—	C	
28W/9418921	SP.13/E	WASHER, striker lever attachment ...	2	—	C	
		Attachments for 10-20 FS 21285A/ND, Mounting :—				
28D/1200120	A25/14B	Bolt, 4 BA	4	—	C	
28M/10287	AGS.2001/B/1	Nut, 4 BA	4	—	C	
28W/9419465	SP.13/B	Washer	4	—	C	

RADIO AND RADAR INSTALLATIONS
INSTALLATION OF AUTO-TONE TRANSMISSION (MOD. 1183)

Ref. No.	Part No.	Description	1 2 3 4 5 6						No. off	Material Specification	Class of Score of L.M	Place No.
	10-20 R 9281A	SWITCH , auto-tone transmission, c/w cables, assembly						1	—	—	NL1	
32A/	10-20 R 9281A/ CABLES	CABLE , assembly (Supplied with switch) ...						1	—	ECC		
19356	S.R.D.E. PS.8784	CORD						QR	Nylon	C		
19357	10-20 R 9293A	PLATE , pull off, 20 SWG						1	—	C	NL1	
	10-20 R 9295	RING , packing, 1" 20 o/d x 0" 90 i/d x 0" 25 thick						1	—	C	NL1	
5930-99-914-1941	—	SWITCH , auto-tone (Supplied c/w cables) ...						1	—	P		
5K:911	ROSS COURTNEY WE.503	TERMINAL						1	—	C		
		Attachments for 10-20 R 9281A, Switch:—										
28P/1013002	SP.4Y/B9	Pin, shackle						1	—	C		
28P/1007741	SP.9/C8	Pin, split						1	—	C		
28S/9419435	A31/B12	Screw, 4 BA						4	—	C		
28W/9419465	SP.13/B	Washer						4	—	C		
28W/9419402	SP.13/C	Washer						1	—	C		
	—	TERMINAL , earth, station 3, coded "C" on rear pressure bulkhead, group						1	—	—		
26DV/7529	DHS.438/C	TAG , corrosion						1	—	C	EBYB	
26DV/4969	DHS.437/C	TERMINAL , earth, assembly (For breakdown see DHS. Data Sheet)						1	—	C		
		Attachments for DHS.437/C, Terminal:—										
28M/10288	AGS.2001/C/1	Nut, 2 BA						2	—	C		
28W/9419475	SP.15/C	Washer						2	—	C		
	—	INSTALLATION AT POWER UNIT CRADLE UNDER EQUIPMENT DECK, AFT OF PILOT'S SEAT (Drg. Nos. 10-20 N 11713 and 10-20 R 3687)						1	—	—		
	10-20 R 4077A	BRACKET , mounting, c/w flasher-unit, assembly						1	—	—	NL1	
5CZ/6796	—	Spares for:— FLASHER-UNIT , Type B, 24 volt, coded "AHY"						1	—	P		
		Attachments for Ref. No. 5CZ/6796, Flasher-unit:—										
28D/1010658	A25/1B	Bolt, 4 BA						4	—	C		
28M/10287	AGS.2001/B/1	Nut, 4 BA						4	—	C		
28W/9419465	SP.13/B	Washer						4	—	C		
		Attachments for 10-20 R 4077A, Bracket:—										
28D/1010029	A25/6B	Bolt, 4 BA						4	—	C		
	AS.2810/4/050	Tube, distance, 1/2" o/d x 20 SWG x 0" 50 long ...						4	L.62	LM		
28W/9419465	SP.13/B	Washer						4	—	C		
	10-20 R 4069A	CABLE , coded "AHY-AF," assembly						1	—	ECC		
	—	INSTALLATION AFT OF PILOT'S SEAT ON COCKPIT WALL, PORT, AT PANEL, CODED "AF" (Drg. Nos. 10-20 R 9355, Pre Mod. 9290; 10-20 R 9349, Mod. 1290 and 10-20 R 3687)						1	—	—		
	—	BLOCK , terminal, coded "A" and "B," group (See sub-section NH)						—	—	—		
	—	BLOCK , terminal, coded "H," group						1	—	—		


INSTALLATION OF AUTO TONE TRANSMISSION (MOD. 1183)

Ref. No.	Part No.	Description	No. off						Material Specification	Class of Store or L.M	Place No.	
			1	2	3	4	5	6				
	DHS.456/10L	BLOCK , terminal, 10-way, L.H., assembly ... (For breakdown see DHS Data Sheet)							1	—	—	
5X/3275	PLESSEY CZ.26808	COVER , terminal block ...							1	—	C	BA13
28M/10287	AGS.2001/B/1	NUT , 4 BA ...							2	—	C	
7657	DHS.870/5	PILLAR , fixing, 4 BA ...							2	—	C	BA17
26DV/12296	DHS.489/5	SPACER (Pre Mod. 1290) ...							2	—	C	BA13
	10-20 R 2547/Mk. 144	CABLE , coded "6.H.A.F.-H.CR.19," assembly ...							1	—	ECC	
	10-20 R 4067A	CABLE , coded "AHX-AF," assembly ...							1	—	ECC	
	10-20 R 9355/ CABLES	CABLES , link (Pre Mod. 1290) ...							QR	—	ECC	
	10-20 R 9349/ CABLES	CABLES , link (Mod. 1290) ...							QR	—	ECC	
19353	10-20 R 4063A	CONNECTOR , coded "MQ3-AF," assembly ...							1	—	C	
	—	PANEL , coded "AF" (See sub-section NH) ...							—	—	—	
	—	INSTALLATION AT PILOT'S EJECTOR SEAT GUN AND AT PANEL, CODED "H" (Drg. No. 10-20 FS 18325)							1	—	—	
	—	BLOCK , terminal, coded "CR," group (See sub-section EBZ)							—	—	—	
19973	10-20 FS 21273	LEVER , striker ...							1	—	C	NL1
20075	10-20 FS 21285A/ND	MOUNTING , auto-tone switch and striker lever to seat gun, assembly Spares for :—							1	—	C	NL1
28D/12550	A25/22E	BOLT , 1/4" BSF, striker lever attachment ...							1	—	C	
28M/10290	AGS.2001/E/1	NUT , 1/4" BSF, striker lever attachment ...							1	—	C	
28W/9418921	SP.13/E	WASHER , striker lever attachment ...							2	—	C	
		Attachments for 10-20 FS 21285A/ND, Mounting :—										
28D/1200120	A25/14B	Bolt, 4 BA ...							4	—	C	
28M/10287	AGS.2001/B/1	Nut, 4 BA ...							4	—	C	
28W/9419465	SP.13/B	Washer ...							4	—	C	
	10-20 R 4059A	SWITCH , auto-tone transmission, c/w cables, assembly							1	—	—	NL1
	10-20 R 4059A/ CABLES	CABLE , assembly (Supplied with switch) ...							1	—	ECC	
5930-99-914-1941	—	SWITCH , auto-tone (Supplied c/w cables) ...							1	—	P	
		Attachments for 10-20 R 4059A, Switch :—										
28P/1013002	SP.4Y/B9	Pin, shackle ...							1	—	C	
28P/1007741	SP.9/C8	Pin, split ...							1	—	C	
28S/9419435	A31/B12	Screw, 4 BA ...							4	—	C	
28W/9419465	SP.13/B	Washer ...							4	—	C	
28W/9419402	SP.13/C	Washer ...							1	—	C	
	—	INSTALLATION ON TOP FUSELAGE PANEL FRAME STN. 107"0, STARBOARD, AND I.F.F. PANEL, CODED "AN" (Drg. Nos. 10-20 FS 20749, 10-20 N 20443 and 10-20 R 3687)							1	—	—	
	—	BLOCK , terminal, coded "AHX," group ...							1	—	—	
5CZ/6589	WARD BROOKE WB.1110/S/10/B	BLOCK , terminal, 10-way single, assembly ...							1	—	C	
5CZ/6574	WARD BROOKE WB.1110/S/B	COVER , terminal block ...							1	—	C	
5CZ/6424	WARD BROOKE WB.1114/28	PILLAR , fixing ...							2	—	C	

RADIO AND RADAR INSTALLATIONS

INSTALLATION OF AUTO TONE TRANSMISSION (MOD. 1183)

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M.	Plate No.
28S/6350	A40/B12	SCREW, 4 BA	2	—	C	
28VV/9419465	SP.13/B	WASHER	2	—	C	
28VV/9416642	SP.47/B	WASHER, spring... ..	2	—	C	
	10-20 R 4145A	CABLE, coded "9.AHX-★29.A.3," assembly ...	1	—	ECC	
	—	SWITCH, auto-tone, cancel, coded "T," group	1	—	—	
	10-20 N 24593	GUARD, switch, engraved "AUTO-TONE CANCEL," white on block, 18 SWG	1	L.72	LM	NL1
	10-20 N 24597A	SWITCH, auto-tone cancel, c/w cables, assembly	1	—	—	NL1
	10-20 N 24597A/ CABLES	CABLE, assembly	1	—	ECC	
5930-99-580-0392	N.S.F.7691B.100	SWITCH	1	—	P	NL1
	—	TERMINAL, earth, station 29, coded "A," on top longeron, stn. 120"72, Starboard, group	1	—	—	
26DV/7529	DHS.438/C	TAG, corrosion	1	—	C	EBY8
6608	10-20 N 2295A	TERMINAL, earth, 45°, assembly	1	—	C	EBY8
	10-20 N 2297A	BRACKET, assembly	1	—	LM	EBY8
	DHS.436ND	PLATE, doubling, 14 SWG	1	BS.265	LM	EBY8
	10-20 N 2299ND	PLATE, terminal, 16 SWG	1	BS.265	LM	EBY8
26DV/11786	AS.2751	CIRCLIP	4	—	C	EBY8
12687	DHS.379/1	LABEL, half	1	BS.265	C	EBY8
12688	DHS.279/2	LABEL, half	1	BS.265	C	EBY8
26DV/11785	AS.2749	SOCKET, half	8	BS.265	C	EBY8
5X/9028	AS.2747	SOCKET, terminal, assembly	4	—	C	EBY8
26DV/11787	AS.2752	SPACER	4	—	C	EBY8
		Attachments for 10-20 N 2295A, Terminal:—				
28D/9140202	AS.1246/1C	Bolt, 2 BA	2	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA	2	—	C	
28VV/9419454	SP.10/C	Washer	2	—	C	
5F/9434858	—	STRAP, flexible, cable fastening, $\frac{5}{16}$ " wide	QR	P.V.C.	C	
5F/9434857	—	STRAP, flexible, cable fastening, $\frac{1}{2}$ " wide	QR	P.V.C.	C	
5F/2307	—	STUD, $\frac{1}{16}$ " cable fastening strap	QR	Nylon	C	
5F/2302	—	STUD, $\frac{1}{8}$ " cable fastening strap	QR	Nylon	C	
32B/—	—	TAPE, identification, numbers and letters, use from Ref. Nos. 32B/1087 to 32B/1120 inclusive as required	QR	—	C	



NL.1

**RADIO AND RADAR
AUTO-TONE TRANSMISSION**

NL.1

[A.L.63]

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

