

INDEX OF ASSEMBLIES

Page 23

Assembly	Drawing No.	Page No.	Plate No.	Follows Page No.
AIRFRAME COMPONENTS ...	A3073 & A3089	B1	—	—
ALIGHTING GEAR				
Main Undercarriage ...	K2724, K2727 & D9529 Sht 14	CA1	—	—
Nosewheel Undercarriage ...	K2737	CB1	—	—
ARMAMENT				
Bomb Gear ...	W1026	DA1	—	—
Gun and Ammunition Installation ...	—	DB1	—	—
Pyrotechnics ...	—	DC1	—	—
CONTROLS				
Auto Pilot ...	V6704 & R3987	EA1	—	—
Engine, at Bulkhead, outboard Port and Starboard ...	1 & 9.O.4257	EB1	—	—
Engine, Centre Portion Fuselage ...	52.O.3311	EC1	—	—
Engine, Front Centre Portion ...	O.3692	ED1	—	—
Engine, Front Spar, to Bulkhead In/bd. ...	1.O.4255	EE1	—	—
Engine, Mainplane Outer Port and Starboard ...	61 & 62.O.3311	EF1	—	—
Flying, in Fuselage ...	—	EG1	—	—
Flying, in Mainplane ...	1 & 2R3881	EH1	—	—
Flying, in Tailplane ...	250 & 254G2831	EJ1	—	—
Flying, Locking, Fuselage ...	—	EK1	—	—
Flying, Locking, Tailplane and Fin ...	—	EM1	—	—
Flying, Trimmer, Fuselage ...	R3695	EN1	—	—
Flying, Trimmer, Mainplane ...	—	EP1	—	—
Flying, Trimmer, Tailplane ...	—	EQ1	—	—
Nosewheel, Steering ...	R3886	ER1	—	—
Parking, Brake ...	R4002	ES1	—	—
ELECTRICAL INSTALLATION				
Centre Portion ...	4V6933	FA1	—	—
Edge, Trailing, Inner Port and Starboard ...	10 & 14V7300	FB1	—	—
Front Centre Portion ...	3V6933	FC1	—	—
Mainplane, Inner, Port and Starboard ...	1 & 13V7300	FD1	—	—
Mainplane, Outer, Port and Starboard ...	2 & 4V7300	FE1	—	—
Nose Portion ...	2V6933	FF1	—	—
Rear Centre Portion ...	5V6933	FG1	—	—
Rear Portion ...	6V6933	FH1	—	—

INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.	Plate No.	Follows Page No.
EQUIPMENT, AIRCRAFT				
Black-out Curtains and Sunblinds	—	GA1	—	—
Compass Installation	—	GB1	—	—
Dinghy and Parachute	—	GC1	—	—
Equipment (Special) in Nose	Z7770	GD1	—	—
Galley	Z7826	GE1	—	—
Instrument Panels	—	GF1	—	—
Photographic	—	GG1	—	—
Seats, Bunks and Fittings	—	GH1	—	—
Trimming and Soundproofing... ..	Z7845	GJ1	—	—
Toilet and Washbasin	—	GK1	—	—
EQUIPMENT, SPECIAL OPERATION (S.O.O.)				
Carrier, for Engine or Power Plant, in Bomb Bay	—	HA1	—	—
Carrier, Undercarriage Wheels, in Bomb Bay	—	HB1	—	—
Carrier, and Oxygen Bottles	AT81901	HC1	—	—
Ditching Position, for 11 Passengers... ..	Z8660	HD1	—	—
Tank, Drop Fuel (400 Gallon) (See—Tanks)	—	—	—	—
Turret Installation	—	HE1	—	—
FUSELAGE				
Centre Portion	4A3089	JA1	—	—
Doors, Bomb	1 & 2D9758	JB1	—	—
Doors, Nosewheel	1 & 2D9965	JC1	—	—
Front Centre Portion	3A3089	JD1	—	—
Nose Portion	2A3089	JE1	—	—
Rear Centre Portion	5A3089	JF1	—	—
Rear Portion	6A3089	JG1	—	—
GROUND EQUIPMENT				
Aircraft Tool Kit	Z8106	KA1	—	—
Flight Tool Kit	Z8107	KB1	—	—
Handling and Storage	—	KC1	—	—
Jacking	—	KD1	—	—
Power Plant Changing... ..	—	KE1	—	—
Rigging Equipment	—	KF1	—	—
Testing and Servicing	—	KG1	—	—
Towing and Steering	—	KH1	—	—
Trestling and Slinging	—	KJ1	—	—

SHACKLETON Mk. 3

INDEX OF ASSEMBLIES

Page 25

Assembly	Drawing No.	Page No.	Plate No.	Follows Page No.
MAINPLANES				
Aileron No. 1, Port and Starboard	1 & 150F9125	MA1	—	—
Aileron No. 2, Port and Starboard	1 & 2F9128	MA3	—	—
Aileron No. 3, Port and Starboard	1 & 2F9131	MA7	—	—
Aileron No. 4, Port and Starboard	1 & 2F9134	MA9	—	—
Edge, Trailing, Inboard, Port and Starboard	2F9349 & 2F9350	MB1	—	—
Edge, Trailing, Outboard, Port and Starboard	2F9274 & 2F9275	MB7	—	—
Flaps, Inboard, Port and Starboard	1F6794 & 1F6795	MC1	—	—
Flaps, Outboard, Port and Starboard	1F6877 & 1F6883	MC5	—	—
Flaps, Extension, Port and Starboard	1F6881 & 1F6882	MC7	—	—
Mainplane, Inner, Port and Starboard	1 & 2F9257	MD1	—	—
Mainplane, Outer, Port and Starboard	1 & 2F8856	ME1	—	—
POWER INSTALLATION				
Bulkhead, Fireproof, Inboard, Port and Starboard	1 & 2E2803	NA1	—	—
Bulkhead, Fireproof, Outboard, Port and Starboard	1 & 2E2839	NB1	—	—
Cooling System	—	NC1	—	—
Gearbox and Accessories, Inboard, Port and Starboard	1.O.3723 & 1.O.3724	ND1	—	—
Gearbox and Accessories, Outboard, Port and Starboard	1 & 2.O.3725	NE1	—	—
Power Installation, Nacelle and Fairings, Inboard	1 & 2 E2808	NF1	—	—
Power Installation, Nacelle and Fairings, Outboard	1 & 2 E2837	NG1	—	—
Subframe, Engine, Inboard, Port and Starboard	1.O.3657	NH1	—	—
Subframe, Engine, Outboard, Port and Starboard	1 & 2.O.4261	NH2	—	—
RADIO AND RADAR INSTALLATION				
	—	P1	—	—
SERVICES				
Air Conditioning	Z7841	QA1	—	—
Air Speed Indicator and Air Mileage Unit	—	QB1	—	—
De-icing	—	QC1	—	—
Dry Air Sandwich Windscreen	Q1999	QD1	—	—
Emergency Air	—	QE1	—	—
Fire Protection and Hand Extinguishers	—	QF1	—	—
Fuel Installation	P3053	QG1	—	—
Fuel (Boost and Primer)	P3085	QH1	—	—
Fuel (Heater)	P3111	QJ1	—	—
Fuel (Methanol Water)	P3107	QK1	—	—
Fuel (Nitrogen)	P3106	QM1	—	—

INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.	Plate No.	Follows Page No.
SERVICES (Cont'd)				
Hydraulics	—	QN1	—	—
Oil Pressure	—	QP1	—	—
Oil System	P.3097 & P.3148	QQ1	—	—
Oxygen	—	QR1	—	—
Pneumatic, Fresh Water and Humidity ...	—	QS1	—	—
Vacuum	—	QT1	—	—
Windscreen Wiper	Q1992 & Q2045	QU1	—	—
A.S.V. Pressurisation System	Q2225	QV1	—	—
TAIL UNIT				
Elevator, Port and Starboard	13 & 14G2968	RA1	—	—
Fin, Port and Starboard	1 & 2H2434	RB1	—	—
Rudder, Port and Starboard	1 & 2H2435	RC1	—	—
Tailplane, Port and Starboard	250 & 254G2831	RD1	—	—
TANKS				
De-icing	—	SA1	—	—
Fuel	—	SB1	—	—
Fuel, Drop (400 Gallon) (S.O.O.)	4P2908	SC1	—	—
Methanol Water, Port and Starboard ...	1 & 2P3094	SD1	—	—
Oil, Inboard and Outboard, Port and Starboard	21 & 22P2718	SE1	—	—
board	1 & 2P2882			
Relief, in Toilet	1Z7836	SF1	—	—
Septic, in Nose	24Z8417	SG1	—	—
Special, Equipment, in Nose	22Z7609	SH1	—	—
Water, Cold (Windscreen and Humidity) ...	Z8072	SJ1	—	—
Water, Fresh	1Z8037	SK1	—	—
Water, Waste	1Z8028	SM1	—	—
Wing Tip, Port and Starboard	1 & 2P3130	SN1	—	—
SCHEDULES				
Cable, Electrical	—	T1	—	—
Cable, Wire Rope	—	U1	—	—
Pipes	—	V1	—	—