


PILOT'S NOTES


WYVERN S.4



Prepared by direction

Promulgated for
information and guidance
of all concerned
by command of

ROLLS ROYCE
AERO INSTRUCTION SCHOOL



WYVERN S.4

LEADING PARTICULARS:

Wing Span

Wings spread 44' 0"
Wings folded 18' 0"

Height (tail down)

Wings spread 15' 6"
Wings folded 16' 5"
Max. height during folding 19' 0"

Length

Overall 42' 0"

NOTE.—This edition supersedes the 1st Edition issued July 1953.

LIST OF ASSOCIATED PUBLICATIONS
AND AIR DIAGRAMS

	A.P.
Air pump units	1519
Air cameras and accessories	1355C
Ejection equipment aircraft	4288A, B
Fuel system components for gas-turbine engines	4282
Gun and R.P. sights	1275E
Instrument manual	1275A and B
Parachutes and harnesses	1182A and B
Python Mk. 2 and 3 aero-engines	4293A
Signal manual	1186 Series
Torpedo sights	1275F
Wheels, tyres and brake systems	2237
Wyvern S.4 aircraft	4272C
	A.D.
Python 2 and 3 aero-engines—Fuel system	4817
Hydraulic system	5063
Wing folding system	5071
Electrical system	5186

WYVERN S.4

LIST OF CONTENTS

	Page
FUEL SYSTEM DIAGRAM	8
FLYING CONTROLS LOCKING GEAR	19
EJECTION SEAT MK. 2B	26
PART I—DESCRIPTIVE	
Introduction	Para. 1
FUEL AND OIL SYSTEMS	
Fuel tanks	2
Fuel transfer system	3
Engine fuel system	4
Fuel contents gauges	5
H.P. cock control lever	6
Oil system	7
ENGINE CONTROLS	
Throttle control lever	8
Propeller blade stops	9
Reverse torque system	10
Propeller braking	11
Engine instruments	12
Engine starter controls	13
J.p.t. warning bell	14
MAIN SERVICES	
Electrical system (24 volts)	15
Hydraulic system	16
Pneumatic system	17
Vacuum system	18

AIRCRAFT CONTROLS

	<i>Para.</i>
Flying controls	19
Stick breaking	20
Flying controls locking gear	21
Trimming tab controls	22
Undercarriage controls and position indicator ..	23
Undercarriage emergency operation	24
Tailwheel control	25
Flaps control	26
Flaps emergency operation	27
Airbrakes control	28
Arrester hook control	29
Arrester hook emergency operation	30
Wing folding control	31

COCKPIT EQUIPMENT

Entry to aircraft	32
Hood operation	33
Hood jettisoning	34
Cockpit ventilation	35
Windscreen de-icing	36
Windscreen wiper	37
Ejection seat, Mk. 1B or Mk. 2B	38
Oxygen system	39
Emergency oxygen system	40
Cockpit lighting	41
External lighting	42
Pressure head heater	43
Ventilated suit system	44
Signal pistol	45
Fire warning lights and extinguisher pushbuttons	46

NAVIGATION EQUIPMENT

ADRS	47
Compasses	48
Chartboard	49

OPERATIONAL EQUIPMENT

Radio controls	50
Radar controls	51
Contacting altimeter	52

ARMAMENT EQUIPMENT

	<i>Para.</i>
Gyro Gunsight Mk. 4E	53
Gyro gunsight emergency lowering	54
G.45 camera and camera recorder	55
F.46 camera	56
F.24 cameras	57
Gun controls	58
R.P. controls	59
Bomb controls	60
Torpedo controls	61
Flare container control	62
"Window" launcher	63
RATOG and catapult gear	64
Bombs and torpedo jettisoning	65

PART II—LIMITATIONS

Engine limitations—Python 3	66
Flying limitations	67

PART III—HANDLING

Management of the fuel system	68
Pilot's external checks	69
Checks before starting	70
Starting the engine (compressed air)	71
Starting the engine (cartridge starter)	72
Warming up	73
Checks after starting	74
Testing the engine and services	75
Checks before taxiing	76
Taxiing	77
Checks before take-off	78
Take-off	79
Climbing	80
Engine handling	81
General flying	82
Use of airbrakes	83
Manoeuvrability	84
Flying at reduced airspeed	85
Flying in conditions of severe turbulence	86
Stalling	87
Diving	88
Checks before landing	89
Approach and landing	90

	<i>Para.</i>
Deck landing	91
Landing with asymmetric load	92
Simulated forced landing practice	93
Instrument approach	94
Going round again	95
Checks after landing	96
Stopping the engine	97

PART IV—EMERGENCY HANDLING

Engine failure in flight	98
Engine stalling	99
P.C.U. failures in flight	100
Restarting the engine in flight	101
Action in the event of fire	102
Hood jettisoning	103
Gyro gunsight emergency lowering	104
Abandoning the aircraft	105
Undercarriage and flaps emergency operation	106
Arrester hook emergency operation	107
Airbrake emergency operation	108
Flapless landing	109
Forced landing	110
Ditching	111
FLYING IN ICING CONDITIONS	111A
ELECTRICAL FAILURES	111B

PART V—OPERATING DATA

Pressure error corrections	112
Flight planning charts DATA	113
Fuel consumptions	114
Descent data	115
Free take-off distances	116
Catapulting	117

PART VI—ILLUSTRATIONS

	<i>Fig.</i>
Cockpit—port side	1
Cockpit forward view	2
Cockpit—starboard side	3

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

