

POWER INSTALLATION COWLING, ENGINE, PORT

Ref. No	Part No.	Description 1 2 3 4 5 6	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.A1.50.395	COWLING, ENGINE, PORT, ASSEMBLY	1	—	—	
		Spares for:—				
626	E.A1.50.103	Clip, toggle, hook spring	2	L.72	C	
627	E.A1.50.105	Clip, toggle, hook spring	2	L.72	C	
2973*	E.A1.50.249	COWL, FRONT, GROUP	1	—	A	
		(Supplied to Drg. No. E.A3.00.123 for spares purposes)				
3004	E.A3.00.121	COWL, FRONT, GROUP	1	—	A	
		Spares for:—				
18193	E.A1.50.843	AIR INTAKE, ASSEMBLY	—	—	B/MR	
		Spares for:—				
10699	E.A1.50.1055	Cover, plate, debris guard attachment plate ...	2	L.72	C	
	E.A1.50.1833	FRAME, FLANGED RING, ASSEMBLY (MOD. 2751)	—	—	—	
		Spares for:—				
33250	EEAS.75	Seal	1	Linatex	C	
3089	E.A1.50.1673	Plate, louvre	2	DTD.166B	C	
10702	E.A1.50.1597	Screen, perforated, 18 SWG	38	Comm. Alumn.	C	
26503	E.A1.50.1823	Sleeve, exhaust outlet	1	—	C	
6615	E.A3.00.239	Baffle, bleed valve air duct (supplied drilled with trim allowance)	1	—	C	
2111	E.A1.50.869	Baffle, bleed valve air duct	1	—	C	
5208	E.A1.50.1753	Duct, air compressor bleed valve	1	—	C	
4784	E.A1.50.1761	Panel, access, for adjustment of accelerator unit and bleed valve control	2	—	C	
4786	E.A1.50.1779	Panel, access, for bleed valve adjustment	1	—	C	
22530	E.A1.50.1805	Panel, access, for P.V. ram (Mod. 1470)	1	L.72	B	
22531	E.A1.50.1807	Panel, access, for P.V. ram (Mod. 1470)	1	L.72	B	
1025	EEAS.1/1C	Screw, 2 BA, c'sk. head, 120°	8	HTS	C	
1026	EEAS.1/1½C	Screw, 2 BA, c'sk. head, 120°	14	HTS	C	
3044	E.A1.50.841	COWL, BOTTOM, REAR (LESS U/C COWL DOOR), GROUP (PRE-MOD. 2545)	1	—	A	
		(Supplied to Drg. E.A3.00.131 for spares purposes)				
		Spares for:—				
4178	E.A1.50.65	Bracket, forward hinge	1	DTD.683	C/MR	
4171	E.A1.50.67	Bracket, aft hinge	1	DTD.683	C/MR	
	E.A1.50.427	COWL, BOTTOM REAR, ASSEMBLY	—	—	—	
		Spares for:—				
5182	E.A1.50.1601	Plate, engine oil sump draining pipe retaining ...	1	—	C	
3036	E.A1.50.317	Door, access, in bottom rear cowl	1	—	C	
3038	E.A1.50.319	Door, undercarriage cowl	1	—	C	

POWER INSTALLATION COWLING, ENGINE, PORT

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
633	E.A1.50.281	FASTENER, TOGGLE, GROUP	2	—	C	
		Spares for:—				
16312	E.A1.50.95	HANDLE, TOGGLE, FASTENER, GROUP ...	1	—	C/MR	
		Spares for:—				
29H/4100	TERRY 169	Ring, split, key, 1"	1	—	C	
635	E.A1.50.49	Spring, 19 SWG	1	Spring Steel Wire S.11	C	
16313	E.A1.50.155	Pin, special, stud	2	—	C/MR	
634	E.A1.50.282	FASTENER, TOGGLE, GROUP	2	—	C	
		Spares for this group are identical with those for group Ref. No. 633				
636	E.A1.50.283	FASTENER, TOGGLE, GROUP	1	—	C	
		Spares for:—				
7133	E.A1.50.97	HANDLE, TOGGLE, FASTENER, GROUP ...	1	—	C/MR	
		Spares for:—				
29H/4100	TERRY 169	Ring, split, key, 1"	1	—	C	
635	E.A1.50.49	Spring, 19 SWG	1	Spring Steel Wire S.11	C	
17661	E.A1.50.157	Pin, special, stud	2	—	C/MR	
637	E.A1.50.284	FASTENER, TOGGLE, GROUP	1	—	C	
		Spares for this group are identical with those for group Ref. No. 636				
	DZUS					
28FP/120	FJ5/60DS	Fastener	4	—	C	
	DZUS					
28FP/122	FJ5/70DS	Fastener	4	—	C	
	DZUS					
28FP/124	FJ5/80DS	Fastener	2	—	C	
628	E.A1.50.161	Panel, toggle, fastener housing	1	—	C	
5412	E.A1.50.1639	ROD, TENSION, FOR UNDERCARRIAGE COWL DOOR, AND CABLE CHECK, ASSEMBLY	1	—	B/MR	
		Consisting of:—				
28D/12531	A25/3C	Bolt, 2 BA, hex. head	1	—	C	
2624	E.A1.50.1641	Cable, check	1	—	C	
28K/551	SP.3/413	Fork, joint	1	—	C	
28K/552	SP.3/413L	Fork, joint	1	—	C	
28M/5234	A14/CB	Nut, 2 BA	1	—	C	
28M/5221	A14/CBI	Nut, 2 BA	1	—	C	
28M/12929	A27/CP	Nut, 2 BA, plain	1	—	C	
28U/4052	SP.8Y/2	Rod, tension	1	—	C	
28W/9419402	SP.13/C	Washer, 2 BA, plain	1	—	C	
	DZUS					
28FP/341	S5/325	Spring	6	—	C	
639	E.A1.50.365	Washer, undercarriage, door hinge thrust	2	L.46	C	
6503	E.A1.50.1793	Washer, cup, engine cowlng dzus fastener retaining (Mod. 886)	10	DTD.124A	C	

POWER INSTALLATION COWLING, ENGINE, PORT

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
30953	E.A3.50.23	COWL, BOTTOM, REAR (LESS U/C COWL DOOR), GROUP (MOD. 2545) (For a/c WD.951 and onwards. Supplied drilled to Pt. No. E.A3.00.263 with trim allowance). Spares for this group are identical with those for group Pt. No. E.A1.50.841 on Page 599, except for the following deletion and addition:— Delete:—	1	—	B	
	E.A1.50.427	COWL, BOTTOM, REAR, ASSEMBLY	1	—	—	
	E.A3.50.25	Add:— COWL, BOTTOM, REAR, ASSEMBLY	1	—	—	
3042	E.A1.50.845	COWL, TOP REAR, GROUP (Supplied to Drg. E.A3.00.127 drilled and with trim allowance) Spares for:—	1	—	A	
15026	E.A1.50.315	Door, access, igniter plug	2	—	C	
628	E.A1.50.161	Panel, toggle fastener housing	2	—	C	
633	E.A1.50.281	FASTENER, TOGGLE, GROUP Spares for:—	2	—	C	
16312	E.A1.50.95	HANDLE, TOGGLE FASTENER, GROUP Spares for:—	1	—	C/MR	
29H/4100	TERRY 169	Ring, split, key, 1"	1	—	C	
635	E.A1.50.49	Spring, 19 SWG	1	Spring Steel Wire S.11	C	
16313	E.A1.50.155	Pin, special, stud	2	—	C/MR	
634	E.A1.50.282	FASTENER, TOGGLE, GROUP Spares for:—	2	—	C	
16312	E.A1.50.95	HANDLE, TOGGLE FASTENER, GROUP Spares for:—	1	—	C/MR	
29H/4100	TERRY 169	Ring, split, key, 1"	1	—	C	
635	E.A1.50.49	Spring, 19 SWG	1	Spring Steel Wire S.11	C	
16313	E.A1.50.155	Pin, special, stud	2	—	C	
636	E.A1.50.283	FASTENER, TOGGLE, GROUP Spares for:—	2	—	C	
7133	E.A1.50.97	HANDLE, TOGGLE FASTENER, GROUP Spares for:—	1	—	C/MR	
29H/4100	TERRY 169	Ring, split, key, 1"	1	—	C	
635	E.A1.50.49	Spring, 19 SWG	1	Spring Steel Wire S.11	C	
17661	E.A1.50.157	Pin, special stud	2	—	C/MR	

POWER INSTALLATION COWLING, ENGINE, PORT

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
637	E.A1.50.284	FASTENER, TOGGLE, GROUP	2	—	C	
		Spares for:—				
7133	E.A1.50.97	HANDLE, TOGGLE FASTENER, GROUP ...	1	—	C/MR	
		Spares for:—				
29H/4100	TERRY 169	Ring, split, key, 1"	1	—	C	
635	E.A1.50.49	Spring, 19 SWG	1	Spring Steel Wire	C	
17661	E.A1.50.157	Pin, special, stud	2	S.11	C/MR	
	DZUS					
28FP/120	FJ5/60DS	Fastener	4	—	C	
	DZUS					
28FP/122	FJ5/70DS	Fastener	4	—	C	
	DZUS					
28FP/124	FJ5/80DS	Fastener	2	—	C	
	DZUS					
28FP/341	S5/325	Spring	8	—	C	
639	E.A1.50.365	Washer, undercarriage door hinge thrust ...	2	L.46	C	
6503	E.A1.50.1793	Washer, cup, engine cowling dzus fastener retaining (Mod. 886)	10	DTD.124A	C	
640	E.A1.50.109	Fitting, fork end, toggle fastener	2	S.11	C	
641	E.A1.50.111	Fitting, rod end, toggle fastener	1	DTD.683	C	
642	E.A1.50.135	Fitting, fork end, toggle fastener	6	DTD.683	C	
643	E.A1.50.137	Fitting, fork end, toggle fastener	8	DTD.683	C	
644	E.A1.50.391	Fitting, fork end, toggle fastener	1	DTD.683	C	
645	E.A1.50.29	Hook, cowl toggle fastener	8	S.11	C	
646	E.A1.50.45	Hook, cowl toggle fastener	10	S.11	C	
3040	E.A1.50.13	PANEL, SERVICE, GROUP	1	—	A	
		Spares for:—				
636	E.A1.50.283	FASTENER, TOGGLE, GROUP	2	—	C	
		Spares for:—				
7133	E.A1.50.97	HANDLE, TOGGLE FASTENER, GROUP ...	1	—	C	
		Spares for:—				
29H/4100	TERRY 169	Ring, split, key, 1"	1	—	C	
635	E.A1.50.49	Spring, 19 SWG	1	Spring Steel Wire	C	
17661	E.A1.50.157	Pin, special, stud	2	S.11	C/MR	
637	E.A1.50.284	FASTENER, TOGGLE, GROUP	2	—	C	
		Spares for this group are identical with those for group Ref. No. 636 on Page 600				
628	E.A1.50.161	Panel, toggle fastener housing	4	—	C	
	E.A1.50.291	PANEL, SERVICE, ASSEMBLY	—	—	—	
		Spares for:—				
16368	E.A6.50.283	Duct, ventilating (Mod. 2571)	2	—	C	
12063	E.B7.50.37	OUTLET, WHEEL CASE BREATHER, ASSEMBLY	1	—	C	
		Spares for:—				
21618	E.B7.50.41	Ring, sealing	1	Bestabell	C	
649	E.A1.50.393	Pin, turbine starter exhaust pipe locating ...	2	DTD.126	C	

CANBERRA P.R. MK. 3

Page 603

POWER INSTALLATION COWLING, ENGINE, PORT

Ref. No	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
3462	E.A1.50.1521	Pipe, engine starter exhaust (Pre-Mod. 1427) ...	2	—	C	
20524	E.A3.50.13	Pipe, engine starter exhaust (Mod. 1427) (Pre-Mod. 2347)	1	—	C	
13219	E.A3.50.21	Pipe, engine starter exhaust (Mod. 2347) ...	2	—	C	
1129	E.A1.50.1051	Screw, special, cowling to wing attachment ...	41	S.11	C	
1026	EEAS.1/1½C	Screw, 2 BA, c'sk. head ...	10	S.11	C	
1037	EEAS.1/8E	Screw, ½" BSF, c'sk. head ...	8	S.11	C	
651	E.A1.50.101	Spring, toggle hook tension ...	4	Spring Steel Wire	C	

Pl. 2.

Pages 60⁵ to 614 not issued



POWER INSTALLATION COWLING, ENGINE, STARBOARD

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
	E.A1.50.396	COWLING, ENGINE, STARBOARD, ASSEMBLY ...						1	—	—	
		Spares for:—									
626	E.A1.50.103	Clip, toggle hook spring						2	L.72	C	
627	E.A1.50.105	Clip, toggle hook spring						2	L.72	C	
2974*	E.A1.50.250	COWL, FRONT, GROUP						1	—	A	
		(Supplied to Drg. No. E.A3.00.124 for spares purposes)									
3005	E.A3.00.122	COWL, FRONT, GROUP						1	—	A	
		Spares for:—									
18193	E.A1.50.843	AIR INTAKE, ASSEMBLY						—	—	B/MR	
		Spares for:—									
10699	E.A1.50.1055	Cover, plate, debris guard attachment plate ...						2	L.72	C	
	E.A1.50.1833	FRAME, FLANGED RING, ASSEMBLY (MOD. 2751)						—	—	—	
		Spares for:—									
33250	EEAS.75	Seal						1	Linatex	C	
3089	E.A1.50.1673	Plate, louvre						1	—	C	
10702	E.A1.50.1597	Screen, perforated, 18 SWG						38	Comm. Alumn.	C	
26503	E.A1.50.1823	Sleeve, exhaust outlet						1	—	C	
6615	E.A3.00.239	Baffle, bleed valve air duct (supplied drilled with trim allowance)						1	—	C	
2111	E.A1.50.869	Baffle, bleed valve air duct						1	—	C	
5208	E.A1.50.1753	Duct, air compressor bleed valve						1	—	C	
4784	E.A1.50.1761	Panel, access, for adjustment of accelerator unit and bleed valve control						2	—	C	
4786	E.A1.50.1779	Panel, access, for bleed valve adjustment ...						1	—	C	
22530	E.A1.50.1805	Panel, access, for P.V. ram (Mod. 1470) ...						1	L.72	C	
22531	E.A1.50.1807	Panel, access, for P.V. ram (Mod. 1470) ...						1	L.72	C	
1025	EEAS.1/1C	Screw, 2 BA, c'sk. head, 120°						8	HTS	C	
1026	EEAS.1/1½C	Screw, 2 BA, c'sk. head, 120°						14	HTS	C	
3045	E.A1.50.842	COWL, BOTTOM, REAR (LESS U/C COWL DOOR), GROUP (PRE-MOD. 2545) (Supplied to Drg. No. E.A3.00.132 for spares purposes)						1	—	A	
		Spares for:—									
4143	E.A1.50.66	Bracket, forward hinge						1	DTD.683	C/MR	
4144	E.A1.50.68	Bracket, aft hinge						1	DTD.683	C/MR	
	E.A1.50.428	COWL, BOTTOM REAR, ASSEMBLY						—	—	—	
		Spares for:—									
5182	E.A1.50.1601	Plate, engine oil sump draining pipe retaining ...						1	—	C	
3037	E.A1.50.318	Door, access, in bottom rear cowl						1	—	C	
3039	E.A1.50.320	Door, undercarriage cowl						1	—	C	

POWER INSTALLATION COWLING, ENGINE, STARBOARD

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
633	E.A1.50.281	FASTENER, TOGGLE, GROUP						2	—	C	
		Spares for:—									
16312	E.A1.50.95	HANDLE, TOGGLE FASTENER, GROUP						1	—	C/MR	
		Spares for:—									
29H/4100	TERRY 169	Ring, split, key, 1"						1	—	C	
635	E.A1.50.49	Spring, 19 SWG						1	Spring Steel Wire	C	
	E.A1.50.157	Pin, special, stud						2	S.11	—	
634	E.A1.50.282	FASTENER, TOGGLE, GROUP						2	—	C	
		Spares for this group are identical with those for group Ref. No. 633									
636	E.A1.50.283	FASTENER, TOGGLE, GROUP						1	—	C	
		Spares for:—									
7133	E.A1.50.97	HANDLE, TOGGLE FASTENER, GROUP						1	—	C/MR	
		Spares for:—									
29H/4100	TERRY 169	Ring, split, key, 1"						1	—	C	
635	E.A1.50.49	Spring, 19 SWG						1	Spring Steel Wire	C	
17661	E.A1.50.157	Pin, special, stud						2	S.11	C/MR	
637	E.A1.50.284	FASTENER, TOGGLE, GROUP						1	—	C	
		Spares for this group are identical with those for group Ref. No. 636									
28FP/120	DZUS FJ5/60D/S	Fastener						4	—	C	
28FP/122	DZUS FJ5/70D/S	Fastener						4	—	C	
28FP/124	DZUS FJ5/80D/S	Fastener						2	—	C	
628	E.A1.50.161	Panel, toggle fastener housing						1	—	C	
5412	E.A1.50.1639	ROD, TENSION, FOR UNDERCARRIAGE COWL DOOR, AND CABLE CHECK, ASSEMBLY						1	—	B/MR	
		Spares for this assembly are identical with those for assembly Pt. No. E.A1.50.1639 on page 600									
28FP/341	DZUS SS/325	Spring						6	—	C	
639	E.A1.50.365	Washer, undercarriage cowl door hinge thrust						2	L.46	C	
6503	E.A1.50.1793	Washer, cup, engine cowling dzus fastener retaining (Mod. 886)						10	DTD.124A	C	

CANBERRA P.R. MK. 3

Page 617

POWER INSTALLATION COWLING, ENGINE, STARBOARD

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
30954	E.A3.50.24	COWL, BOTTOM REAR (LESS U/C COWL DOOR), GROUP (MOD. 2545) (For a/c WD.951 and onwards. Supplied drilled to Pt. No. E.A3.00.264 with trim allowance) Spares for this group are identical with those for Pt. No. E.A1.50.842 on page 615, except for the following deletion and addition Delete:—	1	—	—	
	E.A1.50.428	COWL, BOTTOM REAR, ASSEMBLY Add:—	1	—	—	
	E.A3.50.26	COWL, BOTTOM REAR, ASSEMBLY	1	—	—	
3043	E.A1.50.846	COWL, TOP REAR, STARBOARD, GROUP Spares for this group are identical with those for group Ref. No. 3042 on Page 601 (Supplied to Drg. E.A3.00.128, drilled and with trim allowance for spares purposes)	1	—	A	
640	E.A1.50.109	Fitting, fork end, toggle fastener	2	S.11	C	
641	E.A1.50.111	Fitting, rod end, toggle fastener	1	DTD.683	C	
642	E.A1.50.135	Fitting, fork end, toggle fastener	6	DTD.683	C	
643	E.A1.50.137	Fitting, fork end, toggle fastener	8	DTD.683	C	
644	E.A1.50.391	Fitting, fork end, toggle fastener	1	DTD.683	C	
645	E.A1.50.29	Hook, cowl toggle fastener	8	S.11	C	
646	E.A1.50.45	Hook, cowl toggle fastener	10	S.11	C	
3041	E.A1.50.14	PANEL, SERVICE, GROUP Spares for this group are identical with those for port group Ref. No. 3040 on page 602, except for the following deletion and addition Delete:—	1	—	A	
	E.A1.50.291	PANEL, SERVICE, ASSEMBLY Add:—	—	—	—	
	E.A1.50.292	PANEL, SERVICE, ASSEMBLY Spares for this assembly are identical with those for Pt. No. E.A1.50.291 on Page 602	—	—	—	
649	E.A1.50.393	Pin, turbine starter, exhaust pipe locating	2	DTD.126	C	
3462	E.A1.50.1521	Pipe, engine starter, exhaust (Pre-Mod. 1427)	2	—	C	
20524	E.A3.50.13	Pipe, engine starter, exhaust (Mod. 1427) (Pre-Mod. 2347)	2	—	C	
13219	E.A3.50.21	Pipe, engine starter, exhaust (Mod. 2347)	2	—	C	
1129	E.A1.50.1051	Screw, special, cowl to wing attachment	41	S.11	C	
1026	EEAS.1/1½C	Screw, 2 BA, c'sk. head	10	S.11	C	
1037	EEAS.1/8E	Screw, ½" BSF, c'sk. head	2	S.11	C	
651	E.A1.50.101	Spring, toggle hook tension	4	Spring Steel Wire	C	

Pages 619 to 628 not issued



CANBERRA P.R. MK. 3

Page 629

POWER INSTALLATION COWLING, ENGINE, PORT AND STARBOARD

Ref. No.	Part No.	1	2	3	4	5	6	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.	
											M.R. L.M.		
		SUMMARY OF STOCK ITEMS USED ON ENGINE COWL, PORT AND STARBOARD, ASSEMBLY											
28D/12531	A25/3C	Bolt, 2 BA, hex. head, .75 long	...	...	...	...	...				C		
28D/12537	A25/14C	Bolt, 2 BA, hex. head, 1.85 long	...	...	...	...	...				C		
28D/12567	A25/20C	Bolt, 2 BA, hex. head, 2.45 long	...	...	...	...	...				C		
28D/13447	A25/21C	Bolt, 2 BA, hex. head, 2.55 long	...	...	...	...	...				C		
28D/11937	AS.1246/1B	Bolt, 4 BA, round head, .45 long	...	...	...	...	...				C		
28N/5553	AGS.899/6	Collar	...	...	...	...	...				C		
28M/13124	A27/CT	Nut, 2 BA, thin	...	...	...	...	...				C		
28M/9403520	A27/CP	Nut, 2 BA, plain	...	...	...	...	...				C		
28M/12931	A27/ET	Nut, 1/2" BSF, thin	...	...	...	...	...				C		
28M/13326	A27/GT	Nut, 5/8" BSF, thin	...	...	...	...	...				C		
28M/10287	AGS.2001/B/1	Nut, stiff, 4 BA	...	...	...	...	...				C		
28M/10288	AGS.2001/C/1	Nut, stiff, 2 BA	...	...	...	...	...				C		
28P/1201	AGS.166/1	Pin, split, 1/8" x 1/2"	...	...	...	...	...				C		
28P/9429528	SP.9/C8	Pin, split, 1/8" x 1"	...	...	...	...	...				C		
28P/12262	SP.9/E6	Pin, split, 3/32" x 3/4"	...	...	...	...	...				C		
28P/12351	SP.9/E8	Pin, split, 3/32" x 1"	...	...	...	...	...				C		
28P/864	SP.4Y/D6	Pin, shackle, 1/4" x .5"	...	...	...	...	...				C		
28P/868	SP.4Y/D10	Pin, shackle, 1/4" x .7"	...	...	...	...	...				C		
28P/900	SP.4Y/F10	Pin, shackle, 1/8" x .7"	...	...	...	...	...				C		
28P/1070	SP.4Y/F18	Pin, shackle, 1/8" x 1.2"	...	...	...	...	...				C		
28P/938	SP.4Y/H16	Pin, shackle, 3/8" x 1"	...	...	...	...	...				C		
28W/9419474	SP.15/B	Washer, 4 BA, plain	...	...	...	...	...				C		
28W/9419404	SP.16/C	Washer, 2 BA, plain	...	...	...	...	...				C		
28W/9419402	SP.13/C	Washer, 2 BA, plain	...	...	...	...	...				C		

Restricted

[illegible]

Restricted

POWER INSTALLATION ENGINE MOUNTINGS AND ATTACHMENTS, PORT

Re. No.	Part No.	Description					No. of	Matl. Spec.	Cl. of St. M.R.	Plate and Illust'n No.
		1	2	3	4	5				
	E.A1.51.1	ENGINE MOUNTINGS AND ATTACHMENTS, PORT, ASSEMBLY					—	—	—	
		Spares for :—								
951	E.A1.51.17	Bearing , spherical seating, rear engine mounting					2	S11	C	
952	E.A1.51.37	Bolt , eye, special, engine bracket and control bracket mounting					1	S11	C	
953	E.A1.51.39	Bolt , eye, special engine bracket and control bracket mounting					1	S11	C	
954	E.A1.51.3	BRACKET, ENGINE MOUNTING, REAR, GROUP					1	—	M/C	
		Consisting of :—								
	E.A1.51.11	Bracket , mounting					1	DTD.683	—	
956	E.A1.51.13	Cap , retaining					1	DTD.683	C	
28M/13295	A27Y/JP	Nut , $\frac{3}{8}$ " BSF, plain					2	MS	C	
3626	E.A1.51.207	Screw , grub					2	S11	C	
957	E.A1.51.15	Stud , special					1	S11	C	
28L/683	AGS.195/4	Washer , tab, lock, for stud nuts					2	—	C	
958	E.A1.51.5	MOUNTING, ENGINE, FORWARD, INBOARD, GROUP					1	—	M/C	
		Spares for :—								
960	E.A1.51.33	Bolt , special, shouldered, engine mounting					1	S11	C	
961	E.A1.51.201	Bracket , engine mounting					1	Z5Z	C	
963	E.A1.51.45	End , fork, tie rod					1	S11	C	
964	E.A1.51.27	Nut , locking, special					1	L40	C	
965	E.A1.51.25	Plug , retaining					1	L40	C	
966	E.A1.51.43	Rod , tie, adjustable spherical end					1	S65	C	
30A/1039 2296	—	Wire , locking, 20 SWG					QR	Soft Iron	C	

POWER INSTALLATION ENGINE MOUNTINGS AND ATTACHMENTS, PORT

Ref. No.	Part No.						No. off	Matl. Spec.	C. of St. M.R.	Plate and Illustr'n No.
		1	2	3	4	5				
967	E.A1.51.7	MOUNTING, ENGINE, FORWARD, OUTBOARD, GROUP					1	—	M.C	
		Spares for :—								
960	E.A1.51.33	Bolt , special shouldered, engine mounting...					1	S11	C	
969	E.A1.51.203	Bracket , engine mounting					1	Z5Z	C	
963	E.A1.51.45	End , fork, tie rod					1	S11	C	
964	E.A1.51.27	Nut , locking, special					1	L40	C	
965	E.A1.51.25	Plug , retaining					1	L40	C	
966	E.A1.51.43	Rod , tie, adjustable, spherical end					1	S65	C	
2296 30A/1039	→	Wire , locking, 20 SWG					QR	Soft Iron	C	
971	E.A1.51.19	Pin , special, spherical bearing, rear inboard bracket retaining					1	S11	C	

Pages 633 to 636 not issued



POWER INSTALLATION ENGINE MOUNTINGS AND ATTACHMENTS, STARBOARD

Ref. No.	Part No.	Description					No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4	5			M.R.	
	E.A1.51.2	ENGINE MOUNTINGS AND ATTACHMENTS, STARBOARD, ASSEMBLY					—	—	—	
		Spares for :—								
951	E.A1.51.17	Bearing,	spherical seating,	rear engine			2	S11	C	
			mounting							
952	E.A1.51.37	Bolt, eye,	special, engine bracket and control				1	S11	C	
			bracket mounting							
953	E.A1.51.39	Bolt, eye,	special, engine bracket and control				1	S11	C	
			bracket mounting							
955	E.A1.51.4	BRACKET, ENGINE MOUNTING, REAR, GROUP					1	—	M/C	
		Consisting of :—								
	E.A1.51.12	Bracket,	mounting	...	...	...	1	DTD.683	—	
956	E.A1.51.13	Cap,	retaining	...	...	...	1	DTD.683	C	
28M/13295	A.27/JP	Nut,	$\frac{3}{8}$ " BSF, plain	...	...	...	2	MS	C	
3626	E.A1.51.207	Screw,	grub	...	...	...	2	S11	C	
957	E.A1.51.15	Stud,	special	...	...	...	1	S11	C	
28L/683	AGS.195/4	Washer,	tab, lock, for stud nuts	...	...	...	2	—	C	
959	E.A1.51.6	MOUNTING, ENGINE, FORWARD, INBOARD, GROUP					1	—	M/C	
		Spares for :—								
960	E.A1.51.33	Bolt,	special, shouldered, engine mounting...				1	S11	C	
962	E.A1.51.202	Bracket,	engine mounting	...	...	...	1	Z5Z	C	
963	E.A1.51.45	End,	fork, tie rod	...	...	...	1	S11	C	
964	E.A1.51.27	Nut,	locking, special	...	...	...	1	L40	C	
965	E.A1.51.25	Plug,	retaining	...	...	...	1	L40	C	
966	E.A1.51.43	Rod,	tie, adjustable spherical end	...	...	...	1	S65	C	
30A/1039	20/2256	Wire,	locking, 20 SWG	...	...	...	QR	Soft Iron	C	

POWER INSTALLATION ENGINE MOUNTING AND ATTACHMENTS, STARBOARD

Ref. No.	Part No.	Description					No. off	Matl. Spec.	Cl. of St.	Plate and Illustr'n No.
		1	2	3	4	5			M.R.	
968	E.A1.51.8	MOUNTING, ENGINE, FORWARD, OUTBOARD, GROUP					1	—	M/C	
		Spares for :—								
960	E.A1.51.33	Bolt , special shouldered, engine mounting...					1	S11	C	
970	E.A1.51.204	Bracket , engine mounting					1	Z5Z	C	
963	E.A1.51.45	End , fork, tie rod					1	S11	C	
964	E.A1.51.27	Nut , locking, special					1	L40	C	
965	E.A1.51.25	Plug , retaining					1	L40	C	
966	E.A1.51.43	Rod , tie, adjustable, spherical end					1	S65	C	
30A/1039	30A/22916	Wire , locking, 20 SWG					QR	Soft Iron	C	
971	E.A1.51.19	Pin , special, spherical bearing, rear inboard bracket retaining					1	S11	C	

Pages 639 to 642 not issued



POWER INSTALLATION ENGINE MOUNTING AND ATTACHMENTS, PORT AND STARBOARD

Ref. No.	Part No.	1	2	3	4	5	Description	No. off	Matl. Spec.	Cl. of St. M.R.	Plate and Illust'n No.	
SUMMARY OF STOCK ITEMS USED ON ENGINE MOUNTINGS AND ATTACHMENTS, PORT AND STARBOARD, ASSEMBLY												
28D/12817	A.25/8G	Bolt, $\frac{5}{16}$ " BSF, hex. head, 1".35 long									C	
28D/	A.25/11G	Bolt, $\frac{5}{16}$ " BSF, hex. head, 1".65 long									C	
28D/12819	A.25/12G	Bolt, $\frac{5}{16}$ " BSF, hex. head, 1".75 long									C	
28M/13375	A.27/GP	Nut, $\frac{5}{16}$ " BSF, plain									C	
28M/13123	A.27/JS	Nut, $\frac{3}{8}$ " BSF, slotted									C	
28L/13244	A.27/PT	Nut, $\frac{9}{16}$ " BSF, thin									C	
28M/10291	AGS.2001/G/1	Nut, stiff, $\frac{5}{16}$ " BSF									C	
28P/	SP.9/C8	Pin, split, $\frac{1}{16}$ " dia. x 1" long									C	
28W/	SP.15/A	Washer, $\frac{5}{16}$ " BSF, plain									C	
28W/	SP.16/A	Washer, $\frac{5}{16}$ " BSF, plain									C	
28W/	SP.16/J	Washer, $\frac{3}{8}$ " BSF, plain									C	

CANBERRA P.R. MK.3

Page 645

POWER INSTALLATION RA3 ENGINE INSTALLATION, PORT

Ref. No.	Part No.						No. off	Matl. Spec.	Cl. of St. M.R. L.M.	Plate No.
		1	2	3	4	5				
	E.A1.00.103	RA3 ENGINE INSTALLATION, PORT, ASSEMBLY					—	—	—	
		Spares for:—								
6967	E.A4.61.97	Clip , pipe, special (Mod. 714)					1	—	C	
1380	E.A1.50.959	Duct , air, compressor bleed valve					1	—	C	
1381	E.A1.60.57	Pipe , flexible, fire protection system (Dunlop Pt. No. AHD.24508/10.75)					1	WH2/1	C	
1383	E.A1.57.15	Pipe , flexible, fuel feed to engine (Dunlop Pt. No. AHM.541/21.0)					1	WH2/1	C	
2961	E.A1.50.1665	Pipe , assembly, fuel drain					1	—	C	
3559	E.A2.75.393	PIPE, ASSEMBLY, H.P., CABIN PRESSURE SYSTEM, GROUP					1	—	C	
		Consisting of:—								
2969	K.A.C. CO., GLASGOW C.2593	Coupling , flexible					2	—	C	
28F/11777	AGS.1142/K	Nipple					3	—	C	
	E.A2.75.397	Pipe , elbow					1	—	—	
	E.A2.75.399	Pipe , assembly					1	—	—	
30A/2208	—	Wire , locking, 16 SWG					QR	Soft Iron	C	
19842	E.A2.57.785	Pipe , flexible, drop tank air supply (Mod. 1431)					1	No. 501	C	
1387	E.A3.57.33	Pipe , assembly, from compressor coupling to hose coupling					1	T26	C	
12064	E.A3.50.1	PIPE, ENGINE WHEEL CASE BREATHER, GROUP					1	—	B	
		Spares for:—								
1445	EEAS.66/4	Ring , clamping					2	DTD.610	C	
5850	E.A3.50.9	Sleeve , pipe connecting					1	Silastic	C	
6986	E.A4.61.103	Pipe , assembly, air cooling for 2-speed generator gear box (Mod. 714)					1	T26	C	
6969	E.A4.61.105	Pipe , assembly, flexible, air cooling for 2-speed generator gear box (Mod. 714)					1	—	C	
1391	E.A1.50.973	Ring , air duct retaining					4	DTD.213	C	
	E.A3.81.1105	THERMO-COUPLING, ASSEMBLY ...					4	—	—	
		Spares for:—								
		<i>Ykmo sample</i>					1	—	A	
6A/3811 6A/3812 3613	—	Tube , silicon rubber, $\frac{5}{16}$ " o/d x 16" long ...					1	Shore Hardness 70-80	C	



CANBERRA P.R. MK.3

Page 647

POWER INSTALLATION RA3 ENGINE INSTALLATION, STARBOARD

Ref. No.	Part No.	Description					No. off	Matl. Spec.	Cl. o. St.		Plate No.
									M.R.	L.M.	
	E.A1.00.104	RA3 ENGINE INSTALLATION, STARBOARD, ASSEMBLY					—	—	—		
		Spares for:—									
1380	E.A1.50.959	Duct , air, compressor bleed valve					1	—	C		
1382	E.A1.60.58	Pipe , flexible, fire protection system (Dunlop Pt. No. AHO.24509/10.75)					1	WH2/1	C		
1384	E.A1.57.16	Pipe , flexible, fuel feed to engine (Dunlop Pt. No. AHM.542/21.0)					1	WH2/1	C		
3560	E.A2.75.395	PIPE, ASSEMBLY, H.P., CABIN PRESSURE SYSTEM, GROUP					1	—	C		
		Consisting of:—									
2969	K.A.C. CO., GLASGOW C.2593	Coupling , flexible					2	—	C		
28F/11777	AGS.1142/K	Nipple					3	—	C		
	E.A2.75.419	Pipe , elbow					1	—	—		
	E.A2.75.401	Pipe , assembly					1	—	—		
30A/2208	→	Wire , locking, 16 SWG					QR	Soft Iron	C		
19846	E.B6.57.83	Pipe , flexible, drop tank air supply (Mod. 1431)					1	No. 501	C		
6970	E.B7.61.85	Pipe , flexible, air cooling, for 2-speed generator gear box (Mod. 714)					1	—	C		
12064	E.A3.50.1	PIPE, ENGINE WHEEL CASE BREATHER, GROUP					1	—	B		
		Spares for:—									
1445	EEAS.66/4	Ring , clamping					2	DTD.610	C		
5850	E.A3.50.9	Sleeve , pipe connecting					1	Silastic	C		
	E.A1.50.1667	PIPE, FUEL DRAIN, ASSEMBLY					—	—	—		
		Spares for:—									
2961	E.A1.50.1665	Pipe , drain					1	—	C		
1391	E.A1.50.973	Ring , air duct, retaining					4	DTD.213	C		
	E.A3.81.1105	THERMO-COUPLE, ASSEMBLY					4	—	—		
		Spares for:—									
		<i>Thermocouple</i>					1	—	A		
6A/384 601/541 3613	—	Tube , silicon rubber, $\frac{1}{8}$ " i/d x 16" long ...					1	Shore Hardness 75-80	C		



Pages 649 to 656 not issued



CANBERRA P.R. MK.3

Page 657

POWER INSTALLATION RA3 ENGINE INSTALLATION, PORT AND STARBOARD

Ref. No.	Part No.	Description					No. off	Matl. Spec.	Cl. of St.	Place and Illust'n No.
									M.R.	
		1	2	3	4	5				
		SUMMARY OF STOCK ITEMS USED ON RA3 ENGINE INSTALLATION, PORT AND STARBOARD, ASSEMBLY								
28F/6169	AGS.956/B	Nipple, adaptor, $\frac{1}{4}$ " dia. pipe	...	...	...				C	
8F/9619	AGS.1142/C	Nipple, adaptor, $\frac{3}{8}$ " dia. pipe	...	...	...				C	
28M/7683	AGS.572/A	Nut, $\frac{1}{4}$ " BSF, thin slotted	...	...	...				C	
28F/9439	AGS.1138/H	Washer, sealing	...	...	...	...			C	

[illegible]