

PART IV

INDEX TO EMERGENCY PROCEDURES

PART IV — INDEX TO EMERGENCY PROCEDURES

The following table shows the location of all emergency procedures covered in the text of the Notes and in the Flight Reference Cards.

<i>Emergency or Malfunction</i>	<i>Information in text Part, Chap., Para.</i>			<i>Location in FRCs</i>
Abandoning Barrier engagement	I, III,	9, 2,	1-9 1(g)	ABANDONING BARRIER ENGAGEMENT
Ditching	-	-	-	DITCHING
Electrical system				
Loads	I,	1,	18(a)(iii)	ELECTRICAL SYSTEM FAILURES
Single generator failure	I,	1,	18(a)	
Double generator failure	I,	1,	18(b)	
Low voltage	I,	1,	18(d)	
No. 1 and No. 2 inverter failure	I,	1,	19	
No. 5 inverter failure	I,	1,	20	—
No. 6 inverter failure	I,	1,	21	—
Blue Silk inverter failure	I,	1,	22	—
Overvolting	I,	1,	18(c)	—
Use of emergency battery	I,	1,	12+19 (note)	—
Engine				
Mechanical failure	-	-	-	ENGINE FAILURE
Flame out	III,	4,	3(b)	
Double flame out	III,	4,	4	
Immediate relight	III,	4,	3(a)	
Normal relight	III,	4,	3(d)	
Failure to relight	III,	4,	3(e)	
RPM surge at altitude	III,	2,	3(b)	LOW TEMP. ENGINE SURGE
Failure on take-off	III,	2,	1(g)&(h)	—
Handling in icing conditions	III,	2,	7	—
Handling in severe turbulence	III,	2,	6	—
Fire				
General	I,	7,	1	FIRE
Fire on the ground	-	-	-	
Wheelbrake fire	III,	3,	5(d)	
Engine fire	-	-	-	
Cabin fire	-	-	-	

Fuel				
Booster pump failure	I,	2,	13	BOOSTER PUMP FAILURE
Fuel drill after bomb hang-up	I,	2,	14	—
Jettison procedures				
Armament stores	I,	11,	12 & 14	JETTISON PROCEDURES
Wing tip tanks	I,	2,	1(c)	
	II,	2,	6	
	III,	2,	1(g)&(h)	
Navigator's hatch	I,	9,	9	
Canopy	I,	9,	8	
Entrance door	I,	9,	7	
Landing				
Without flaps	III,	3,	2	HAZARDOUS LANDINGS
Asymmetric landing	III,	4,	5	
Asymmetric wing tip fuel load	III,	3,	4	
After undercarriage malfunction	-	-	-	
Forced landing	-	-	-	
Oxygen				
Toxic fumes	I,	9,	17	EMERGENCY USE OF OXYGEN
Blinker failure	I,	9,	18	
Use of emergency bottle	I,	9,	20	
Partial system failure	I,	9,	19	
Pressurisation				
Cabin pressurisation failure	I,	8,	4	PRESSURISATION FAILURE
Undercarriage				
Failure to retract	I,	5,	7(a)	UNDERCARRIAGE
Failure to lower	I,	5,	8	
Wheelbrakes				
Hydraulic failure	I,	5,	11(b)	WHEELBRAKES
Bomb doors				
Failure to open	I,	11,	7	BOMB DOORS