

CANBERRA B Mk. 6

Page 415

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.1	PRESSURE CABIN EQUIPMENT, ASSEMBLY						—	—	—	
		Spares for:—									
27N/1	†	AXE, fire (Mod. 2197—S.O.O.)						1	—	B	
	E.A3.83.95	BALLAST UNDER BOMB AIMER'S RAMP, ASSEMBLY						—	—	—	
		Consisting of:—									
	E.A3.84.29	BLOCK, ballast (S.O.O. only)						3	—	—	
32203	E.A3.84.23	BLOCK, ballast, 18½ lbs. (S.O.O.)						1	—	B	
12997	E.A3.84.25	BLOCK, ballast, 49½ lbs. (S.O.O.)						3	—	B	
32202	E.A3.84.21	BLOCK, ballast, 106½ lbs. (S.O.O.)						1	—	B	
26763	E.A3.83.105	BLOCK, packing						1	—	C	
26762	E.A3.83.107	BLOCK, packing						2	—	C	
28D/1011239	A25/3E	BOLT, ½" BSF						1	—	C	
28D/1008151	A25/4E	BOLT, ½" BSF						1	—	C	
28D/1011240	A25/5E	BOLT, ½" BSF						1	—	C	
28D/1011254	A25/10E	BOLT, ½" BSF						4	—	C	
28D/1013176	AS.1242/10E	BOLT, ½" BSF						1	—	C	
28D/1212828	AS.1242/11E	BOLT, ½" BSF						1	—	C	
28D/1212831	AS.1242/14E	BOLT, ½" BSF						7	—	C	
13044	E.A3.83.97	BOX, ballast, assembly						1	—	B	
28M/1011475	A27/EP	NUT, ½" BSF						9	—	C	
28M/1201610	AGS.2001/E/1	NUT, ½" BSF						7	—	C	
26651	E.A3.83.169	PACKING						1	—	MR	
	E.A3.84.27	PACKING, ballast wood (S.O.O.)						1	—	—	
	E.A3.83.113	PACKING, ballast wood (Standard fitment until S.O.O. weights are fitted)						1	—	—	
32204	E.A3.83.99	STRAP, ballast box						1	—	B	
26760	E.A3.83.101	STRAP, supporting						2	—	C	
26650	E.A3.83.103	SUPPORT, ballast box						1	—	MR	
28W/9418921	SP.13/E	WASHER						11	—	C	
26761	E.A3.83.109	WASHER						1	—	C	
33887	E.A3.84.111	WASHER						2	—	C	
	E.A3.80.6175	BLOCK, STOWAGE, PILOT'S EJECTION SEAT SAFETY PINS, INSTALLATION (MOD. 4442)						—	—	—	
		Spares for:—									
6101183	E.A3.80.6547	BLOCK, stowage (Mod. 4925)						1	—	MR	
		Attaching parts for E.A3.80.6547:—									
28D/1204937	AS.1242/6C	Bolt, 2 BA						2	—	C	
1438887	E.A3.80.6173	CLIP, spring						1	—	C	
	E.B6.80.7133	BLOCK, STOWAGE, REAR CREW EJECTION SEAT SAFETY PINS, INSTALLATION (MOD. 4442)						—	—	—	
		Spares for:—									
6101183	E.A3.80.6547	BLOCK, stowage (Mod. 4925)						2	—	MR	
		Attaching parts for E.A3.80.6547:—									
28D/1010030	A25/7C	Bolt, 2 BA (Upper)						2	—	C	
28D/1200120	A25/14B	Bolt, 4 BA (Lower)						2	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA (Upper)						2	—	C	
1438886	E.A3.80.6183	Packer (Lower)						2	—	MR	
28W/9419401	SP.10/B	Washer (Lower)						2	—	C	
28W/9419454	SP.10/C	Washer (Upper)						2	—	C	
28W/9419175	SP.15/C	Washer (Upper)						2	—	C	

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
32569	E.B6.90.299	BRACKET , assembly, for type 705 control unit (Mod. 2542)						1	—	C	
	E.B6.82.265	BRACKET , assembly, for control panel type 912 (Mod. 2542)						1	—	—	
	E.B6.10.337	BRACKET , assembly, for intercomm. amplifier (Mod. 2542)						1	—	—	
	E.A3.80.2619	COMPASS, E2A, ASSEMBLY Spares for:—						—	—	—	
4626	E.A3.80.2623	BRACKET , mounting, assembly Attaching parts for E.A3.80.2623:—						1	—	C	
28M/4342710	AGS.2001/B/4	Nut, 4 BA						2	—	C	
28S/9148118	A43/B10	Screw, 4 BA						2	—	C	
6B/4343605	†	COMPASS , type E2A Attaching parts for Ref. 6B/4343605:—						1	—	A	
28M/4342710	AGS.2001/B/4	Nut, 4 BA						2	—	C	
28S/1012356	A43/B12	Screw, 4 BA						2	—	C	
8631	E.A3.80.2621	FLAP (Pre-Mod. 4724) Attaching parts for E.A3.80.2621:—						1	—	—	
28M/10273	AGS.2001/A/4	Nut, 6 BA						2	—	C	
8633	E.A3.80.1949	Pin, hinge						1	—	C	
8632	E.A3.80.2627	Spring						1	—	C	
8630	E.A3.80.2633	Tube						2	—	C	
28W/3537	AGS.1583/D	Washer, double spring						2	—	C	
	E.B6.80.39	CONSOLE, PILOT'S, ASSEMBLY Spares for:—						—	—	—	
	E.B6.80.59	FAIRING, CONTROL, GROUP Spares for:—						—	—	—	
5449	E.A3.80.2579	COVER , detachable						1	—	C	
36277	E.B7.80.135	MEMBER , vertical, assembly						1	—	C	
5808	E.B6.80.53	PANEL , side removable control access						1	L.72	C	
5625	E.B7.80.153	PANEL, REMOVABLE SNATCH UNIT ACCESS, ASSEMBLY Spares for:—						1	—	C	
33048	E.B7.80.419	FAIRING , assembly						1	—	C	
5626	E.B7.80.161	PANEL , side, removable control access						1	L.72	C	
5627	E.B7.80.163	PANEL , side, removable control access						1	L.72	C	
5628	E.B7.80.365	PANEL , forward removable battery access						1	L.72	C	
16709	E.B6.80.47	PLATE , cover						1	—	MR	
	E.A3.80.2057	CONTAINER, URINE, ASSEMBLY Spares for:—						1	—	—	
	E.A3.80.2801	BRACKET , support						1	—	—	
27H/3224	†	CONTAINER , Mk. 2						1	—	C	
27H/2316	†	FUNNEL						1	—	C	
27541	E.A3.10.3059	COVER AND MOUNTING, SIGNAL PISTOL, ASSEMBLY (PRE-MOD. 2187) Spares for:—						—	—	MR	
3654	E.A3.10.3003	BOLT , special						1	—	C	AE.1
2736	E.A3.10.2571	COVER , for signal mounting aperture						1	—	C	AE.1
—	E.A3.10.3033	PATCH , fabric						1	—	—	
2738	E.A3.10.2573	PLATE , spreader						1	—	C	AE.1
2737	E.A3.10.2575	SEAL , pressure						1	Rubber	C	AE.1
4433	E.A3.10.2995	SEAL , pressure						1	Linatex	C	
2734	E.A3.10.2659	WASHER						1	Rubber	C	

CANBERRA B. Mk. 6

Page 417

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B7.80.327	CURTAINS, BLACKOUT, ASSEMBLY						—	—	—	
		Spares for:—									
12993	E.B7.80.331	CURTAIN , main						1	—	B	
6332	E.A3.80.1753	CURTAIN , navigator's						1	—	B	
29G/4137	CARR. 759	FASTENER , "Durable Dot"						3	—	C	
28M/1278190	AGS.2001/C/1	NUT , 2 BA						4	—	C	
28M/9433473	AGS.2002/C/1	NUT , 2 BA						2	—	C	
18721	E.B6.80.139	PLATE , blackout, starboard						1	—	C	
22511	E.B6.80.183	PLATE , blackout, port						1	—	C	
3148	EEAS.132/12	STRAP , securing						2	—	C	
29G/2180	CARR. 882	STUD						6	—	C	
18854	EEAS.27/16ER	WASHER						2	L.72	C	
	E.B6.80.3	EQUIPMENT, BOMB AIMER'S, ASSEMBLY						—	—	—	
		Spares for:—									
6B/562	†	AMPLIFIER , type B, for gyro compass, Mk. 4B						1	—	A	
14A/2210	†	CONTROL , camera, remote, type 35, No. 8						1	—	A	
		Attaching parts for Ref. 14A/2210:—									
28M/1278190	AGS.2001/C/1	Nut , 2 BA						4	—	C	
28S/1200053	A.33/C16	Screw , 2 BA						4	—	C	
28W/9419475	SP.15/C	Washer						4	—	C	
8511	E.A3.80.929	FLOOR , assembly, bomb aimer's						1	—	C/MR	
	E.B6.80.41	LABEL , camera, master switch						1	—	—	
5K/3390	AS.3360/B/3B	LEAD , bonding						1	—	C	
		Attaching parts for AS.3360/B/3B:—									
28M/1278189	AGS.2001/B/1	Nut , 4 BA						1	—	C	
28S/1200053	A32/B12	Screw , 4 BA						1	—	C	
	EEAS.28/2CP	Washer						1	—	—	
5D/1482	†	PANEL , 24-way, bomb aimer's						1	—	A	
		Attaching parts for Ref. 5D/1482:—									
28D/1013301	AS.1248/4C	Bolt , 2 BA						6	—	C	
28W/9419475	SP.15/C	Washer						6	—	C	
14A/540	†	PLATE , wedge for camera control						1	—	C	
8515	E.A3.10.2799	RAMP , for strobe unit						1	—	C/MR	
5X/759	†	RING , locking, No. 1						1	—	C	
5X/769	†	RING , locking, No. 2						2	—	C	
5X/799	†	RING , locking, No. 4						2	—	C	
	ROTAX										
5CW/4184	D.5404/3	SWITCH , SP, "on/off"						1	—	B	
		Attaching parts for D.5404/3:—									
28S/1214164	A44/B14	Screw , 4 BA						2	—	C	
28W/1206041	AGS.2035/B	Washer						2	—	C	
5D/1566	†	SWITCH , fusing, Mk. 1						1	—	C	
		Attaching parts for Ref. 5D/1566:—									
28D/1008147	A25/1A	Bolt , 6 BA						4	—	C	
28M/10286	AGS.2001/A/1	Nut , 6 BA						4	—	C	
28W/9419473	SP.15/A	Washer						4	—	C	

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.6089	SWITCH, HATCH, DETONATOR, ASSEMBLY (MOD. 3776)						1	—	—	
		Spares for:—									
	E.A3.81.6517	FLAP, assembly (Mod. 4465)						1	—	—	
1439163	E.A3.81.6519	FLAP, SPRING, ASSEMBLY (MOD. 4465) ...						1	—	C	
		Spares for:—									
	E.A3.81.6513	FLAP (Mod. 4465)						1	BSS.265	—	
40619	E.A4.81.1663	FLAP, support						1	—	C	
27353	E.A4.81.1659	PIN						1	—	C	
27352	E.A4.81.1661	SPRING						1	—	C	
3223	E.A6.81.369	PIN, hinge						1	DTD.683	C	
3224	E.A1.81.929	SPRING, torsion						1	—	C	
	E.A3.81.6497	SWITCH-UNIT, sub-assembly (Mod. 4437) ...						1	—	—	
		Attaching parts for E.A3.81.6497:—									
	E.A3.81.6515	Packing (Mod. 4465)						1	LFS	—	
28S/	A32/A17	Screw, 6 BA (Reduce 28S/1200081 to suit) ...						4	—	—	
		SWITCH, type AS.10512C-1 (Mod. 4465) ...						2	—	B	
5CW/9255	†	TRAY, amplifier, mounting						1	—	B	
6B/437	†	Attaching parts for Ref. 6B/437:—									
28D/1215327	AS.1246/1E	Bolt, 1/2" BSF						4	—	C	
8509	E.A3.82.9	TRAY, mounting, strobe unit						1	—	B	
5D/1742	†	UNIT, control bomb distributor, 12/24way- Mk. 2						1	—	A	
		Attaching parts for Ref. 5D/1742:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA						4	—	C	
10A/19429	†	Washer, check						8	—	C	
8510	EEAS.12/2CP	WASHER						2	L.16	C	
	EEAS.28/2FR	WASHER						2	L.72	—	
15493	EEAS.28/2GP	WASHER						2	L.16	C	
	—	EQUIPMENT, NAVIGATOR'S AND BOMB AIMER'S LEG RESTRAINT (E.A3.80.2869) (MOD. 2580)						—	—	—	
		Spares for:—									
27L/510	A/MBEU/3666	BRACKET, floor						4	—	C	
27L/2729	B/MBEU/17353	LINE, leg (Mod. 3949)						4	—	C	
27L/80	C/MBEU/1434	PIN						4	—	C	
	—	EQUIPMENT, PILOT'S LEG RESTRAINT (E.B6.16.3) (MOD. 3278)						—	—	—	
		Spares for:—									
27L/510	A/MBEU/3666	BRACKET, floor						2	—	C	
27L/2729	A/MBEU/17353	LINE, leg (Mod. 3948)						2	—	C	
27L/80	C/MBEU/1434	PIN						2	—	C	
	E.A3.80.2009	EQUIPMENT, NAVIGATOR'S COMPARTMENT, ASSEMBLY						—	—	—	
		Spares for:—									
32565	E.B6.80.935	BRACKET, assembly, for A.M.U.						1	—	C	
	E.B6.80.915	BRACKET, assembly, for "G" scope						1	—	—	
	E.A3.80.2023	CONTROL, A.M.U., INSTALLATION						—	—	—	
		Spares for:—									
6B/471	†	PANEL, control for Mk. 4B air mileage unit ...						1	—	A	
		Attaching parts for Ref. 6B/471:—									
28D/9128739	AS.1248/1B	Bolt, 4 BA						4	—	C	

CANBERRA B. Mk. 6

Page 418A

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A3.80.2025	EQUIPMENT, FORWARD OF NAVIGATOR'S TABLE						—	—	—	
		Spares for:—									
6B/291	†	DRIVE , flexible						1	—	C	
	E.A3.80.2769	PLATE , base						1	L.72	—	
	E.A3.81.2269	PLATE , mounting						1	L.72	—	
		Attaching parts for E.A3.81.2269:—									
28D/8337	AS.1248/1B	Bolt, 4 BA						6	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						6	—	C	
28V/9419474	SP.15/B	Washer						6	—	C	
6B/314	†	REPEATER unit						1	—	A	
		Attaching parts for Ref. 6B/314:—									
28D/9436920	A25/1C	Bolt, 2 BA						3	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						3	—	C	
	EEAS.132/7	STRAP , cable						2	—	—	
		Attaching parts for EEAS.132/7:—									
28D/1218385	AS.1248/2B	Bolt, 4 BA						1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						1	—	C	
28V/9419474	SP.15/B	Washer						1	—	C	
3567	E.A3.80.49	FRAME , receiver, G.H.						1	—	C	AE.1

CANBERRA B Mk 6

Page 419

EQUIPMENT AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A3.20.2017	MOUNTING, ASSEMBLY, FOR G-H AND CONTROLLER						—	—	—	
		Spares for:—									
8744	E.A3.80.2461	BOLT , G.H. indicator, securing ...						2	—	C	
		Attaching parts for E.A3.80.2461:—									
28D/9140645	A25/10C	Bolt, 2 BA ...						1	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA ...						1	—	C	
28W/9419475	SP.15/C	Washer ...						1	—	C	
8746	E.A3.80.2463	CLAMP , toggle, G-H controller, securing ...						2	—	C	
8745	E.A3.80.107	NUT , knurled finger, G-H indicator securing ...						2	—	C	
		Attaching parts for E.A3.80.2017:—									
	WELLS & CO. LTD.										
10A/J/	H.D.F.M. 35	Mounting, equiflex ...						4	—	—	
28M/10292	AGS.2001/J/1	Nut, 1" BSF ...						8	—	C	
28W/9419477	SP.15/J	Washer ...						8	—	C	
	E.A3.80.2685	MOUNTING, R.F. UNIT, ASSEMBLY						—	—	—	
		Spares for:—									
	E.A3.80.2709	BRACKET ...						4	—	—	
		Attaching parts for E.A3.80.2709:—									
28D/9436920	A25/1C	Bolt, 2 BA ...						4	—	C	
28W/9419402	SP.13/C	Washer ...						4	—	C	
	E.A3.80.2687	MOUNTING, ASSEMBLY ...						1	—	—	
		Spares for:—									
10A/17616	†	MOUNTING , anti-vibration, type 682						4	—	B	
		Attaching parts for E.A3.80.2687:—									
28D/1011011	A25/8B	Bolt, 4 BA ...						4	—	C	
28W/9419465	SP.13/B	Washer ...						4	—	C	
	E.A3.80.2699	Washer ...						4	—	—	
	E.A3.80.2725	SUPPORT ...						1	—	—	
	E.A3.80.2726	SUPPORT ...						1	—	—	
		Attaching parts for E.A3.80.2725 and E.A3.80.2726:—									
28D/1010658	A25/1B	Bolt, 4 BA ...						2	—	C	
28W/9419465	SP.13/B	Washer ...						2	—	C	
10AB/2506	159/3	MOUNTING , assembly ...						1	—	A	
		Attaching parts for 159/3:—									
28D/1011245	A25/10E	Bolt, 1" BSF ...						4	—	C	
28M/10290	AGS.2001/E/1	Nut, 1" BSF ...						4	—	C	
8575	E.A3.80.1323	Washer ...						4	—	C	
	E.B6.80.5937	PANEL, INSTRUMENT, NAVIGATOR'S, ASSEMBLY (MOD. 3747) (PRE-MOD. 2530)						1	—	—	
		Spares for:—									
6A/8267/1	†	ALTIMETER , Mk. 19F ...						1	—	A	
		Attaching parts for Ref. 6A/8267/1:—									
28S/1214166	A44/B28	Screw, 4 BA ...						4	—	C	
28W/9419448	AGS.2035/B	Washer ...						4	—	C	

EQUIPMENT AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
8731	E.A3.80.551	BRACKET, L.H., instrument panel, attachment	1	—	C	
8735	E.A3.80.2329	BRACKET, R.H., instrument panel, attachment	1	—	C	
8732	E.A3.80.2325	CLIP, L.H., assembly, panel attachment on coaming tube	1	—	C	
8733	E.A3.80.2327	CLIP, R.H., assembly, panel attachment on coaming tube	1	—	C	
		Attaching parts for E.A3.80.2325 and E.A3.80.2327:—				
28D/9140645	A25/10C	Bolt, 2 BA	2	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA	2	—	C	
28W/9419402	SP.13/C	Washer	2	—	C	
6B/634	†	COMPASS, G.4B	1	—	A	
		Attaching parts for Ref. 6B/634:—				
28M/10281	AGS.2001/C3	Nut, 2 BA	3	—	C	
28S/1212721	A40/C32	Screw, 2 BA	3	—	C	
6B/556	†	HOLDER, deviation card	1	—	B	
6B/458	†	INDICATOR, air position	1	—	A	
		Attaching parts for Ref. 6B/458:—				
28D/1213484	AS.4565/9E	Bolt, 1/2" BSF	2	—	C	
28D/1213513	AS.4565/31E	Bolt, 1/2" BSF	1	—	C	
28M/10282	AGS.2001/E/3	Nut, 1/2" BSF	3	—	C	
28W/9419405	SP.15/E	Washer	3	—	C	
6A/4722	†	INDICATOR, air speed	1	—	A	
		Attaching parts for Ref. 6A/4722:—				
28D/1215159	AS.4565/1C	Bolt, 2 BA	3	—	C	
28M/10281	AGS.2001/C/3	Nut, 2 BA	3	—	C	
6A/2769	†	INDICATOR, air temperature S63-112, frame 4	1	—	A	
5CZ/5003	†	INDICATOR, electro magnetic	1	—	B	
10QB/6130	†	INDICATOR unit, type 208	1	—	A	
	E.A3.80.2301	PANEL, INSTRUMENT, SUB-ASSEMBLY	1	—	—	
		Spares for:—				
	E.A3.80.533	BRACKET, L.H., attachment	1	—	—	
	E.A3.80.2333	BRACKET, mounting altimeter	1	—	—	
	E.A3.80.2309	BRACKET, mounting indicator, type 208	1	—	—	
	A. WELLS & CO.					
	M.D.S.M.10	MOUNTING, equiflex	4	—	—	
10AJ/	†	VIBRATOR, unit and clip	1	—	A	
6A/7041	†	Attaching parts for E.B6.80.5937:—				
28D/1011242	A25/7E	Bolt, 1/2" BSF	1	—	C	
28D/1011244	A25/9E	Bolt, 1/2" BSF	1	—	C	
28D/1011245	A25/10E	Bolt, 1/2" BSF	1	—	C	
28D/1011246	A25/11E	Bolt, 1/2" BSF	1	—	C	
28M/10282	AGS.2001/E/3	Nut, 1/2" BSF	1	—	C	
28M/10330	AGS.2002/E/1	Nut, 1/2" BSF	3	—	C	
8734	E.A3.80.2331	Piece, distance	4	—	C	
28W/9419487	SP.16/E	Washer	2	—	C	

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
	E.B6.80.5939	PANEL, INSTRUMENT, NAVIGATOR'S, ASSEMBLY (MOD. 3747-2530) Spares for this assembly are identical with those for assembly Part No. E.B6.80.5937 on page 419, except for the following deletion and additions:— Delete:—						1	—	—	
	E.A3.80.2301	PANEL, INSTRUMENT, SUB-ASSEMBLY Add:—						1	—	—	
10Q/16314	†	INDICATOR , bearing, type 1630						1	—	A	
28S/9992525	A32/B12	Attaching parts for Ref. 10Q/16314:— Screw, 4 BA						4	—	C	
10Q/16073	†	INDICATOR , C.R.T., type 27						1	—	A	
28S/6350	A40/B12	Attaching parts for Ref. 10Q/16073:— Screw, 4 BA						4	—	C	
	E.B6.80.905	PANEL, INSTRUMENT, SUB-ASSEMBLY Spares for:—						1	—	—	
	E.B6.80.917	BRACKET , mounting, bearing indicator Attaching parts for E.B6.80.917:—						1	—	—	
28D/1007979	AS.1246/1B	Bolt, 4 BA						6	—	C	
28M/10287	AGS.2001/B/1	Nut, 4 BA						6	—	C	
28W/9419465	SP.13/B	Washer						6	—	C	
	E.B6.80.915	BRACKET , mounting, "G" scope Attaching parts for E.B6.80.915:—						1	—	—	
28D/1007979	AS.1246/1B	Bolt, 4 BA						6	—	C	
	E.A3.80.2013	TABLE, NAVIGATOR'S, ASSEMBLY (MOD. 3383) Spares for:—						—	—	—	
8722	E.A3.80.2119	EYE-BOLT , 2 BA						1	—	C	
8815	E.A3.80.2171	PEDESTAL , table						1	—	C	
		Attaching parts for E.A3.80.2171:—									
28D/9133011	A25/2C	Bolt, 2 BA						10	—	C	
28M/9403520	A27/CP	Nut, 2 BA						10	—	C	
28W/1007983	AGS.162/C	Washer						10	—	C	
28W/9419475	SP.15/C	Washer						10	—	C	
8814	E.A3.80.2091	SLIDE , table, assembly						1	—	C	
		Attaching parts for E.A3.80.2091:—									
28D/9133011	A25/2C	Bolt, 2 BA						4	—	C	
28D/1214044	AS.1242/23C	Bolt, 2 BA						3	—	C	
28M/9403520	A27/CP	Nut, 2 BA						7	—	C	
8726	E.A3.80.2097	Saddle						1	—	C	
	AS.2808/5/142	Tube, distance						3	T.35	LM	
8729	EEAS.27/16DR	Washer						3	—	C	
28W/1007983	AGS.162/C	Washer						7	—	C	

EQUIPMENT AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
8813	E.A3.80.2169	SLIDE , table, assembly						1	—	C	
		Attaching parts for E.A3.80.2169:—									
28D/9133011	A25/2C	Bolt, 2 BA						4	—	C	
28D/1214031	AS.1242/8C	Bolt, 2 BA						3	—	C	
28M/9403520	A27/CP	Nut, 2 BA						7	—	C	
8726	E.A3.80.2097	Saddle						1	—	C	
28W/1007983	AGS.162/C	Washer						7	—	C	
8811	E.A3.80.2173	TABLE , folding						1	—	B	
		Attaching parts for E.A3.80.2173:—									
8725	E.A3.80.2133	Bolt, pivot						2	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA						2	—	C	
	AS.2808/5/012	Piece, distance						2	T.35	LM	
8728	EEAS.28/36CU	Washer						2	—	C	
8812	E.A3.80.2175	TABLE , fixed						1	—	B	
		Attaching parts for E.A3.80.2175:—									
28D/9133011	A25/2C	Bolt, 2 BA						1	—	C	
28D/8337	AS.1248/1B	Bolt, 4 BA						6	—	C	
28M/9403520	A27/CP	Nut, 2 BA						1	—	C	
28W/1007983	AGS.162/C	Washer						1	—	C	
	E.B7.80.685	TRAY , mounting transmitter G-H (Mod. 1282) ...						1	—	—	
		Attaching parts for E.B7.80.685:—									
28D/1011029	A25/1E	Bolt, 1/2" BSF						16	—	C	
28M/10290	AGS.2001/E/1	Nut, 1/2" BSF						16	—	C	
652	E.A3.80.411	Washer, special						4	L.40	C	
	E.A3.80.647	WASHER , special platform support						1	—	C	
	E.A3.80.651	WASHER , special platform support						2	—	—	
8944	E.A3.80.133	WASHER , special G.H. receiver						4	—	C	
	E.A3.80.899	EXTINGUISHER, FIRE, ASSEMBLY (PRE-MOD. 2197)						—	—	—	
		spares for:—									
8625	E.A3.80.1211	BRACKET , assembly						1	—	C	
8626	E.A3.80.1213	BRACKET , assembly						1	—	C	
27N/85	†	BRACKET , fire extinguisher						1	—	B	
27N/70	†	EXTINGUISHER , fire						1	—	A	
	AS.2810/8/05	TUBE , distance						4	T.4	LM	
	E.B6.80.837	EXTINGUISHER, FIRE MOUNTING, ASSEMBLY (MOD. 2197-500)						—	—	—	
	E.B6.80.883	BRACKET , assembly						1	—	—	
	E.B6.80.889	BRACKET , assembly						1	—	—	
27N/85	†	BRACKET , fire extinguisher						1	—	B	
27N/70	†	EXTINGUISHER , fire						1	—	A	
	AS.2810/8/075	PIECE , distance						4	T.4	LM	
	E.A3.83.179	FLAP SWITCH AND UNDERCARRIAGE SWITCH LOCK STOWAGE, ASSEMBLY (MOD. 1724)						—	—	—	
		Spares for:—									
8969	E.A3.83.173	BAG , stowage, for flap, switch, locking pin ...						1	—	B	
22167	E.A3.83.295	BAG , stowage, for undercarriage switch locking pin						1	—	B	

CANBERRA B Mk 6

Page 423

EQUIPMENT AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5CW/4751	E.A3.83.175	LOCK, FLAP SWITCH, ASSEMBLY						1	—	B	
		Spares for:—									
28FP/1200982	AVDEL: A415	PIN , "pip", quick release						1	—	C	
22168	E.A3.83.299	LOCK , undercarriage switch						1	—	C	
3501	E.A3.80.1989	HANDLE, EMERGENCY HYDRAULIC PUMP, ASSEMBLY						1	—	C	
		spares for:—									
6369	ROMAC B80	GRIP						1	—	C	
or											
13048	B.79										
	E.A3.80.1833	MOUNTING, FIRST AID CONTAINER ON BOMB-AIMER'S FLOOR, ASSEMBLY						1	—	—	
		Spares for:—									
	E.A1.80.881	CONTAINER						1	—	—	
		Attaching parts for E.A1.80.881:—									
28D/1013301	AS.1248/4C	Bolt, 2 BA						2	—	C	
28M/10288	AGS.2001/C/I	Nut, 2 BA						2	—	C	
28W/1200071	SP.23/C	Washer						4	—	C	
	E.A3.80.1835	COVER						1	—	—	
		Attaching parts for E.A3.80.1835:—									
28FP/1004892	ODDIE 213	Stud						2	—	C	
28FP/1004893	ODDIE 214	Washer						2	—	C	
	E.A3.85.15	MOUNTING, DESTRUCTOR						1	—	—	
		Spares for:—									
	E.A3.85.17	BRACKET , mounting						1	—	—	
	E.A3.80.901	MOUNTING, FIRE, AXE, ASSEMBLY (PRE-MOD. 2197)						1	—	—	
		Spares for:—									
27N/1	†	AXE , fire						1	—	A	AE.1
28E/9513854	AS.2294/8	CLIP , spring						1	—	C	AE.1
6372	†	FASTENER , Newey, type, 7/7						1	—	C	AE.1
8595	E.A3.80.1829	PLATE , doubling						1	L.72	C/MR	
8596	E.A3.80.1831	STRAP , 1/2" thick						1	Leather	C/MR	
	E.A3.80.1923	PAD , packing						1	—	—	
	E.B6.80.161	PANEL, INSTRUMENT, ASSEMBLY (MOD.1255)						—	—	—	
		spares for:—									
27355	E.B6.80.621	ANGLE , assembly (Mod. 1482)						1	—	C/MR	
27354	E.B6.80.687	BRACKET , assembly (Mod. 1482)						1	—	C/MR	
27H/2952	†	MOUNTING , anti-vibration, 4lb. light duty						6	Rubber	B	
27H/2784	†	MOUNTING , anti-vibration, 8 lb. medium duty						4	Rubber	B	
27H/2786	†	MOUNTING , anti-vibration 12 lb.						4	Rubber	B	
	E.B7.80.19	PANEL UNDERCARRIAGE INSTRUMENT ASSEMBLY (MOD. 4005)						—	—	—	
		Spares for:—									
	E.A3.81.2081	BRACKET						1	—	—	
		Attaching parts for E.A3.81.2081:—									
28S/9419435	A31/B12	Screw 4 BA						4	—	C	

EQUIPMENT AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B7.80.35							1	—	—	
28D/1007971	A25/1/2B							4	—	C	
28M/10287	AGS.2001/B/1							4	—	C	
5K/2724	†							1	—	—	
5L/9951272	†							9	—	C	
5L/9951286	†							9	—	C	
6A/2924	SMITH 218FL							1	—	A	
5CX/4204	†							1	—	A	
or											
5CX/5164	†							1	—	A	
	E.A3.81.2075							1	DTD.683	—	
28S/1005622	A31/B28							1	—	C	
28W/1206041	AGS.2035/B							1	—	C	
	E.B7.75.57							1	—	—	
15200	E.B7.75.515							1	—	C	
20635	E.B7.75.55							1	—	B	
	E.B7.80.21							1	—	—	
	E.B7.80.31							1	L.72	—	
	E.A3.81.5851							1	—	—	
5CW/7748	†							1	—	C	
28S/9419435	A31/B12							4	—	C	
28W/1206041	AGS.2035/B							4	—	C	
	E.A3.81.2073							1	LFS.26	—	
28S/1200055	A33/A6							2	—	C	
5CW/898	†							1	—	B	
28M/10286	AGS.2001/A/1							4	—	C	
28S/9995324	A32/A16							4	—	C	
5CW/4506	†							1	—	A	
28M/10287	AGS.2001/B/1							2	—	C	
28S/6577	A40/B16							2	—	C	
	E.B6.80.5941							—	—	—	
6A/2944	†							1	—	A	
6A/7018	†							1	—	A	
6A/8267/1	†							1	—	A	
6A/7762	†							1	—	A	

CANBERRA B Mk. 6

Page 425

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.							No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.2841							1	—	—	
5E/4183	†										
5617	EEAS.111/4							QR	—	C	
10H/0970060	†							1	—	C	
10H/0970067	†							1	—	C	
10H/0970090	†							1	—	C	
5X/6488	CZ.23144/B							1	—	C	
5K/	EEAS.118/3/16N							1	—	—	
5K/9107065	EEAS.146/A							31	—	C	
5K/9107066	EEAS.146/A1							1	—	C	
10H/0560220	†							1	—	C	
	HELLERMANN										
5F/9454141	NY.18067							QR	—	C	
5F/9138823	NY.3255							16	—	C	
32B/1250522	†							QR	—	C	
5F/	†							QR	—	—	
6A/2089	†							1	—	A	
or											
6A/2958	†							1	—	A	
or											
6A/2197	†							1	—	A	
10L/240	†							1	—	A	
6A/5798	†							1	—	A	
6B/561	†							1	—	A	
6A/3147	†							1	—	A	
5CZ/5074	†							1	—	C	
6A/3119	†							1	—	A	
5CZ/5003	†							1	—	C	
10Q/61	†							1	—	A	
6A/2966	†							1	—	A	
or											
6A/2697	†							1	—	A	
6A/2945	†							1	—	A	
5180	E.A3.90.26/1							1	—	A	
6A/3667	SMITH 496FL							1	—	A	
6A/5622	SMITH 814FL							1	—	A	
6A/3160	SMITH 430FL							1	—	A	
5CW/4192	†							1	—	C	
6A/3384	†							1	—	A	
	E.B6.80.853							—	—	—	
	E.B7.80.473							4	DTD.683	—	
	E.B6.80.861							1	—	—	
33440	E.B6.81.5349							2	—	—	
	E.B6.80.823							1	—	—	
6A/3120	†							1	—	A	
6A/4417	†							1	—	A	
5CW/1047693	†							1	—	B	
	E.B6.80.5935							—	—	—	
6A/7041	†							1	—	A	

CANBERRA B Mk. 6

Page 426A

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.607	CABLE, ASSEMBLY, 16H, FROM STARBOARD, FIXED PANEL TO J.B.16						1	—	—	
		Consisting of:—									
5E/4183	†	CABLE, Uninyvin 20						QR	—	C	
10H/0970294	CZ.69735	CLAMP, cable						1	—	C	
10H/0970059	Z.60668	GASKET, outlet						1	—	C	
10H/0970111	Z.62237	GASKET, union						1	—	C	
10H/0970065	CZ.49182	OUTLET, straight						1	—	C	
10H/0970091	Z.62231	RING, sealing						1	—	C	
10H/9995082	Z.66473	RING, thrust						1	—	C	
5K/9107065	EEAS.146/A	SLEEVE, 3/4" long						21	—	C	
5K/9107066	EEAS.146/A1	SLEEVE, 3/4" long						3	—	C	
5K/9107067	EEAS.146/B	SLEEVE, 3/4" long						1	—	C	
5K/9107067	EEAS.146/C	SLEEVE, 3/4" long						2	—	C	
5K/9107069	EEAS.146/E	SLEEVE, 1" long						4	—	C	
10H/0560180	CZ.49126	SOCKET, Mk. 4, 12-way						1	—	C	
	HELLERMANN										
5F/9454141	NY.18307A	STRAP						QR	—	C	
	HELLERMANN										
5F/9138822	NY.3342	STUD						6	—	C	
5X/9450396	HC.490	TAG, QR						3	—	C	
32B/498	†	THREAD, waxed linen, No. 18						QR	—	C	
5L/9951272	†	FILAMENT, lamp, 28 volt, 3.5 watt						2	—	C	
5L/9951273	†	FILAMENT, lamp, 28 volt, 3.5 watt						2	—	C	
20387	E.A4.81.1687	FLAP, spring, assembly						1	—	C	
6D/2237	†	GAUGE, pressure, oxygen, Mk. 4						2	—	A	
6A/2693	†	GAUGE, pressure, Mk. 14LL						2	—	C	
6A/3942	SMITH 505FL	INDICATOR, cabin, air						1	—	C	
6A/2775	†	LABEL, hydraulic, fluorescent						2	—	C	
5CX/1553	†	LAMP, warning, Rotax, type H.2702, red						2	—	C	
	E.B6.80.691	PANEL, ASSEMBLY						1	—	—	
		Spares for:—									
	E.B6.80.693	PANEL, blank						1	—	—	
27357	E.B6.80.695	DOOR, assembly						1	—	C	
6A/3121	†	PANEL, control, Zero reader						1	—	A	
19968	E.A4.80.377	PLATE, blanking						2	L.72	—	
	E.B6.80.609	PLATE, blanking						2	L.72	—	
27356	E.B6.80.763	PLATE, blanking						1	L.72	C	
27364	E.B6.80.615	SPACER, threaded						2	—	C	
5CW/9438526	†	SWITCH, push, type B						1	—	B	
5CW/6311	†	SWITCH, fire warning						2	—	B	
5CW/5818	NSF.8812-K7	SWITCH						1	—	C	
5CW/4400123	NSF.8810-K6	SWITCH						3	—	C	
5CW/4400085	NSF.8295-B109	SWITCH						1	—	C	
5Q/4347793	†	VOLTMETER, 0-40 volt						1	—	C	
5CW/11817	†	WINDOW, for fire warning switch, type F1						1	—	C	
5CW/11818	†	WINDOW, for fire warning switch, type F2						1	—	C	

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.1005	PANEL, INSTRUMENT, STARBOARD, ASSEMBLY (MOD. 2659) Spares for this assembly are identical with those for assembly Part No. E.B6.80.689 on page 426, except for the following deletion and addition Delete:—						—	—	—	
6A/3121	†	PANEL , control, Zero reader Add:—						1	—	A	
19968	E.A4.80.377	PLATE , blanking						1	L.72	C	
12611	E.B7.80.497	SNUB , pilot's instrument panel, buffer						4	Shore 30	C	
2033	E.A3.80.1789	WASHER , special, for flexible mounting						10	L.72	C	
6918	EEAS.28/51FR	WASHER , special, for flexible mounting						10	L.72	C	
	EEAS.28/51JR	WASHER , for flexible mounting						2	—	—	
18859	EEAS.28/6GR	WASHER , special, for flexible mounting						2	—	C	
	E.B6.80.779	NAVIGATOR'S INSTRUMENT PANEL, ASSEMBLY (MOD. 2542) Spares for:—						—	—	—	
	E.B6.80.773	PLATE , mounting, assembly						1	—	—	
	E.B6.71.575	RELEASE, BOMB AIMER'S EMERGENCY OXYGEN, INSTALLATION (MOD. 4052) Spares for:—						—	—	—	
	E.B6.71.583	RELEASE, OXYGEN, EMERGENCY, ASSEMBLY ... Spares for:—						1	—	—	
34485	E.B6.71.591	CABLE , assembly						1	—	—	
	E.B6.71.581	TUBE , assembly						1	—	—	
	E.B6.71.635	RELEASE, NAVIGATOR'S EMERGENCY OXYGEN, INSTALLATION (MOD. 4052 AND 4065) Spares for:—						—	—	—	
	E.B6.71.627	PLATE , mounting Attaching parts for E.B6.71.627:—						1	—	—	
28D/9436920	A25/1C	Bolt , 2 BA						4	—	C	
28W/9419475	SP.15/C	Washer						4	—	C	
34350	E.B6.71.579	RELEASE, OXYGEN, EMERGENCY ... Spares for:—						1	—	—	
34485	E.B6.71.591	CABLE , assembly						1	—	C	
	E.B6.71.577	TUBE , assembly Attaching parts for E.B6.71.577:—						1	—	—	
28D/9436920	A25/1C	Bolt , 2 BA						2	—	C	
28W/9419475	SP.15/C	Washer						2	—	C	
	E.B6.71.593	RELEASE, PILOT'S EMERGENCY, OXYGEN, INSTALLATION (MOD. 4051) Spares for:—						—	—	—	
	E.B6.71.611	RELEASE, OXYGEN, EMERGENCY, ASSEMBLY Spares for:—						1	—	—	
34485	E.B6.71.591	CABLE, ASSEMBLY ... Spares for:—						1	—	—	
	E.B6.71.587	KNOB ... Attaching parts for E.B6.71.587:—						1	—	—	
28M/9433473	AGS.2002/C/1	Nut , 2 BA						1	—	C	
28W/9419402	SP.13/C	Washer						1	—	C	
	E.B6.71.589	PIECE , distance						1	—	—	
	E.B6.71.585	WIRE , cable						1	—	—	

CANBERRA B. Mk. 6

Page 426C

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5				
34486	E.B6.71.613					TUBE , and bracket, assembly	1	—	—	
						Attaching parts for E.B6.71.613:—				
28D/9138768	A25/1C					Bolt, 2 BA	2	—	C	
28D/9136920	A25/1C					Bolt, 2 BA	2	—	C	
28W/9419402	SP.13/C					Washer	4	—	C	
	E.B6.71.601					TOP HAT	1	—	—	
						Attaching parts for E.B6.71.601:—				
28D/9136920	A25/1C					Bolt, 2 BA	9	—	C	
28D/9130082	AS.1246/3B					Bolt, 4 BA	2	—	C	
28M/1278190	AGS.2001/C/1					Nut, 2 BA	9	—	C	
28M/1006504	A27/BT					Nut, 4 BA	2	—	C	
28W/9419402	SP.13/C					Washer	9	—	C	
	E.A3.80.1231					SEAT, MAP READER'S, ASSEMBLY	1	—	—	
						Spares for:—				
4537	E.A3.80.1289					CABLE, 'BOWDEN', ASSEMBLY	1	—	B	AE.1
						Consisting of:—				
5200	E.A3.80.1293					BRACKET	1	L.72	C	AE.1
29H/2153	P.19/52A					CABLE , Bowdenite, non fray, inner	QR	—	C	
29H/2184	B.52					CONDUIT , outer	QR	—	C	
29H/1893	PN.980					FERRULE , plain	2	—	C	
29H/2154	PN.3341A					NIPPLE , spherical	2	—	C	
29H/1901	PN.1161/1159					STOP , plain, adjusting	1	—	C	
5201	E.A3.80.1291					WASHER , tapped, radiused	1	S.11	C	
2165	EEAS.112/6					CLIP , pipe, 1/4" BSF, single	4	L.16	C	
4538	E.A3.80.1237					LOCK, BOTTOM, ASSEMBLY	1	—	B	AE.1
						Spares for:—				
	E.A3.80.1255					BOLT , special	1	S.11	—	
	E.A3.80.1249					BRACKET , bottom, half	1	L.40	—	
	E.A3.80.1250					BRACKET , bottom half	1	L.40	—	
	E.A3.80.1251					CATCH , bottom	1	DTD.124		AE.1
5066	E.A3.80.1253					SPRING	1	Spring Steel	C	AE.1
	E.A3.80.1285					WASHER , saddle	1	DTD.124		AE.1
18859	EEAS.28/6GR					WASHER	1	L.72	C	
	E.A3.80.1231A					PAD , 2" x 1" (Make from Ref. 32C/384)	1	Sorbo Rubber	LM	AE.1
	E.A3.80.1957					STOWAGE MAP READER'S SEAT, ASSEMBLY	1	—	—	
						Spares for:—				
5197	E.A3.80.1959					STRAP	1	—	C	AE.1
8521	E.A3.80.1235					SUPPORT, MAP READER'S SEAT, ASSEMBLY	1	T.45	B	
						Spares for:—				
31533	E.A3.80.1261					ROLLER, GUIDE, ASSEMBLY	1	—	C	
						Consisting of:—				
	E.A3.80.1259					BOLT	1	S.11		AE.1
	E.A3.80.1257					ROLLER	1	L.40		AE.1
	AS.2811/6/020					WASHER , distance	1	T.4	LM	
	AS.2811/6/025					WASHER , distance	1	T.4	LM	

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.867	SEAT, MAP READER'S AND FIRE AXE STOWAGE, ASSEMBLY (MOD. 2197 - S.O.O.) Spares for this assembly are identical with those for assembly Part No. E.A3.80.1231 on page 426C, except for the following deletions and additions:— Delete:—						1	—	—	
8521	E.A3.80.1235	SUPPORT, MAP READER'S SEAT, ASSEMBLY ... Add:—						1	T.45	B	
	E.B6.80.869	SUPPORT, SEAT AND FIRE AXE STOWAGE ... Spares for:—						1	—	—	
	E.B6.80.831	BRACKET, MOUNTING, ASSEMBLY ... Spares for:—						1	—	—	
28E/9513854	AS.2294/8	CLIP, spring ...						1	—	C	
	E.B6.80.815	PLATE, MOUNTING, ASSEMBLY ... Spares for:—						1	—	—	
8596	E.A3.80.1831	STRAP, 1/4" thick, leather ...						1	—	C/MR	
31533	E.A3.80.1261	ROLLER, GUIDE, ASSEMBLY ... Consisting of:—						1	—	B	
	E.A3.80.1259	BOLT ...						1	S.11	—	
	E.A3.80.1257	ROLLER ...						1	L.40	—	
	AS.2811/6/020	WASHER, distance ...						1	T.4	LM	
	E.B6.80.5983	SEATING IN PRESSURE CABIN, ASSEMBLY (MOD. 4051-4052)						—	—	—	
	E.B6.80.5957	SEATING IN PRESSURE CABIN, ASSEMBLY (MOD. 3518-2685) Spares for:—						—	—	—	
	E.B6.80.25	BRACKET, top pilot's seat rail, attachment ...						1	S.95	—	
	E.B6.80.26	BRACKET, top pilot's seat rail, attachment ... Attaching parts for E.B6.80.25 and E.B6.80.26:—						1	S.95	—	
5629	E.B6.80.27	Bolt, 2 BA ...						2	S.97	C	
28M/9436836	AGS.2001/C/2	Nut, 2 BA ...						2	—	C	
16706	E.B6.80.29	Packing, filter ...						2	L.72	C	
	E.G5.80.181	BRACKET, pipe clamp ...						1	—	—	
	E.B6.80.5977	BRACKET, LEG RESTRAINT, INSTALLATION ... Spares for:—						—	—	—	
	MARTIN BAKER A/MBEU/3666	BRACKET, floor ... Attaching parts for A/MBEU/3666:—						2	—	—	
28D/9140644	A25/9C	Bolt, 2 BA ...						4	—	C	
	E.G5.80.159	CHANNEL ...						1	—	—	
	E.G5.80.165	CHANNEL ...						1	—	—	
27L/2729	MARTIN BAKER B/MBEU/17353	LINE, leg ...						2	—	C	
27L/80	O/MBEU/1434	PIN ...						2	—	C	
	E.B6.80.5949	BRACKET, TRIP ROD, BOMB AIMER'S, INSTALLATION Spares for:—						—	—	—	
	E.B6.80.5953	ANGLE, support ...						3	—	—	
	E.B6.80.5951	BRACKET ...						1	—	—	
	E.B6.80.5955	BRACKET ...						3	—	—	

CANBERRA B Mk. 6

Page 426E

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.5947	BRACKET, TRIP ROD, NAVIGATOR'S, INSTALLATION						—	—	—	
		Spares for:—									
	E.B6.80.5953	ANGLE , support						2	—	—	
41333	E.B6.80.5951	BRACKET						1	—	MR	
41334	E.B6.80.5955	BRACKET						3	—	MR	
12K/1277	†	CARTRIDGE , No. 3, Mk. 1						1	—	C	
12K/9629465	†	CARTRIDGE , No. 13, Mk. 1 (Mod. 4448)						3 Sets	—	C	
41866	E.G5.80.177	CLAMP, ASSEMBLY						1	—	C	
		Spares for:—									
	E.G5.80.179	CLAMP , half						2	—	—	
	E.B6.80.8027	EQUIPMENT, SINGLE LEVER EJECTION ON PRESSURE BULKHEAD, INSTALLATION (MOD. 3776)						—	—	—	
		Spares for:—									
1439133	E.A3.80.6409	BOX , sealing						1	—	C	
34835	E.A3.80.6423	CABLE , secondary firing, assembly (For aircraft not embodying Martin Baker Mod. ESA47)						2	—	C	
		Attaching parts for E.A3.80.6423:—									
28P/9140979	SP.4Z/B4	Pin, shackle						2	—	C	
28P/1021104	SP.90/C3	Pin, split						2	—	C	
28W/9419402	SP.13/C	Washer						2	—	C	
	E.A3.80.6609	CABLE , assembly, secondary firing (Made from BS 2W11/5PNC) (Mod. 4948, for aircraft embodying Martin Baker Mod. ESA47)						2	—	—	
		Attaching parts for E.A3.80.6609:—									
28P/9140979	AVDEL BLC-6BA-04SF	Pin, quick release						1	—	—	
28P/1021104	SP.4/Z/B4	Pin, shackle						1	—	C	
28W/9419402	SP.90/C3	Pin, split						1	—	C	
	SP.13/C	Washer						1	—	C	
	E.B6.80.8025	CONDUIT , convoluted, bomb aimer's, assembly						1	—	—	
	E.B6.80.8023	CONDUIT , convoluted, navigator's, assembly...						1	—	—	
		Attaching parts for E.B6.80.8023:—									
28D/1008149	A25/2B	Bolt, 4 BA						8	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						8	—	C	
34849	E.A3.80.6429	Seal, $\frac{1}{8}$ " thick						1	NEOPRENE	C	
28W/9419465	SP.13/B	Washer						8	—	C	
	E.A3.80.6407	COVER , assembly						1	—	—	
34838	E.A3.80.6417	LEVER , cocking, assembly						2	—	C	
42531	E.A3.80.6413	LINK , cocking, assembly						1	—	C	
		Attaching parts for E.A3.80.6413:—									
28M/1278190	E.A3.80.6411	Bolt						3	S.95	—	
28P/1202569	AGS.2001/C/1	Nut, 2 BA						3	—	C	
28W/9419454	SP.90/E3	Pin, split						3	—	C	
28W/9419404	SP.10/C	Washer						1	—	C	
28W/9418921	SP.16/C	Washer						2	—	C	
	SP.13/E	Washer						3	—	C	
1439180	E.A3.81.6523	MECHANISM, SINGLE LEVER EJECTION BOMB AIMER'S, ASSEMBLY (MOD. 4468)						1	—	B	
		Consisting of:—									
42534	E.A3.81.6047	ARM , cam follower, assembly						1	—	C	
	E.A3.81.6061	BLOCK , guide						1	L.64	—	

CANBERRA B. Mk. 6

Page 426G

EQUIPMENT, AIRCRAFT **PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
27L/5355	MARTIN BAKER MBCJ/972							1	—	C	
27L/	MARTIN BAKER MBCJ/1582							1	—	—	
27L/5353	MARTIN BAKER MBCJ/970							1	—	C	
27L/50131	MARTIN BAKER EMBEU/1964EE							1	—	B	
28D/1008151	A25/4E							9	—	C	
28D/1011240	A25/5E							8	—	C	
28D/1008145	A25/6E							6	—	C	
28D/1018884	A25/9G							2	—	C	
28D/1213582	A25/5L							5	—	C	
28D/1013178	AS.1242/5E							1	—	C	
28M/1201610	AGS.2001/E/1							24	—	C	
28M/10291	AGS.2001/G/1							2	—	C	
28M/10293	AGS.2001/L/1							5	—	C	
3802	E.A3.10.2197							1	—	C	
4885	E.A3.80.477							2	—	C	
3897	E.A3.80.481							20	—	C	
3935	E.A3.10.571							1	—	C	
28W/9419405	SP.15/E							20	—	C	
28W/9419476	SP.15/G							2	—	C	
28W/9419478	SP.15/L							5	—	C	
28W/9419487	SP.16/E							4	—	C	
27L/50130	MARTIN BAKER EMBEU/1963EE							1	—	B	
28D/1008145	A25/6E							12	—	C	
28D/1011242	A25/7E							10	—	C	
28D/1010031	A25/8E							1	—	C	
28D/1011257	A25/7G							4	—	C	
28D/1011258	A25/8G							1	—	C	
28D/1011259	A25/10G							2	—	C	
28D/1213582	A25/5L							5	—	C	
28D/1013179	AS.1242/6E							1	—	C	
28M/1201610	AGS.2001/E/1							24	—	C	
28M/10291	AGS.2001/G/1							7	—	C	
28M/10293	AGS.2001/L/1							5	—	C	
16667	E.A3.80.439							1	—	C	
3802	E.A3.10.2197							1	—	C	
4885	E.A3.80.477							2	—	C	
4886	E.A3.80.479							5	—	C	
3897	E.A3.80.481							20	—	C	
3935	E.A3.10.571							1	—	C	
28W/9419405	SP.15/E							20	—	C	
28W/9419476	SP.15/G							2	—	C	
28W/9419478	SP.15/L							5	—	C	
28W/9419487	SP.16/E							4	—	C	
28W/9419488	SP.16/G							4	—	C	

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
27L/50129	MARTIN BAKER EMBEU/1902EE							1	—	B	
		RAIL, guide, pilot's									
		Attaching parts for EMBEU/ 1902EE:—									
28D/1011256	A25/5G							2	—	C	
28D/1006583	A25/5J							2	—	C	
28M/10291	AGS.2001/G/1							2	—	C	
28M/10292	AGS.2001/J/1							2	—	C	
28W/9419477	SP.15/J							2	—	C	
27L/1445204	MARTIN BAKER †							1	—	A	
		SEAT, EJECTION MK. 2,CA1 MK. 2, PILOT'S (MOD. 4448)									
27L/1445205	MARTIN BAKER †							2	—	A	
		SEAT, EJECTION, MK. 2,CA2, MK. 4 (MOD. 4448)									
27L/5021	MARTIN BAKER MBCJ/159							1	—	A	
		TIME RELEASE AND BREECH COMBINED UNIT									
27L/1445196	MARTIN BAKER C76-HC-MB							2	—	C	
	—							—	—	—	
		UNION, coupling (Ermeto)									
		STOWAGE PERISCOPE, ASSEMBLY (E.B6.90.943) (MOD. 2312)									
		Spares for:—									
	E.B6.80.947							1	—	—	
	E.B6.80.949							1	L.72	—	
	E.B6.80.975							1	—	—	
	E.B6.80.1019							1	S.510	—	
32547	E.B6.80.945							1	—	B	
		TUBE, ASSEMBLY									
		Spares for:—									
	E.B6.80.985							1	—	—	
	E.B6.80.979							1	L.65	—	
	E.B6.80.983							1	L.65	—	
28P/1011122	SP.29/E8							1	—	C	
32548	E.B6.80.981							1	BS.1408	C	
	E.B6.80.977							1	—	—	
	EEAS.28/42AR							QR	—	—	
	E.A1.80.967							—	—	—	
		STRAP, BACK OCCASIONAL, SEAT, ASSEMBLY ...									
		Spares for:—									
28FP/1048015	AVDEL A.405							1	H.T.S.	C	AE.1
6407	E.A3.80.2665							1	—	B	
		Spares for:—									
	AS.2394							1	—	—	
8809	E.A1.80.971							1	L.72	C	
	E.A1.80.973							1	L.72	—	AE.1
6180	E.A1.80.975							1	L.72	C	AE.1
28U/13992	AS.2385							1	—	C	AE.1
32B/498	†							QR	—	C	
8810	E.A3.80.2681							1	—	C	
5630	E.A3.83.181							1	—	A	
		SUNBLIND, PILOT'S, ASSEMBLY (PRE-MOD. 3278)									
		Spares for:—									
8798	E.A3.83.195							2	LFS.26	C	
8799	E.A3.83.197							2	LFS.26	C	
13152	E.A3.83.279							1	—	C	
	†							QR	DTD.67A	—	
	E.A3.83.217							1	DTD.793	—	
		CORD, silk (Make from Ref. 32A/155)									
		FABRIC, nylon, white (Make from Ref. 32B/1019)									

CANBERRA B. Mk. 6

Page 426j

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description	No off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.A3.83.219	FABRIC , nylon, green (Make from Ref. 32B/1020)	1	DTD.793	—	
8793	E.A3.83.185	FRAME , inner	1	L.65	—	
8794	E.A3.83.187	FRAME , outer, starboard	1	—	B	
8795	E.A3.83.189	FRAME , OUTER, PORT, ASSEMBLY	1	—	B	
		Spares for:—				
21222	E.A3.83.287	FRAME , outer, flexible	1	Nevellon	B	
5631	E.A3.83.205	SPRING , compression	1	DTD.215	C	
8803	E.A3.83.209	STIFFENER	1	Nevellon	C	
8804	E.A3.83.211	STIFFENER	2	Nevellon	C	
8805	E.A3.83.213	STIFFENER	2	Nevellon	C	
8806	E.A3.83.215	STIFFENER	2	Nevellon	C	
8800	E.A3.83.201	TUBE , spring housing	1	—	C	
8801	E.A3.83.203	TUBE , spring housing	1	—	C	
33335	E.B6.83.363	SUNBLIND, PILOT'S, ASSEMBLY (MOD. 3278) ...	1	—	B	
		Spares for this assembly are identical with those for assembly Part No. E.A3.83.181 on page 426H, except for the following deletion and addition:—				
		Delete:—				
8793	E.A3.83.185	FRAME , inner	1	—	B	
		Add:—				
	E.B6.83.365	FRAME , inner	1	—	—	
41357	E.G5.83.21	SUNBLIND, PILOT'S, ASSEMBLY (MOD. 4051) ...	1	—	B	
		Spares for:—				
	E.G5.83.51	BRACKET , stop, port	1	—	C	
	E.G5.83.53	BRACKET , stop, starboard	1	—	C	
32A/155	†	CORD , silk (Alternative)	QR	DTD.67A	C	
32A/141	†	CORD , nylon (Alternative)	QR	DTD.481F	C	
	E.G5.83.61	FABRIC , nylon, green (Make from Ref. 32B/1020)	1	DTD.793	LM	
	E.G5.83.59	FABRIC , nylon, white (Make from Ref. 32B/1019)	1	DTD.793	LM	
	E.G5.83.55	FRAME , flexible	1	Glass cloth	—	
	E.G5.83.27	FRAME , INNER, ASSEMBLY	1	—	C	
		Spares for:—				
	E.G5.83.31	FRAME , wire	1	—	—	
	E.G5.83.29	MEMBER , inner frame	1	—	—	
	E.G5.83.33	SOCKET , inner frame, port	1	—	—	
	E.G5.83.35	SOCKET , inner frame, starboard	1	—	—	
34436	E.G5.83.63	HANDLE , control	1	—	C	
		Attaching parts for E.G5.83.63:—				
28D/1007468	AS.1242/3B	Bolt, 4 BA	4	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	4	—	C	
28W/9419465	SP.13/B	Washer	4	—	C	
	E.G5.83.45	LEVER , assembly	1	—	—	
	E.G5.83.47	PLATE , stop, assembly	1	—	—	
	E.G5.83.41	SHAFT , inner	1	—	—	
	E.G5.83.37	SOCKET , outer frame, port	1	—	—	
	E.G5.83.39	SOCKET , outer, frame, starboard	1	—	—	
	E.A3.83.205	SPRING	1	DTD.215	—	
	E.G5.83.23	STAY , outer, port	1	—	—	
	E.G5.83.25	STAY , outer, starboard	1	—	—	
	E.G5.83.57	STIFFENER	1	—	—	
8804	E.A3.83.211	STIFFENER	2	—	C	
8805	E.A3.83.213	STIFFENER	2	—	C	

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
8806	E.A3.83.215	STIFFENER						2	—	C	
	E.G5.83.43	TUBE, bearing						1	—	—	
8800	E.A3.83.201	TUBE, spring housing						1	—	C	
8801	E.A3.83.203	TUBE, spring housing						1	—	C	
		Attaching parts for E.A3.83.201 and E.A3.83.203:—									
28N/1045681	AGS.899/1	Collar						1	—	C	
28P/814	SP.4Y/A4	Pin, shackle						1	—	C	
28P/9710567	SP.90/C4	Pin, split						1	—	C	
		Attaching parts for E.G5.83.21:—									
8798	E.A3.83.195	Bearing, support, bottom						2	—	C	
8799	E.A3.83.197	Bearing, support, bottom						2	—	C	
28D/1214035	AS.1242/13C	Bolt, 2 BA						4	—	C	
28M/9433473	AGS.2002/C/1	Nut, 2 BA						4	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
	E.B6.80.787	SWITCH, MASTER, U/C, ASSEMBLY (MOD. 2364)						1	—	—	
		Spares for:—									
37435	E.A9.80.1259	BRACKET, switch, mounting						1	—	C	
5CW/5765	†	SWITCH, GUARD						1	—	B	
5CW/6435	†	SWITCH, D.P. change over						1	—	B	
	E.B6.85.1	WINDOW, CARTRIDGE STOWAGE (MOD. 1435)						—	—	—	
		Spares for:—									
37555	E.B6.85.9	BRACKET, end, L.H.						1	L.72	C/MR	
37556	E.B6.85.10	BRACKET, end, R.H.						1	L.72	C/MR	
26478	E.B6.85.3	STOWING, cartridge, assembly						1	—	B/MR	
	E.B6.80.631	ZERO READER, ASSEMBLY (MOD. 1447)						—	—	—	
		Spares for:—									
	E.B6.80.619	COMPUTER, FLIGHT, FITTINGS						1	—	—	
		Spares for:—									
	E.B6.80.647	ANGLE, forward (Made from R.S.130/42)						1	L.72	C/MR	
	E.B6.80.649	DIAPHRAGM, L.H.						1	L.72	C/MR	
26436	E.B6.80.650	DIAPHRAGM, R.H.						1	L.72	C/MR	
	E.B6.80.761	PIECE, packing						2	L.72	—	
	E.B6.80.653	PLATE, mounting, assembly						1	—	C/MR	
32534	E.B6.80.633	MOUNTING, COMPUTER FLIGHT, ASSEMBLY						1	—	A	
		Spares for:—									
	MARCONI										
	R.I.D.1004A	DEVICE, lock						2	—	—	
	E.B6.80.635	MEMBER, horizontal (Made from Marconi Part R.I.D.101-1, Ref. 9)						1	—	—	
	MARCONI										
	R.I.D.1012-1-Ref. 5	MEMBER, side, R.H.						1	—	—	
	MARCONI										
	R.I.D.1012-2-Ref. 15	MEMBER, side, L.H.						1	—	—	
	SPERRY										
	SK.9054-8	MOUNTING, shock absorber						4	—	—	
	AS.2810/4/02	TUBE, distance						4	—	—	
	MARCONI										
	R.I.D.1012-3	WASHER, domed						8	—	—	
	E.B6.80.637	MOUNTING, BOX, JUNCTION FLIGHT, INSTRUMENTS						1	—	—	
		Spares for:—									
26413	E.B6.80.639	ANGLE, mounting, assembly						1	—	C	
26412	E.B6.80.643	PLATE, mounting, assembly						1	—	C	

CANBERRA B. Mk. 6

Page 427

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M	
1 2 3 4 5 6						
SUMMARY OF STOCK ITEMS USED ON PRESSURE CABIN EQUIPMENT						
28D/1008147	A25/1A	Bolt, 6 BA, hex. head, 0"45 long ...	...		C	
28D/1007971	A25/1B	Bolt, 4 BA, hex. head, 0"25 long ...	...		C	
28D/1010658	A25/1B	Bolt, 4 BA, hex. head, 0"5 long ...	...		C	
28D/9140638	A25/4B	Bolt, 4 BA, hex. head, 0"8 long ...	...		C	
28D/1011011	A25/8B	Bolt, 4 BA, hex. head, 1"2 long ...	...		C	
28D/9140639	A25/11B	Bolt, 4 BA, hex. head, 1"5 long ...	...		C	
28D/9436920	A25/1C	Bolt, 2 BA, hex. head, 0"55 long ...	...		C	
28D/9133011	A25/2C	Bolt, 2 BA, hex. head, 0"65 long ...	...		C	
28D/9133012	A25/3C	Bolt, 2 BA, hex. head, 0"75 long ...	...		C	
28D/1200119	A25/4C	Bolt, 2 BA, hex. head, 0"85 long ...	...		C	
28D/1011019	A25/8C	Bolt, 2 BA, hex. head, 1"25 long ...	...		C	
28D/9140645	A25/10C	Bolt, 2 BA, hex. head, 1"5 long ...	...		C	
28D/1011029	A25/1E	Bolt, 1" BSF, hex. head, 0"6 long ...	...		C	
28D/1008151	A25/4E	Bolt, 1" BSF, hex. head, 0"9 long ...	...		C	
28D/1011240	A25/5E	Bolt, 1" BSF, hex. head, 1"0 long ...	...		C	
28D/1008145	A25/6E	Bolt, 1" BSF, hex. head, 1"1 long ...	...		C	
28D/1011242	A25/7E	Bolt, 1" BSF, hex. head, 1"2 long ...	...		C	
28D/1010031	A25/8E	Bolt, 1" BSF, hex. head, 1"3 long ...	...		C	
28D/1011244	A25/9E	Bolt, 1" BSF, hex. head, 1"4 long ...	...		C	
28D/1011245	A25/10E	Bolt, 1" BSF, hex. head, 1"5 long ...	...		C	
28D/1011246	A25/11E	Bolt, 1" BSF, hex. head, 1"6 long ...	...		C	
28D/7002418	A25/14E	Bolt, 1" BSF, hex. head, 1"9 long ...	...		C	
28D/9706306	A25/17E	Bolt, 1" BSF, hex. head, 2"2 long ...	...		C	
28D/1011256	A25/5G	Bolt, 5/16" BSF, hex. head, 1"05 long ...	...		C	
28D/1011257	A25/7G	Bolt, 5/16" BSF, hex. head, 1"25 long ...	...		C	
28D/1011258	A25/8G	Bolt, 5/16" BSF, hex. head, 1"35 long ...	...		C	
28D/1018884	A25/9G	Bolt, 5/16" BSF, hex. head, 1"45 long ...	...		C	
28D/1011259	A25/10G	Bolt, 5/16" BSF, hex. head, 1"55 long ...	...		C	
28D/1006583	A25/5J	Bolt, 5/16" BSF, hex. head, 1"15 long ...	...		C	
28D/1213582	A25/5L	Bolt, 5/16" BSF, hex. head, 1"2 long ...	...		C	
28D/1212964	A61/1B	Bolt, 4 BA, hex. head, 0"5 long ...	...		C	
28D/1212965	A61/2B	Bolt, 4 BA, hex. head, 0"6 long ...	...		C	
28D/1213235	A61/14E	Bolt, 1" BSF, hex. head, 1"9 long ...	...		C	
28D/1007975	AS.1242/1C	Bolt, 2 BA, c'sk. head, 0"5 long ...	...		C	
28D/9709461	AS.1242/3C	Bolt, 2 BA, c'sk. head, 0"7 long ...	...		C	
28D/1214036	AS.1242/14C	Bolt, 2 BA, c'sk. head, 1"8 long ...	...		C	
28D/1007979	AS.1246/1B	Bolt, 4 BA, hex. head, 0"5 long ...	...		C	
28D/9140202	AS.1246/1C	Bolt, 2 BA, round head, 0"5 long ...	...		C	
28D/9137409	AS.1246/2C	Bolt, 2 BA, round head, 0"6 long ...	...		C	
28D/9140203	AS.1246/3C	Bolt, 2 BA, round head, 0"7 long ...	...		C	
28D/1215327	AS.1246/1E	Bolt, 1" BSF, round head, 0"55 long ...	...		C	
28D/1213450	AS.1247/1B	Bolt, 4 BA, round head, 0"4 long ...	...		C	
28D/1007982	AS.1248/1C	Bolt, 2 BA, mushroom head, 0"5 long ...	...		C	
28D/1013301	AS.1248/4C	Bolt, 2 BA, mushroom head, 0"8 long ...	...		C	
28D/1215159	AS.4565/1C	Bolt, 2 BA, hex. head, 0"5 long ...	...		C	
28D/1213484	AS.4565/9E	Bolt, 1" BSF, hex. head, 1"4 long ...	...		C	
28D/1213513	AS.4565/31E	Bolt, 1" BSF, hex. head, 1"5 long ...	...		C	
28N/1045681	AGS.899/1	Collar, 1" BSF, hex. head, 1"5 long ...	...		C	
28M/1200096	A27/AT	Nut, 6 BA, thin ...	...		C	
28M/9403519	A27/BP	Nut, 4 BA, plain ...	...		C	
28M/1006504	A27/BT	Nut, 4 BA, thin ...	...		C	
28M/5808573	A27/CS	Nut, 2 BA, slotted ...	...		C	

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
28M/1011475	A27/EP	Nut,	1"	BSF,	plain	...	...	...	...	C	
28M/10286	AGS.2001/A/1	Nut,	stiff,	6:BA	...	...	...	...	...	C	
28M/10279	AGS.2001/A/3	Nut,	stiff,	6:BA	...	...	...	...	...	C	
28M/1278189	AGS.2001/B/1	Nut,	stiff,	4:BA	...	...	...	...	...	C	
28M/10274	AGS.2001/B/4	Nut,	stiff,	4:BA	...	...	...	...	...	C	
28M/1278190	AGS.2001/C/1	Nut,	stiff,	2:BA	...	...	...	...	...	C	
28M/9436836	AGS.2001/C/2	Nut,	stiff,	2:BA	...	...	...	...	...	C	
28M/10281	AGS.2001/C/3	Nut,	stiff,	2:BA	...	...	...	...	...	C	
28M/10275	AGS.2001/C/4	Nut,	stiff,	2:BA	...	...	...	...	...	C	
28M/1201610	AGS.2001/E/1	Nut,	stiff,	1"	BSF	...	...	...	...	C	
28M/10282	AGS.2001/E/3	Nut,	stiff,	1"	BSF	...	...	...	...	C	
28M/10291	AGS.2001/G/1	Nut,	stiff,	...	...	...	...	...	...	C	
28M/10292	AGS.2001/J/1	Nut,	stiff,	3"	BSF	...	...	...	...	C	
28M/10293	AGS.2001/L/1	Nut,	stiff,	7/8"	BSF	...	...	...	...	C	
28M/10318	AGS.2002/B/3	Nut,	stiff,	4:BA	...	...	...	...	...	C	
28M/11957	AGS.2007/C/1	Nut,	stiff,	2:BA	...	...	...	...	...	C	
28P/1207920	SP.90/B5	Pin,	split,	3/4"	dia. x 3/4" long	...	...	...	...	C	
28P/9710567	SP.90/C4	Pin,	split,	1/8"	dia. x 5/8" long	...	...	...	...	C	
28P/9527619	SP.90/C7	Pin,	split,	1/8"	dia. x 1" long	...	...	...	...	C	
28P/814	SP.4Y/A4	Pin,	shackle	...	...	...	...	...	...	C	
28P/9446312	SP.4Y/B3	Pin,	shackle	...	...	...	...	...	...	C	
28S/9419435	A31/B12	Screw,	4:BA,	cheese head,	1/8" long	...	...	...	...	C	
28S/1005622	A31/B28	Screw,	4:BA,	cheese head,	7/8" long	...	...	...	...	C	
28S/1006948	A32/A12	Screw,	6:BA,	round head,	3/8" long	...	...	...	...	C	
28S/9995324	A32/A16	Screw,	6:BA,	round head,	1/2" long	...	...	...	...	C	
28S/9992525	A32/B12	Screw,	4:BA,	round head,	3/8" long	...	...	...	...	C	
28S/1007817	A32/B24	Screw,	4:BA,	round head,	3/4" long	...	...	...	...	C	
28S/1202768	A33/C16	Screw,	2:BA,	c'sk. head,	1/2" long	...	...	...	...	C	
28S/9440345	A40/B8	Screw,	4:BA,	round head,	1/4" long	...	...	...	...	C	
28S/1212706	A40/B12	Screw,	4:BA	...	...	...	...	...	...	C	
28S/121708	A40/B16	Screw,	4:BA,	round head,	1/2" long	...	...	...	...	C	
28S/1212709	A40/B20	Screw,	4:BA,	round head,	5/8" long	...	...	...	...	C	
28S/1212721	A40/C32	Screw	...	...	...	...	...	...	...	C	
28S/9148119	A43/A10	Screw,	6:BA,	cheese head,	1/8" long	...	...	...	...	C	
28S/9148118	A43/B10	Screw,	4:BA,	cheese head,	1/8" long	...	...	...	...	C	
28S/1012356	A43/B12	Screw,	4:BA,	cheese head,	3/8" long	...	...	...	...	C	
28S/9134016	A43/B14	Screw,	4:BA,	cheese head,	1/8" long	...	...	...	...	C	
28S/9144116	A43/B20	Screw,	4:BA,	cheese head,	1/2" long	...	...	...	...	C	
28S/9130752	A43/B24	Screw,	4:BA,	cheese head,	3/4" long	...	...	...	...	C	
28S/9992520	A43/C20	Screw,	4:BA,	cheese head,	1" long	...	...	...	...	C	
28S/9134791	A44/B6	Screw,	4:BA,	round head,	1/8" long	...	...	...	...	C	
28S/9447551	A44/B10	Screw,	4:BA,	round head,	1/8" long	...	...	...	...	C	
28S/9145185	A44/B12	Screw,	4:BA,	round head,	1" long	...	...	...	...	C	
28S/1013430	A44/B20	Screw,	4:BA,	round head,	1" long	...	...	...	...	C	
28S/1017078	A44/B24	Screw,	4:BA,	round head,	3/4" long	...	...	...	...	C	
28S/1214166	A44/B28	Screw,	4:BA,	round head,	7/8" long	...	...	...	...	C	
28S/1214172	A44/C20	Screw,	2:BA,	round head,	1" long	...	...	...	...	C	
28S/1214174	A44/C28	Screw,	2:BA,	round head,	7/8" long	...	...	...	...	C	
28S/1214177	A44/C20	Screw,	2:BA,	round head,	1 1/4" long	...	...	...	...	C	
28W/9419465	SP.13/B	Washer,	4:BA,	plain	...	...	...	...	...	C	
28W/9419402	SP.13/C	Washer	...	...	...	...	...	...	...	C	
28W/9418921	SP.13/E	Washer,	1"	BSF, plain	...	...	...	...	...	C	
28W/9419466	SP.13/J	Washer,	3/8"	BSF, plain	...	...	...	...	...	C	

CANBERRA B Mk. 6

Page 429

EQUIPMENT, AIRCRAFT PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
28W/9143227	SP.14/B	Washer,	4	BA,	plain	...	...	...		C	
28W/9419473	SP.15/A	Washer,	6	BA,	plain	...	...	...		C	
28W/9419474	SP.15/B	Washer,	4	BA,	plain	...	...	...		C	
28W/9419475	SP.15/C	Washer,	2	BA,	plain	...	...	...		C	
28W/9419405	SP.15/E	Washer,	1	"	BSF, plain	...	...	...		C	
28W/9419476	SP.15/G	Washer,	1	"	BSF, plain	...	...	...		C	
28W/9419477	SP.15/J	Washer,	1	"	BSF, plain	...	...	...		C	
28W/9419478	SP.15/L	Washer,	1	"	BSF, plain	...	...	...		C	
28W/9419404	SP.16/C	Washer,	2	BA,	plain	...	...	...		C	
28W/9419487	SP.16/E	Washer,	1	"	BSF, plain	...	...	...		C	
28W/9419488	SP.16/G	Washer,	1	"	BSF, plain	...	...	...		C	
28W/9416642	SP.47/B	Washer,	4	BA,	spring	...	...	...		C	
28W/9416632	SP.47/C	Washer,	2	BA,	spring	...	...	...		C	
28W/3537	AGS.1583/D	Washer,	6	BA	...	...	...	...		C	
28W/9419448	AGS.2035/B	Washer	...	...	...	...	...	...		C	

CANBERRA B Mk. 6

Page 431

EQUIPMENT, AIRCRAFT EQUIPMENT FOR B.S.

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.B6.80.235	EQUIPMENT FOR B.S. (MOD.1043) (S.O.O.) ...	—	—	—	
	E.A3.80.2919	Spares for:— BRACKET, ATTACHMENT, NAVIGATOR'S TABLE TO PILOT'S SEAT RAIL (MOD. 3396)	—	—	—	
	E.A3.80.2925	Spares for:—				
34174	E.A3.80.2921	Angle 2	2	L.72	—	
		Bracket, assembly 1	1	—	C	
		Attaching parts for E.A3.80.2921:—				
28D/9436920	A25/1C	Bolt, 2 BA 4	4	—	C	
28D/9133012	A25/3C	Bolt, 2 BA 4	4	—	C	
28W/9419454	SP.10/C	Washer 4	4	—	C	
28W/9419402	SP.13/C	Washer 4	4	—	C	
	E.B6.75.657	CABIN PRESSURE SYSTEM, FRONT FUSELAGE, ASSEMBLY	—	—	—	
		Spares for:—				
12209	E.B6.75.679	Connection, for flexible pipe at navigator's table	1	—	C	
	E.B6.75.665	DIFFUSER, NAVIGATOR'S ASSEMBLY ...	1	—	—	
		Spares for:—				
	E.B6.75.667	Bracket, diffuser mounting 1	1	L.72	—	
1349	E.A3.75.89	Clip, diffuser retaining 1	1	L.72	C	
6980	E.B7.75.23	Diffuser 1	1	—	C	
12210	E.B6.75.659	Pipe, flexible, from main branch pipe at frame 2 to pipe joint at navigator's table	1	Bell's asbestos	C	
12211	E.B6.75.661	Pipe, flexible, from main branch pipe to navigator's diffuser	1	Bell's asbestos	C	
12212	E.B6.75.677	Pipe, flexible, from pipe joint at navigator's table to navigator's louvre	1	Bell's asbestos	C	
	E.A3.81.651/1	CABLE, ASSEMBLY, N.97, FROM CONNECTION AT PRESSURE BULKHEAD TO J.B.266GH (RED ENTRY), GROUP	1	—	—	
		Consisting of:—				
5E/4203	†	Cable, Uninyvinmet 12 QR	QR	—	C	
10H/0970076	Z.49047	Ferrule, inner 1	1	—	C	
10H/0970075	Z.49048	Ferrule, outer 1	1	—	C	
10H/0970058	Z.54184	Gasket, outlet 1	1	—	C	
10H/0970061	CZ.49178	Outlet, straight 1	1	—	C	
10H/0970087	Z.49049	Ring, sealing 1	1	—	C	
5K/	†	Sleeve, 3/4" long 4	4	—	—	
5K/	†	Sleeve, 1" long 2	2	—	—	
10H/419	†	Socket, assembly, type WV.165, 2-way 1	1	—	C	
10H/0560090	CZ.49014	Socket, assembly, 2-way, Mk. 4 1	1	—	C	
	E.B6.81.777	CABLE, ASSEMBLY, N.98, FROM CONNECTION AT PRESSURE BULKHEAD TO J.B.266GH (BLACK ENTRY), GROUP	1	—	—	
		Consisting of:—				
5E/4203	†	Cable, Uninyvinmet 12 QR	QR	—	C	
10H/0970076	Z.49047	Ferrule, inner 1	1	—	C	
10H/0970075	Z.49048	Ferrule, outer 1	1	—	C	
10H/0970058	Z.60667	Gasket, outlet 1	1	—	C	
10H/0970061	CZ.49178	Outlet, straight 1	1	—	C	
10H/0970087	Z.49049	Ring, sealing 1	1	—	C	
5K/9107067	EEAS.146/C	Sleeve, 3/4" long 4	4	—	C	
5K/9107068	EEAS.146/D1	Sleeve, 1" long 2	2	—	C	
10H/419	†	Socket, assembly, type WV.165, 2-way 1	1	—	C	
10H/0560591	CZ.49014/1	Socket, free, Mk. 4, 2-way 1	1	—	C	

EQUIPMENT, AIRCRAFT EQUIPMENT FOR B.S.

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.81.2599	CABLE, ASSEMBLY, F.38A, FROM PLUG BREAK TO ELECTRONIC REGULATOR, GROUP (MOD. 2573)						1	—	—	
		Consisting of:—									
5E/4199	†	Cable	Uninyvinmetsheath	20	...	...	...	QR	—	C	
5E/4203	†	Cable	Uninyvinmet	12	...	...	...	QR	—	C	
10H/0970296	Z.69738	Clamp	cable	...	...	...	...	2	—	C	
5X/9400051	AS.2672	Ferrule	...	...	...	...	...	8	—	C	
5X/9400055	AS.2674	Ferrule	...	...	...	...	...	8	—	C	
30B/1145	†	Gauze	fine wire (cadmium plated)	...	...	...	...	QR	—	C	
10H/	Z.50743	Outlet	90°	...	...	...	...	1	—	—	
10H/	Z.50744	Outlet	straight	...	...	...	...	1	—	—	
10H/0970059	Z.60668	Outlet	gasket	...	...	...	...	2	—	C	
10H/0560760	CZ.56735	Plug	fixed coupler	...	...	...	...	1	—	C	
5K/9107065	EEAS.146/A	Sleeve	3/4" long	...	...	...	...	QR	—	C	
5K/9107066	EEAS.146/A1	Sleeve	1" long	...	...	...	...	8	—	C	
5K/9107066	EEAS.146/B	Sleeve	1" long	...	...	...	...	8	—	C	
5K/9107070	EEAS.146/J	Sleeve	1" long	...	...	...	...	4	—	C	
10H/0560180	CZ.49126	Socket	...	...	...	...	...	1	—	C	
	E.B6.81.2601	CABLE, ASSEMBLY, F.37B, FROM PLUG BREAK TO ELECTRONIC REGULATOR, GROUP (MOD. 2573)						1	—	—	
		Consisting of:—									
5E/4199	†	Cable	Uninyvinmetsheath	20	...	...	...	QR	—	C	
5K/27	Z.23241/4	Ferrule	cut	...	...	...	...	2	—	C	
10H/0970108	Z.62235	Gasket	union	...	...	...	...	2	—	C	
10H/0970058	Z.60667	Outlet	gasket	...	...	...	...	2	—	C	
10H/0970061	CZ.49178	Outlet	assembly, straight	...	...	...	...	1	—	C	
10H/0970068	CZ.49179	Outlet	assembly, 90°	...	...	...	...	1	—	C	
10H/0560720	CZ.56732	Plug	fixed coupler	...	...	...	...	1	—	C	
5K/9107066	EEAS.146/A1	Sleeve	3/4" long	...	...	...	...	4	—	C	
5K/9107068	EEAS.146/D	Sleeve	1" long	...	...	...	...	4	—	C	
10H/0560110	CZ.49016	Socket	...	...	...	...	...	1	—	C	
5E/9102378	†	Wire	tinned copper, 26 SWG	...	...	...	...	QR	—	C	
	E.B6.81.2603	CABLE, ASSEMBLY, F.40A, FROM PLUG BREAK TO ELECTRONIC REGULATOR, GROUP (MOD. 2573)						1	—	—	
		Consisting of:—									
5E/9100010	†	Cable	Trivenmet small, 2.5	...	...	...	...	QR	—	C	
10H/20406	Z.54443	Ferrule	inner	...	...	...	...	2	—	C	
10H/20407	Z.54444	Ferrule	outer	...	...	...	...	2	—	C	
10H/0970058	Z.60667	Gasket	outlet	...	...	...	...	2	—	C	
10H/0970062	CZ.49180	Outlet	assembly (straight)	...	...	...	...	1	—	C	
10H/0970069	CZ.49181	Outlet	90°	...	...	...	...	1	—	C	
10H/0560710	CZ.56731	Plug	fixed coupler	...	...	...	...	1	—	B	
10H/0970088	Z.62229	Ring	sealing	...	...	...	...	2	—	C	
5K/9107065	EEAS.146/A	Sleeve	3/4" long	...	...	...	...	6	—	C	
5K/9107068	EEAS.146/D1	Sleeve	1" long	...	...	...	...	4	—	C	
10H/0560100	CZ.49015	Socket	...	...	...	...	...	1	—	C	

CANBERRA B. Mk. 6

Page 433

EQUIPMENT, AIRCRAFT EQUIPMENT FOR B.S.

Ref. No.	Part No.	Description	No. off	Matl. Spec	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.B6.71.79	OXYGEN SYSTEM, ASSEMBLY	—	—	—	
		Spares for:—				
5780	E.B7.71.49	Bracket, reducing valve mounting	1	—	C	
	E.B7.71.169	Clip, half, pipe	2	DTD.124	—	
5551	EEAS.143/14	Clip, pipe	4	L.72	C	
	E.B7.71.55	Hose, rubber, $\frac{7}{8}$ " i/d x 3'0" long (make from 32C/445)	1	DTD.625	LM	
12213	E.B6.71.81	Pipe, assembly, L.P., from navigator's reducing valve, to regulator	1	—	C	
12214	E.B6.71.83	Pipe, assembly, H.P., from navigator's reducing valve to tee piece at cross tube	1	—	C	
12215	E.B6.71.85	Pipe, assembly, H.P., from stop valve tee piece to reducing valve connection, port	1	—	C	
12216	E.B6.71.87	Pipe, assembly, H.P., from reducing valve tee to 3-way connector at frame 5	1	—	C	
12217	E.B6.71.93	Pipe, L.P., from hose coupling at navigator's table to hose coupling at frame 5	1	—	C	
12218	E.B6.71.95	Pipe, L.P. bend, Navigator's supply, from hose coupling at navigator's table to coupling between frames 6 and 7	1	—	C	
12219	E.B6.71.121	Pipe, assembly, L.P., from hose coupling at frame 5 to navigator's oxygen regulator	1	—	C	
	E.B6.73.247	PIPES, HYDRAULIC, FROM RESERVOIR TO FRAME 12 AND PRESSURE BULKHEAD, ASSEMBLY	—	—	—	
		Spares for:—				
12220	E.B6.73.225	Pipe, assembly, from return line tee forward of frame 12 to coupling at frame 12	1	—	C	
12221	E.B6.73.227	Pipe, assembly, between reservoir running coupling and return line tee forward of frame 12	1	—	C	
12222	E.B6.73.229	Pipe, assembly, from running coupling at frame 12 to running coupling forward of frame 12 engine driven pump suction line	1	—	C	
12223	E.B6.73.231	Pipe, assembly, from thermal relief valve tee at wheel well wall to hydraulic reservoir tee forward of frame 12	1	—	C	

CANBERRA B Mk. 6

Page 435

EQUIPMENT, AIRCRAFT L.L.A.B.S. REMOVABLE EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.81.1515	EQUIPMENT, L.L.A.B.S. REMOVABLE FITTINGS, GROUP (MOD. 2198) (S.O.O.)						—	—	—	
		Spares for:—									
37709	E.B6.81.1439	BOX, CONTROL, ASSEMBLY						1	—	B	
		Spares for:—									
	E.B6.81.1435	Box, engraved						1	—	—	
5E/4183	†	Cable, Uninyvin 20						QR	—	C	
5E/4185	†	Cable, Uninyvin 16						QR	—	C	
	E.B6.81.1437	Cover, assembly						1	—	—	
	E.A9.81.3923	Cover, plate						1	—	—	
5D/1541	†	Indicator, magnetic						4	—	B	
	CANNON										
5X/8351	AN.3102A/14S/2P	Plug						1	—	C	
	E.A9.81.3919	Seal, rubber						1	—	—	
5CW/6436	D.504	Switch, D.P.						1	—	B	
5CW/2910	†	Switch, rotary						1	—	B	
	E.A9.81.3917	Tag						1	—	—	
	E.A9.81.3921	Window, perspex						1	—	—	
	E.B6.81.1467	CRATE, MOUNTING, ASSEMBLY						—	—	—	
		Spares for:—									
	E.B6.81.1407	BOX, JUNCTION, ASSEMBLY						1	—	—	
		Spares for:—									
	CANNON										
5X/8256	2209/10	Cap, dust						1	—	—	
	CANNON										
5X/8520	2209/12	Cap, dust						1	—	—	
	E.B6.81.1409	LID, ASSEMBLY						1	—	—	
		Spares for:—									
33H/56	†	Cement, Bostik						QR	—	C	
32C/614	†	Rubber, synthetic, 0"14 dia.						QR	DTD.552	C	
32368	E.A9.81.4357	Screw						6	—	C	
1066	EEAS.28/2CU	Washer						12	DTD.124	C	
1108	EEAS.42	Washer, leather						6	—	C	
	E.B6.81.1377	CABLE, ASSEMBLY, FA.63, FROM L.A.B.S. J.B. "A" TO PROTECTIVE RELAY UNIT, GROUP						1	—	—	
		Consisting of:—									
5E/4183	†	Cable, Uninyvin 20						QR	—	C	
5E/2034	†	Conduit, flexible						QR	—	C	
26DK/6014	EEAS.111/2	Ferrule						1	—	C	
10H/0970058	Z.60667	Gasket, outlet						1	—	C	
5X/2784	No. 3	Grommet, tension						1	—	C	
10H/0970062	CZ.49180	Outlet, straight						1	—	C	
5X/1529	†	Ring, clamp						1	—	C	
10H/0970088	Z.62229	Ring, sealing						1	—	C	
5K/9107065	EEAS.146/A	Sleeve						2	—	C	
5K/9107068	EEAS.146/D	Sleeve						4	—	C	
10H/0560120	CZ.49017	Socket, 6-way						1	—	C	
5X/9400061	Z.19924	Tag						1	—	C	
5X/9400062	Z.19974	Thimble						1	—	C	

EQUIPMENT, AIRCRAFT **LL.A.B.S. REMOVABLE EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.81.1379	CABLE, ASSEMBLY, FA.65, FROM L.A.B.S. J.B. TO FUZE CHART UNIT, GROUP						1	—	—	
		Consisting of:—									
5E/4183	†	Cable, Uninyvin 20						QR	—	C	
5F/2037	†	Conduit, flexible						QR	—	C	
	E.B6.81.1495	Ferrule						1	—	—	
10H/0970060	Z.60669	Gasket, outlet						1	—	C	
5X/2789	2026	Grommet, tension						1	—	C	
10H/0970093	CZ.50784	Outlet, angle						1	—	C	
10H/0560390	CZ.53159	Plug, 18-way						1	—	C	
5X/6489	CZ.23144/C	Ring, clamp						1	—	C	
10H/0970092	CZ.62232	Ring, sealing						1	—	C	
5K/9107065	EEAS.146/A	Sleeve						36	—	C	
5K/9107070	EEAS.146/K	Sleeve						4	—	C	
5X/9430396	HC.490	Tag						18	—	C	
	E.B6.81.1381	CABLE, ASSEMBLY, FA.62, FROM L.A.B.S. J.B. TO PROTECTIVE RELAY UNIT, GROUP						1	—	—	
		Consisting of:—									
5E/4183	†	Cable, Uninyvin 20						QR	—	C	
5F/9143294	†	Conduit, flexible						QR	—	C	
26DK/6014	EEAS.111/2	Ferrule						1	—	C	
10H/0970058	Z.60667	Gasket, outlet						1	—	C	
5X/2786	No. 3	Grommet, tension						1	—	C	
10H/0970062	CZ.49180	Outlet, straight						1	—	C	
5X/1529	CZ.69733	Ring, clamp						1	—	C	
10H/0970088	Z.62229	Ring, sealing						1	—	C	
5K/9107065	EEAS.146/A	Sleeve						4	—	C	
5K/9107068	EEAS.146/D1	Sleeve						4	—	C	
10H/0560511	CZ.49016/1	Socket, 4-way						1	—	C	
5X/9430396	HC.490	Tag						2	—	C	
	E.B6.81.1383	CABLE, ASSEMBLY, FA.66, FROM L.A.B.S. J.B.A., TO EARTH, GROUP						1	—	—	
		Consisting of:—									
5E/4187	†	Cable, Uninyvin 12						QR	—	C	
5F/9013643	†	Conduit, flexible						QR	—	C	
5X/2786	No. 3	Grommet, tension						1	—	C	
5X/9400389	†	Lug, Mk. 9						2	—	C	
5K/9107066	EEAS.146/A1	Sleeve						4	—	C	
5K/9107069	EEAS.146/F	Sleeve						4	—	C	
5X/9430224	HC.510	Tag						2	—	C	
	E.B6.81.1385	CABLE, ASSEMBLY, FA.64, L.A.B.S. J.B. TO PROTECTIVE RELAY UNIT, GROUP						1	—	—	
		Consisting of:—									
5E/4183	†	Cable, Uninyvin 20						QR	—	C	
5F/2035	†	Conduit, flexible						QR	—	C	
18864	EEAS.111/3	Ferrule						1	—	C	
10H/0970059	Z.60668	Gasket, outlet						1	—	C	
5X/2788	No. 5	Grommet, tension						1	—	C	


Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
10H/0970065	CZ.49182	Outlet, straight	1	—	C	
5X/1530	Z.18501/Z	Ring, clamp	1	—	C	
10H/0970091	Z.62231	Ring, sealing	1	—	C	
5K/9107065	EEAS.146/16	Sleeve	16	—	C	
5K/9107070	EEAS.146/H	Sleeve	4	—	C	
10H/0560180	CZ.49126	Socket, 12-way	1	—	C	
5K/9430396	HC.490	Tag	9	—	C	
	E.B6.81.4243	CABLE, ASSEMBLY, FA.67, FROM PROTECTIVE RELAY UNIT TO FUZE CHARGE UNIT, GROUP (MOD. 3442)	1	—	—	
		Consisting of:—				
5E/4183	†	Cable, Uninyvin 20	QR	—	C	
5F/2037	†	Conduit, flexible	QR	—	C	
	E.B6.81.1495	Ferrule	2	—	—	
10H/0970060	Z.60669	Gasket, outlet	2	—	C	
10H/0970073	CZ.50784	Outlet, angle	2	—	C	
10H/0560390	CZ.53159	Plug, 18-way	1	—	C	
5X/6489	CZ.23144/C	Ring, clamp	2	—	C	
10H/0970092	Z.62232	Ring, sealing	2	—	C	
10H/0560210	CZ.50794	Socket, 18-way	1	—	C	
5K/9107065	EEAS.146/16	Sleeve	36	—	C	
5K/9107070	EEAS.146/00	Sleeve	4	—	C	
	E.B6.81.1389	CABLE, ASSEMBLY, FA.61, FROM L.A.B.S. J.B. TO PROTECTIVE RELAY UNIT, GROUP	1	—	—	
		Consisting of:—				
5E/4183	†	Cable, Uninyvin 20	QR	—	C	
5F/2034	†	Conduit, flexible	QR	—	C	
26DK/6014	EEAS.111/2	Ferrule	1	—	C	
10H/0970058	Z.60667	Gasket, outlet	1	—	C	
5X/2786	No. 3	Grommet, tension	1	—	C	
10H/0970062	CZ.49180	Outlet, straight	1	—	C	
5X/1599	Z.18501/A	Ring, clamp	1	—	C	
10H/0970088	Z.62229	Ring, sealing	1	—	C	
10H/0560110	CZ.49016	Socket, 4-way	1	—	C	
5K/9107065	EEAS.146/16	Sleeve	4	—	C	
5K/9107067	EEAS.146/6	Sleeve	4	—	C	
5X/9430396	HC.490	Tag	2	—	C	
34113	E.B6.81.1447	CRATE, MOUNTING, ASSEMBLY	1	—	—	
		Spares for:—				
3416	EEAS.132/7	Strap, cable	1	—	C	
27459	EEAS.30/28HR	Washer	1	—	C	
	E.B6.81.1845	EQUIPMENT, INSTALLATION, ON FRAMES 27-29, GROUP	—	—	—	
		Spares for:—				
	E.A9.81.3545	Bolt, special	8	—	—	
9/4890	†	Gyro, yaw roll, cageable	1	—	A	
9/4889	†	Gyro, vertical, cageable	1	—	A	
9/4613	†	RELAY, BOX AND TIMER (PRE-MOD. 3768) ...	1	—	A	
		Consisting of:—				
9/4717	†	Relay, box	1	—	A	
9/4718	†	Timer	1	—	A	
9/4873	†	Relay, box (Mod. 3768) (S.O.O.) B(l) 6 A/C only	1	—	A	
9/4718	†	Timer (Mod. 3768) (S.O.O.) B(l) 6 A/C only	1	—	A	

EQUIPMENT AIRCRAFT L.L.A.B.S. REMOVABLE EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.81.5183	PANEL, CONTROL, ASSEMBLY (MOD. 3452) ...						1	—	—	
		Spares for:—									
5L/9959118	†	Bulb, 28 volt ...						1	—	B	
	DOWTY										
5CZ/6114	C.5175Y Mk.66	Indicator, magnetic, 3-way ...						1	—	B	
5D/1541	†	Indicator, magnetic ...						2	—	B	
	PAGE ENG'RING										
5CW/6462	C.330/C	Lamp, amber ...						1	—	B	
33681	E.B6.81.1473	Panel, blanking, assembly ...						1	—	C	
32366	E.A9.81.4659	PANEL, CONTROL, ASSEMBLY ...						1	—	B	
		Spares for:—									
28FP/621	DZUS PRN.3½	Fastener ...						4	—	C	
5CZ/5027	BERCO L.25/GB	Rheostat ...						1	—	B	
	E.B6.81.1431	Seal, rubber ...						1	—	—	
5CW/6435	†	Switch, Rotax ...						1	—	B	
5CW/5823	†	Switch, Rotax ...						1	—	B	
5CW/5825	†	Switch, Rotax ...						1	—	B	
10F/1786	†	Switch, type 1290 ...						1	—	B	
33101	E.A9.81.4401	Tag ...						1	—	C	
	EEAS.28/2HP	Washer, spacing ...						8	—	—	
	E.B6.81.1429	Window, perspex ...						1	—	—	
	E.A9.81.3627	PANEL, CONTROL, AND INVERTER, TYPE 112, INSTALLATION, GROUP						—	—	—	
		Spares for:—									
	E.A9.81.3571	CABLE, ASSEMBLY, FROM PANEL CONTROL TO INVERTER, GROUP						2	—	—	
		Consisting of:—									
5E/9100021	†	Cable, Sextovinmet miniature 6B ...						QR	—	C	
10H/0970077	Z.49042	Ferrule, outer ...						2	—	C	
10H/0970078	Z.49041	Ferrule, inner ...						2	—	C	
10H/0970058	Z.60667	Gasket, outlet ...						2	—	C	
10H/0970069	CZ.49181	Outlet, angle ...						1	—	C	
10H/0970062	CZ.49180	Outlet, straight ...						1	—	C	
10H/0560300	CZ.49222	Plug, free, Mk. 4 ...						1	—	C	
10H/0970088	Z.62229	Ring, sealing ...						2	—	C	
5K/9107065	EEAS.146/16	Sleeve, ¾" long ...						10	—	C	
5K/9107067	EEAS.146/6	Sleeve, 1" long ...						2	—	C	
10H/0560120	CZ.49017	Socket, free, Mk. 4 ...						1	—	C	
	E.A9.81.3573	CABLE, ASSEMBLY, FROM PANEL CONTROL TO INVERTER, GROUP						2	—	—	
		Consisting of:—									
5E/4199	†	Cable, Uninyvinmet sheath 20 ...						QR	—	C	
10H/0970292	†	Clamp, cable ...						1	—	C	
10H/0970293	†	Clamp, cable ...						1	—	C	
10H/0970069	CZ.49181	Outlet, angle ...						1	—	C	
10H/0970058	Z.60667	Outlet, gasket ...						2	—	C	
10H/0970061	CZ.49178	Outlet, straight ...						1	—	C	
10H/0560270	CZ.49216	Plug, free, Mk. 4 ...						1	—	C	
5K/9107065	EEAS.146/16	Sleeve, ¾" long ...						4	—	C	
5K/9107066	EEAS.146/12	Sleeve, 1" long ...						2	—	C	

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of	Plate No.
					Equip. M.R. L.M.	
10H/0970114	Z.62240	Sleeve, cable	2	—	C	
10H/0560090	CZ.49014	Socket, free, Mk. 4	1	—	C	
37711	E.A9.81.3629	Frame, mounting, inverter	1	—	—	
SUB/6505	ROTAX S.3302/L	Inverter, type 112	2	—	A	
SUC/6030	ROTAX U.1504/L	Panel, control, type 26	2	—	A	
28FP/9432062	AVIATION DEVS. A.143	Pin, "Pip"	4	—	C	
33680	E.A9.81.3661	TRAY, MOUNTING, ASSEMBLY	2	—	—	
		Spares for:—				
	E.A9.81.3675	Bracket	2	L.72	—	
	E.A9.81.3677	Catch	2	L.72	—	
	E.A9.81.3671	Cirdip	2	DTD.215	—	
	E.A9.81.3669	Dowel	2	L.64	—	
10AJ/158	†	Mounting, A.V. 4 lbs.	2	—	B	
10AJ/159	†	Mounting, A.V. 6 lbs.	2	—	B	
	E.A9.81.3673	Nut	2	BS.21	—	
	E.A9.81.3683	Pillar	2	L.64	—	
	E.A9.81.3667	Screw	2	S.92	—	
10A/17930	†	Washer, 0"·48 thick, cadmium plate	4	—	C	

Plate A.E.1



EQUIPMENT IN PRESSURE CABIN