

EQUIPMENT ANCILLARY GROUND EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A1.88.2	GROUND EQUIPMENT, ASSEMBLY						—	—	—	
		Spares for:—									
4Q/2627	E.A1.88.77	ADAPTOR , fuselage jacking						1	—	B	GE.1
1L/178	†	ADAPTOR , canopy to fuselage torque wrench (Mod. 2536)						1	—	C	
95087	E.A3.88.157	ARM, NOSEWHEEL STEERING, ASSEMBLY						1	—	A	GE.1
		Spares for:—									
20870	E.A3.88.57	ARM STEERING, ATTACHMENT						1	—	A/MR	
		Spares for:—									
21123	E.A3.88.47	BAR , release axle pin						2	—	C/MR	
21124	E.A3.88.49	BAR , release plunger						2	—	C/MR	
21218	E.A3.88.51	BUSH						2	—	C/MR	
40109	E.A3.88.41	GUIDE , axle pin						2	—	C/MR	
95459	E.A3.88.43	GUIDE , plunger						2	—	C/MR	
26190	E.A3.88.55	PIN , adaptor						2	—	C/MR	
22988	E.A3.88.25	PIN , axle, port						1	—	C/MR	
21120	E.A3.88.27	PIN , axle, starboard						1	—	C/MR	
21122	E.A3.88.45	PLUNGER						2	—	C/MR	
21219	E.A3.88.69	SPRING						2	—	C/MR	
95460	E.A3.88.53	WASHER , saddle						2	—	C/MR	
	FLEXELLO										
95494	633-C1	CASTOR , unit						2	—	B	
95022	E.A3.88.15	ATTACHMENT, NOSE TOWING BAR, ASSEMBLY						1	—	A	GE.1
		Spares for this assembly are identical with those for assembly Part No. E.A3.88.157 except for the following deletion and addition:—									
		Delete:—									
26190	E.A3.88.55	PIN , adaptor						2	—	C/MR	
		Add:—									
25733	E.A3.88.37	PIN , adaptor						2	—	C/MR	
95539	L.F.D.S. 4319	ASSISTOR , Avro triple bomb carrier (Mod. 2671)						1	—	B	
4G/2792	†	BAR , towing						1	—	A	
95299	E.A3.88.297	BLOCK , for depressing stud ring cover when assembling or withdrawing fuel tanks No. 1 and 2						2	—	B	
	ELEC.HYDR'LICS										
95103	T.1342/75	BLOCK , split, for air brake						1	—	B	GE.1
95490	E.A1.88.889	BOLT , canopy slave (ST.8/4833) (Mod. 2536)						32	S.97	C	
95413	E.A3.88.307	BRACKET, MAIN WHEEL JACKING, ASSEMBLY (MOD. GE.1451)						2	—	B	
		Spares for:—									
21870	E.A3.88.219	BOLT						2	S.94 or S.95	C	
95013	E.A3.88.79	BRIDGE , detachable, for wing slugging						1	—	A	GE.1
95012	E.A1.88.89	CABLES , retaining bomb door						2	—	B	
1971	E.A3.88.91	CLAMP , aileron locking						1	—	B	GE.1
1972	E.A3.88.92	CLAMP , aileron locking						1	—	B	GE.1
1867	E.A1.88.73	CLAMP , elevator locking, starboard						1	—	B	GE.1
13142	E.A1.88.873	CLAMP , elevator locking, port (Mod. GE.2134)						1	—	B	
2468	E.A3.88.153	CLAMP, RUDDER, LOCKING, ASSEMBLY						2	—	B	GE.1
		Spares for:—									
14747	TERRY EX.12	SPRING						1	—	C	

EQUIPMENT ANCILLARY GROUND EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
95298	E.A3.88.205	COVER, used for protection and depressing stud rings when assembling or withdrawing fuel tanks No. 1 and 2						2	—	B	GE.1
	E.B6.88.35	COVERS, AIRCRAFT, GROUP (MOD. 1701)						—	—	—	
27D/2948	E.A3.88.301	COVER, nose						1	—	B	
27D/2809	E.A1.88.401	COVER, coupe						1	—	B	
27D/2991	E.A9.88.27	COVER, engine						2	—	B	
27D/2811	E.A1.88.405	COVER, jet pipe						2	—	B	
27D/2807	E.A1.88.407	COVER, main wheel						2	—	B	
27D/2806	E.A1.88.409	COVER, nose wheel						2	—	B	
27D/2962	E.A1.88.597	COVER, pressure head						1	—	B	
27D/2878	E.A1.88.787	COVER, equipment door						1	—	B	
95109	E.A3.88.211	CRADLE, for handling jettisonable wing tanks						1	—	A	
95037	E.A1.88.417	CRADLE, retraction test for use at frame 13						1	—	A	
95038	E.A1.88.419	CRADLE, retraction test for use at frame 29						1	—	A	
95113	ALVIS AS.18086	CRADLE, for bomb trolley						1	—	A	
95072	E.A1.88.551	DISC, setting engine control, starboard, 12 SWG						2	L.72	B	GE.2
95408	E.B6.88.27	DISC, setting engine control, port, 12 SWG						1	L.72	B	
	—	EQUIPMENT, SIGHTING, COMPASS ALIGNMENT, GROUP (MOD. 2627 - S.O.O.)						—	—	—	
		Spares for:—									
95563	E.A9.88.481	CASE, carrying, assembly						1	—	B	
95562	E.A9.88.479	ROD, SIGHTING, ASSEMBLY, AFT						1	—	A	
		Spares for:—									
	E.A9.88.497	BRACKET, mounting (spirit level)						1	—	—	
	E.A9.88.445	BRACKET, rod sighting						1	—	—	
	E.A9.88.447	JOINT, ball, inner						1	—	—	
	E.A9.88.449	JOINT, ball, outer						1	—	—	
	E.A9.88.467	KNOB						1	—	—	
	COOKE										
	TROUGHTON & SIME LTD. E.985	LEVEL, spirit circular						1	—	—	
	E.A9.88.495	SHAFT						1	—	—	
	E.A9.88.469	STUD						1	—	—	
95561	E.A9.88.477	ROD, SIGHTING, FORWARD, ASSEMBLY						1	—	A	
		Spares for:—									
	E.A9.88.513	BRACKET, mounting (spirit level)						1	—	—	
	E.A9.88.505	CHUCK, inner portion						1	—	—	
	E.A9.88.507	CHUCK, sleeve						1	—	—	
	E.A9.88.515	CLIP						2	—	—	
	E.A9.88.447	JOINT, ball, inner						1	—	—	
	E.A9.88.449	JOINT, ball, outer						1	—	—	
	E.A9.88.517	JOINT, ball, rod end						1	—	—	
	COOKE										
	TROUGHTON & SIME LTD. E.985	LEVEL, spirit circular						1	—	—	
	E.A9.88.509	PLATE, sighting						1	—	—	
	E.A9.88.519	ROD						1	—	—	
	E.A9.88.511	TIP, sighting						1	—	—	
	E.A9.88.503	TUBE, 1½" o/d. x 22 SWG						1	—	—	
95292	A.6300	EXTRACTOR and assembly tool for wheels						1	—	B	
95047	E.A1.88.359	EXTRACTOR, wing to fuselage pick-up pins						1	—	A	GE.2
95044	E.A1.88.375	EXTRACTOR, for tab torque lever						1	—	A	GE.2

CANBERRA B. Mk. 6

Page 442A

EQUIPMENT ANCILLARY GROUND EQUIPMENT

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
95104	E.A1.88.825	EXTRACTOR, for aileron hinge pin						1	—	A	GE.2
95462	E.B6.88.103	EXTRACTOR, rudder blow-back rod (Mod. GE.1912)						1	—	A	
27G/5105	A.10056	FIXTURE, hydraulic brake alignment.. ...						1	—	B	
	E.A1.88.91	FORMERS, ASSEMBLY, DRAWING, PORT						—	—	—	
95025	E.A1.88.91A	FORMER, wing lifting gantry forward, port ...						1	—	B	GE.2
95026	E.A1.88.91B	FORMER, wing lifting gantry, centre, port ...						1	—	B	GE.2
95027	E.A1.88.91C	FORMER, wing lifting gantry, aft, port ...						1	—	B	GE.2
95028	E.A1.88.91D	FORMER, wing lifting gantry, forward, port ...						1	—	B	GE.2
95029	E.A1.88.91E	FORMER, wing lifting gantry, centre, port ...						1	—	B	GE.2
95030	E.A1.88.91F	FORMER, wing lifting gantry, aft, port ...						1	—	B	GE.2
	E.A1.88.92	FORMERS, ASSEMBLY, DRAWING, STARBOARD						—	—	—	
95031	E.A1.88.92A	FORMER, wing lifting gantry, forward, starboard						1	—	B	GE.2
95032	E.A1.88.92B	FORMER, wing lifting gantry, centre, starboard ...						1	—	B	GE.2
95033	E.A1.88.92C	FORMER, wing lifting gantry, aft, starboard ...						1	—	B	GE.2
95034	E.A1.88.92D	FORMER, wing lifting gantry, forward starboard						1	—	B	GE.2
95035	E.A1.88.92E	FORMER, wing lifting gantry, centre, starboard ...						1	—	B	GE.2
95036	E.A1.88.92F	FORMER, wing lifting gantry, aft, starboard ...						1	—	B	GE.2
95115	E.A3.88.179	GAUGE, tailplane incidence and dihedral						1	—	B	
95010	E.A1.88.93	GAUGE, wing incidence dihedral						1	—	B	
95040	E.A1.88.447	GAUGE, levelling, cockpit lateral and fuselage longeron						1	—	B	
95093	E.A1.88.747	GAUGE, levelling, cockpit longeron and fuselage lateral						1	—	B	

CANBERRA B Mk. 6

Page 443

EQUIPMENT, ANCILLARY
GROUND EQUIPMENT

Ref. No.	Part No.	Description						No Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
95100	E.A1.88.823	GAUGE, aileron, fixed tab angle checking ...						1	—	B	
95653	—	GAUGES, clearance, aileron shroud screen (Supplied in set of three)						1 Set	—	B	
95532	E.A1.88.893	GAUGE, inspection, assembly of canopy to fuselage (Mod. 2536)						1	—	B	
95273	E.A1.88.785	GEAR, LIFTING, COMPLETE AIRCRAFT, ASSEMBLY (MOD. GE.876)						2	—	A	
		Spares for:—									
95526	E.A3.88.317	BOLT, special shouldered ...						2	S.97	C	
95527	E.A3.88.319	WASHER, special ...						2	MS	C	
95276	E.B7.88.15	GUARD, AIR INTAKE, DEBRIS, ASSEMBLY (FOR USE ON A/C NOT EMBODYING AVON MOD. 843)						2	—	B	
		Spares for:—									
95503	E.A3.88.295	BOLT, key ...						2	MS	C	
95538	E.B7.88.205	GUARD, AIR INTAKE, DEBRIS, ASSEMBLY (FOR USE ON A/C EMBODYING AVON MOD. 843) (MOD. GE.2396)						2	—	B	
		Spares for:—									
33H/	†	ADHESIVE, P.R.C. compound ...						QR	—	—	
	E.B7.88.207	SEGMENT ...						3	LFS.21	—	
28S/1214853	4100/8/8"	SCREW, P.K. ...						21	—	C	
32B/	E.B7.88.209	STRIP, felt, 3/8" x 1"0 x 38" long ...						1	DTD.590	—	
1B/4467	†	GUN, lubricating ...						1	—	A	
95080	A.T.81489	HANDLE, crutching ...						1	—	A	
4Q/2626	E.A1.88.257	HEAD, 10 ton jack adaptor ...						2	MS	A	
95112	E.A3.88.269	HEAD, jacking for 15 ton pillar jack ...						2	—	B	
95293	E.A1.88.831	INDICATOR, engine controls, setting disc, 20 SWG						1	DTD.124	A	
95051	E.A1.88.349	INSERTER, piston ring, main undercarriage oleo leg						1	L.72	A	
95048	E.A1.88.363	INSERTER, wing to fuselage, pick-up pins ...						1	—	A	
95052	E.A1.88.383	INSERTER, main oleo pivot point bush ...						1	—	A	
95050	E.A1.88.389	INSERTER, for bushes in torque links, main oleo leg						1	—	A	
95053	E.A1.88.391	INSERTER, and extractor for sealing rings, main oleo leg						1	—	A	
95088	E.A1.88.733	INSERTER, main undercarriage pivot pin ...						1	—	A	
4Q/2232	†	JACK, hydraulic, fuselage ...						1	—	A	
95063	E.A1.88.395	KEY, hydraulic tank ...						1	—	B	
1970	E.A1.40.169	LUG, picketing and towing ...						2	S.11	C	
27Q/11743	D.2606Y	NOZZLE, flexible, c/w gauge ...						1	—	A	
95015	E.A1.88.255	PIN, nosewheel locking ...						1	—	B	
95491	E.A1.88.891	PIN, locating (ST.8/4842) (Mod. 2536) ...						6	—	C	
95407	E.B6.88.29	PLATE, setting, bellcrank lever, engine control, port						1	L.59	B	
95294	E.A1.88.547	PLATE, setting, bellcrank lever, engine control, port						1	—	A	
95295	E.A1.88.548	PLATE, setting, bell lever, engine control starboard						1	—	C	
95074	E.A1.88.549	PLATE, setting, throttle box, 16 SWG ...						1	L.72	C	
95270	E.A3.88.281	PLUG, BLANKING, CABIN, PRESSURE CONTROL VALVE, ASSEMBLY						1	—	A	
		Consisting of:—									
	†	CHAIN, retaining ...						QR	Brass	—	
21084	E.A2.88.77	PENNANT, ...						1	—	C	
	E.A3.88.283	PLUG, ...						1	L.40	—	
	†	RING, split, 3/4" o/d. x 1/8" dia. ...						2	—	—	

EQUIPMENT, ANCILLARY GROUND EQUIPMENT

Ref. No.	Part No.							No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
6A/2679	†							4	—	B	
1C/2161	†							1	—	B	
95277	E.B6.88.1							2	—	B	
95442	E.B6.88.85							2	—	A	
	E.B6.88.139							—	—	—	
	E.B6.83.173							1	—	—	
	E.B6.88.185							4	S.1	—	
	E.B6.88.175							1	—	—	
	E.B6.88.187							4	—	—	
	E.B6.88.179							2	—	—	
	E.B6.88.177							2	—	—	
	E.B6.88.189							4	—	—	
	E.B6.88.273							2	—	—	
	E.B6.88.205							1	—	—	
	E.B6.88.209							2	—	—	
	E.B6.88.211							2	—	—	
	E.B6.88.213							1	—	—	
	E.B6.88.223							1	S.92	—	
	E.B6.88.225							1	S.92	—	
	E.B6.88.221							2	S.92	—	
	E.B6.88.219							2	S.92	—	
	E.B6.88.215							1	—	—	
	E.B6.88.251							1	—	—	
	E.B6.88.223							1	S.92	—	
	E.B6.88.225							1	S.92	—	
	E.B6.88.253							2	S.96	—	
	E.B6.88.217							2	—	—	
	E.B6.88.217							2	—	—	
	E.B6.88.227							4	—	—	
	E.B6.88.281							1	—	—	
	E.B6.88.229							1	—	—	
	E.B6.88.283							1	—	—	
	E.B6.88.287							1	—	—	
	E.B6.88.209							1	—	—	
	E.B6.88.219							1	S.92	—	
	E.B6.88.221							1	S.92	—	
28M/13811	A27/JTL							1	—	C	
28M/1007404	A27/JT							1	—	C	
	E.B6.88.295							1	—	—	
	E.B6.88.213							1	—	—	
	E.B6.88.223							1	S.92	—	
	E.B6.88.225							1	S.92	—	
28M/13811	A27/JTL							1	—	C	
28M/1007404	A27/JT							1	—	C	
28M/1011467	A27/ES							2	—	C	

CANBERRA B Mk. 6

Page 445

EQUIPMENT, ANCILLARY
GROUND EQUIPMENT

Ref. No.	Part No.	Description						No Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
28P/9559603 28W/14395 28N/5555	E.B6.88.297							2	Silver steel	—	
	SP.90/C6							2	—	C	
	AS.1905/E8							4	—	C	
	AGS.899/8							4	—	C	
	E.B6.88.293							1	—	—	
	E.B6.88.251							1	—	—	
	E.B6.88.223							1	S.92	—	
	E.B6.88.225							1	S.92	—	
28M/13811	A27/JTL							1	—	C	
28M/1007404	A27/JT							1	—	C	
28M/1011467	A27/ES							4	—	C	
	E.B6.88.253							2	S.96	—	
	E.B6.88.299							2	Silver steel	—	
28P/9559603	SP.90/C6							4	—	C	
28P/14543	SP.31/H8							2	—	C	
28W/14395	AS.1905/E8							8	—	C	
	E.B6.88.227							4	S.92	—	
28P/1202570	SP.90/E5							4	—	C	
	E.B6.88.285							1	—	—	
	E.B6.88.289							2	—	—	
	E.B6.88.219							1	S.92	—	
	E.B6.88.221							1	S.92	—	
28M/13811	A27/JTL							1	—	C	
28M/1007404	A27/JT							1	—	C	
	†							QR	—	—	
	E.B6.88.255							1	—	—	
	E.B6.88.259							2	S.92	—	
	E.B6.88.239							1	S.96	—	
	E.B6.88.141							1	—	—	
95089	E.A1.88.743							2	—	A	
	E.A2.88.77							2	—	C	
28FP/9432064	AVDEL A.817							2	—	C	
95008	E.A1.88.11							1	—	A	
95009	E.A1.88.59							1	—	A	
95006	E.A1.88.61							1	—	A	
95005	E.A1.88.63							1	—	A	
95007	E.A1.88.65							1	—	A	
95084	E.A1.88.601							1	—	A	
95094	E.A1.88.741							1	—	A	
95443	E.B6.88.39							1	—	A	
	E.B6.88.57							1	S.92	C	
1L/22	†							1	—	B	
1L/45	†							1	—	B	
1L/67	†							1	—	B	
95269	E.A3.88.293							1	—	C	

EQUIPMENT, ANCILLARY GROUND EQUIPMENT

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
95064	E.A1.88.263	SPANNER, integral and drop tanks						1	DTD.124A	B	
95493	E.A1.88.877	SPANNER, nosewheel door (Mod. 2311)						1	—	B	
95054	E.A1.88.345	SPANNER, torque link, main undercarriage						1	DTD.124A	C	
95056	E.A1.88.347	SPANNER, special, "C", main undercarriage, oleo stop nut						1	—	B	
95057	E.A1.88.353	SPANNER, special, main undercarriage oleo piston						1	—	B	
95325	E.A3.88.303	SPANNER, special, main undercarriage oleo bearing ring						1	—	B	
95086	E.A3.88.135	SPANNER, special, main undercarriage oleo axle clamp						1	—	B	
95065	E.A1.88.365	SPANNER, special, plug, forward jacking point ...						1	—	B	
95046	E.A1.88.379	SPANNER, universal, for attaching aileron to centre hinge bracket						1	M.S.	B	
95059	E.A1.88.385	SPANNER, special, for undercarriage pivot pin ...						1	M.S.	B	
95060	E.A1.88.387	SPANNER, special, for undercarriage pivot nut ...						1	M.S.	B	
95079	E.A1.88.531	SPANNER, special, for drop tank, assembly ...						1	M.S.	C	
1C/3226	†	SPANNER, union, main fuel feed						2	—	B	
95466	E.B7.88.203	SPANNER, special, fuel pump, pipe, integral tank (Mod. GE.1730)						1	S.3	B	
95095	E.A1.88.749	SPANNER, forward bomb crutch						1	—	C	
95004	E.A1.88.23	SPIGOT, forward jacking, front fuselage						1	S.65	B	
95262	E.A3.88.273	STRAP, metal, for use with combined nose and centre fuselage sling						1	—	B	
95090	E.A1.88.799	STRUT, jury, tailplane						1	—	A	
95444	E.B6.88.81	STRAP, INNER, INTEGRAL TANK, ASSEMBLY (MOD. GE.1292)						1	—	B	
		Spares for:—									
95465	E.B6.88.119	BOLT, sub-assembly						1	—	C	
95464	E.B6.88.121	BOLT, sub-assembly						1	—	C	
95483	E.B6.88.47	BRACKET, guide, inner						1	—	C	
05445	E.B6.88.83	STRAP, outer, integral tank, assembly						1	—	B	
	E.B7.88.53	TEMPLATES, NEUTRAL RIGGING, ASSEMBLY ...						—	—	—	
		Spares for:—									
95297	E.B7.88.65	TEMPLATE, neutral, rigging, aileron						1	—	A	
95296	E.B7.88.55	TEMPLATE, neutral, rigging, elevator						1	—	A	
95265	E.A3.88.247	TEMPLATE, neutral, rigging, rudder						1	—	A	
	E.A3.88.5053	TEST SET, AIR VENTILATED SUIT (MOD. GE.4047)						—	—	—	
		Spares for:—									
	E.A3.88.5069	ADAPTOR, test gauge, assembly						1	—	—	
	E.A3.88.5077	ADAPTOR, test gauge, assembly						1	—	—	
	E.A3.88.5057	ADAPTOR, orifice						3	—	—	
	E.A3.88.5055	CASE, carrying						1	—	—	
6A/	6685-420483	GAUGE, 0-30 lb.						1	—	—	
6A/	6685-420491	GAUGE, 0-200 lb.						1	—	—	
	E.A3.88.5059	PLUG, blanking, assembly						1	—	—	
	E.A3.88.5061	PLUG, blanking, assembly						1	—	—	
	E.A3.88.5063	PLUG, blanking, assembly						1	—	—	
95061	E.A1.88.351	TOOL, shock absorbing piston, centralising ...						1	—	A	
95062	E.A1.88.361	TOOL, special, combination, main undercarriage oleo insertion and extraction of spherical bearing						1	—	C	

CANBERRA B Mk. 6

Page 447

EQUIPMENT, ANCILLARY
GROUND EQUIPMENT

Ref. No.	Part No.	Description						No Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
95101	E.A1.88.821	TOOL	setting	...	...	...	...	1	—	A	
	MARTIN-BAKER										
95082	A/MBEU/70/EE	TOOL	for cocking and uncocking snatch unit	...	...	...	...	1	—	C	
	E.A1.88.87	TRESTLES	REAR FUSELAGE, ASSEMBLY	...	...	...	...	—	—	—	
		Spares for:—									
95017	E.A1.88.87A	FORMER	forward	...	...	...	...	1	Spruce	B	
95018	E.A1.88.87B	FORMER	aft	...	...	...	...	1	Spruce	B	
95016	E.A1.88.85	TROLLEY	PRESSURE CABIN, GROUND MAINTENANCE, ASSEMBLY	...	...	...	...	1	—	A	
		Spares for:—									
95487	E.A2.88.53	WHEEL	trolley (Capowheel T.82)	...	...	...	...	1	—	A	
95069	ALVIS S.4954	TROLLEY	BOMB LOADING, HYDRAULIC, MK. 1	...	...	...	...	4	—	A	
	or										
95111	18101	TROLLEY	BOMB LOADING, HYDRAULIC, MK. 2	...	...	...	...	1	—	A	
		Spares for:—									
95239	HC.34501B	ADAPTOR	hose, pump, O.S.	...	...	...	...	1	—	B	
95240	HC.31723	ADAPTOR	hose, pump, lines	...	...	...	...	2	—	B	
95241	HC.24313	ADAPTOR	tank and pump	...	...	...	...	3	—	B	
95242	HC.4968	ADAPTOR	...	...	...	...	...	3	—	B	
95243	HC.27254	ADAPTOR	...	...	...	...	...	4	—	B	
95244	HC.33438	ADAPTOR	cylinder to hose	...	...	...	...	3	—	B	
95155	AS.17986	ADAPTOR	plate, 16½" dia.	...	...	...	...	8	—	C	
95122	AS.16571	ARM	steering, O.S.	...	...	...	...	1	—	A	
95123	AS.16572	ARM	steering, N.S.	...	...	...	...	1	—	A	
95249	HC.23364	BANJO	fitting	...	...	...	...	30	—	B	
95250	HC.23367	BANJO	fitting, double, ⅝"	...	...	...	...	8	—	B	
95251	HC.16297	BANJO	fitting, angle, reversing valve	...	...	...	...	1	—	B	
95252	HC.38058	BANJO	hose, ¼"	...	...	...	...	10	—	B	
95217	AS.18151	BEARING	assembly, roller, cradle	...	...	...	...	8	—	A	
95218	AS.1856	BEARING	assembly, roller, store	...	...	...	...	8	—	A	
95253	HC.1318	BOLT	banjo, ¼"	...	...	...	...	49	—	B	
95530	HC.31727/4	BOOT	cylinder lifting	...	...	...	...	1	—	C	
95531	HC.41447	BOOT	cylinder lifting	...	...	...	...	1	—	C	
95254	No. 1331	BOOT	for reversing valve	...	...	...	...	1	—	B	
95118	AS.16555	BRAKE	drum	...	...	...	...	2	—	A	
	GIRLING										
16L/21880	GB.34608	BRAKE	assembly, R.H.	...	...	...	...	1	—	A	
	GIRLING										
16L/21890	GB.34609	BRAKE	assembly, L.H.	...	...	...	...	1	—	A	
95138	AS.16688	BUSH	bellcrank lever	...	...	...	...	1	—	B	
95141	AS.16685	BUSH	upper brake lever spindle and valve handle shaft	...	...	...	...	6	—	B	
95142	AS.16686	BUSH	lower brake lever spindle	...	...	...	...	2	—	B	
95144	AS.16687	BUSH	bisector lever	...	...	...	...	2	—	B	
95133	AS.16716	BUSH	handbrake lever	...	...	...	...	1	—	B	
95159	AS.16981	BUSH	reversing lever	...	...	...	...	1	—	B	
95121	AS.16575	BUSH	stub axle swivel pin and lifting arm stop	...	...	...	...	8	—	B	
95146	AS.16684	BUSH	spindle, brake lever	...	...	...	...	2	—	B	
95128	AS.16591	BUSH	tow bar, yoke and plate	...	...	...	...	4	—	B	
95151	AS.16569	BUSH	tilting cylinder pin	...	...	...	...	2	—	B	
95152	AS.16816	BUSH	long, transmitter shaft	...	...	...	...	2	—	B	
95153	AS.16817	BUSH	short, transmitter shaft	...	...	...	...	2	—	B	

EQUIPMENT, ANCILLARY GROUND EQUIPMENT

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
95157	AS.16987	BUSH	store roller	...	...	...	...	4	—	B	
95131	AS.17263	CATCH	trigger tow bar	...	...	...	...	1	—	C	
95255	K.20109	CLIP	for boot	...	...	...	...	1	—	B	
95219	HC.41412	CYLINDER	lifting	...	...	...	...	2	—	A	
95220	HC.31392J	CYLINDER	lifting	...	...	...	...	2	—	A	
95221	HC.25220-QC4	CYLINDER	TABLE OPERATING, 4" STROKE	...	...	...	...	2	—	A	
		Spares for:—									
	HC.26357/8	BOOT	c/w clip and filter, assembly	...	...	...	...	1	—	—	
95222	HC.25220-NJ6	CYLINDER	table operating, 6" stroke	...	...	...	...	2	—	A	
16T/770	No. 6358	EXTENSION	valve	...	...	...	...	4	—	B	
95226	MF.2604	FILTER	micronic	...	...	...	...	1	—	C	
	or										
	MF.2629	FILTER	micronic	...	...	...	...	1	—	C	
95247	HC.36961	FITTING	bulkhead	...	...	...	...	26	—	B	
16L/8300	15489	FITTING	bulkhead	...	...	...	...	8	—	C	
16L/10800	KL.44524	GASKET	for banjo	...	...	...	...	54	—	C	
95257	KL.44521	GASKET	...	...	...	...	...	70	—	B	
95258	KL.44528	GASKET	$\frac{3}{8}$ "	...	...	...	...	8	—	B	
95259	KL.44535	GASKET	$\frac{1}{2}$ "	...	...	...	...	8	—	B	
95225	HC.2107A	HANDWHEEL	...	...	...	...	...	2	—	B	
95230	CM.323B12	HOSE	pump and tank, N.S. and O.S., 12" long	...	...	...	...	3	—	B	
95231	CM.274D18	HOSE	pump and tank, N.S., 18" long	...	...	...	...	1	—	B	
95232	CM.374D24	HOSE	pump and tank, O.S., 24" long	...	...	...	...	1	—	B	
95233	CM.322B19	HOSE	lifting cylinder and hydroloc, O.S., 19" long	...	...	...	...	8	—	B	
95234	CM.323B24	HOSE	lifting, cylinder, 24" long	...	...	...	...	4	—	B	
95235	CM.322B42	HOSE	table cylinder	...	...	...	...	1	—	B	
95236	CM.322B34	HOSE	table cylinder	...	...	...	...	1	—	B	
95237	CM.322B41	HOSE	table cylinder	...	...	...	...	1	—	B	
95238	CM.322B32	HOSE	table cylinder	...	...	...	...	1	—	B	
95124	AS.16573	KEY	steering arm	...	...	...	...	2	—	B	
95126	AS.16595	LOCKNUT	steering arm tie rod socket, R.H.	...	...	...	...	2	—	B	
95127	AS.16596	LOCKNUT	steering arm tie rod socket, L.H.	...	...	...	...	2	—	B	
16L/9752	18234	NUT	tube, $\frac{5}{8}$ "	...	...	...	...	114	—	C	
95256	No. 19885	NUT	tube	...	...	...	...	6	—	B	
95117	AS.16438	NUT	wheel	...	...	...	...	32	—	B	
16M/1478	HC.1787	OUTLET	straight	...	...	...	...	10	—	C	
95245	HC.14028	OUTLET	straight, tank	...	...	...	...	1	—	B	
95136	AS.16751	PAWL	handbrake	...	...	...	...	1	—	B	
16L/2460	1234	PIECE	3-way, $\frac{3}{8}$ " pipe	...	...	...	...	5	—	C	
95243	HC.40504	PIECE	3-way, pump line, N.S.	...	...	...	...	1	—	B	
95154	AS.17039	PIN	hinge, transmitter, bracket	...	...	...	...	2	—	B	
28FP/9243488	AVDEL A1013	PIN	"pip"	...	...	...	...	2	—	C	
95134	AS.16715	PIN	pivot, handbrake lever	...	...	...	...	1	—	B	
95139	AS.16675	PIN	pivot, bellcrank lever	...	...	...	...	1	—	B	
95148	AS.16892	PIN	pivot, 22" long lifting cylinder	...	...	...	...	2	—	B	
95149	AS.16800	PIN	pivot, 8 $\frac{3}{4}$ " long lifting cylinder	...	...	...	...	2	—	B	
95150	AS.16568	PIN	pivot, lifting cylinder	...	...	...	...	2	—	B	
95455	AS.17990	PIN	plunger, cradle retaining	...	...	...	...	4	—	C	
95120	AS.16574	PIN	stub, axle swivel (front) and lifting arm stop	...	...	...	...	1	—	B	
95129	AS.16592	PIN	swivel, tow bar yoke	...	...	...	...	1	—	B	
95130	AS.16594	PIN	swivel, tow bar	...	...	...	...	1	—	B	
95161	AS.17187	PIPE	tank to tee piece	...	...	...	...	1	—	B	
95162	AS.17188	PIPE	hose adaptor to filter, N.S.	...	...	...	...	1	—	B	
95163	AS.17189	PIPE	tank to hose, N.S.	...	...	...	...	1	—	B	
95164	AS.17191	PIPE	3-way, to pump, N.S.	...	...	...	...	1	—	B	
95165	AS.17192	PIPE	pump to hose, N.S.	...	...	...	...	1	—	B	
95166	AS.17193	PIPE	pump to hose, O.S.	...	...	...	...	1	—	B	

EQUIPMENT, ANCILLARY
GROUND EQUIPMENT

Ref. No.	Part No.							No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
95167	AS.17194	PIPE	reversing valve to selector valve ...	...	...	...	...	1	—	B	
95168	AS.17195	PIPE	3-way, to reversing valve, N.S. ...	...	...	...	...	1	—	B	
95169	AS.17196	PIPE	O.S. pump hose to 3-way, N.S. ...	...	...	...	...	1	—	B	
95170	AS.17197	PIPE	3-way, to hose adaptor, N.S. ...	...	...	...	...	1	—	B	
95171	AS.17202	PIPE	filter, to reversing valve ...	...	...	...	...	1	—	B	
95172	AS.17203	PIPE	reversing valve to selector valve ...	...	...	...	...	1	—	B	
95173	AS.17204	PIPE	bracket to selector valve ...	...	...	...	...	1	—	B	
95174	AS.17205	PIPE	bracket to selector valve ...	...	...	...	...	1	—	B	
95175	AS.17206	PIPE	bracket to selector valve ...	...	...	...	...	1	—	B	
95176	AS.17207	PIPE	bracket to selector valve ...	...	...	...	...	1	—	B	
95177	AS.17208	PIPE	O.S. bracket to N.S. bracket ...	...	...	...	...	1	—	B	
95178	AS.17209	PIPE	O.S. bracket to N.S. bracket ...	...	...	...	...	1	—	B	
95179	AS.17210	PIPE	O.S. bracket to N.S. bracket ...	...	...	...	...	1	—	B	
95180	AS.17211	PIPE	O.S. bracket to N.S. bracket ...	...	...	...	...	1	—	B	
95181	AS.17212	PIPE	hydroloc valve to hydroloc valve (arm) ...	...	...	...	...	2	—	B	
95182	AS.17213	PIPE	hydroloc valve to hydroloc valve (arm) ...	...	...	...	...	2	—	B	
95183	AS.17216	PIPE	No. 1, hydroloc valve (arm) to bracket, O.S.	...	...	...	...	1	—	B	
95184	AS.17217	PIPE	No. 2, hydroloc valve (arm) to bracket, O.S.	...	...	...	...	1	—	B	
95185	AS.17218	PIPE	No. 3, hydroloc valve (arm) to bracket, O.S.	...	...	...	...	1	—	B	
95186	AS.17219	PIPE	No. 4, hydroloc valve (arm) to bracket, O.S.	...	...	...	...	1	—	B	
95187	AS.17220	PIPE	No. 1, hydroloc valve (on arm) to bracket (on arm), O.S.	...	...	...	...	1	—	B	
95188	AS.17221	PIPE	No. 2, hydroloc (on arm) to bracket (on arm), O.S.	...	...	...	...	1	—	B	
95189	AS.17222	PIPE	No. 3, hydroloc (on arm) to bracket (on arm), O.S.	...	...	...	...	1	—	B	
95190	AS.17223	PIPE	No. 4, hydroloc (on arm) to bracket (on arm), O.S.	...	...	...	...	1	—	B	
95191	AS.17224	PIPE	jack to jack (Forward and aft) ...	...	...	...	...	1	—	B	
95192	AS.17225	PIPE	jack to jack (Forward and aft) ...	...	...	...	...	1	—	B	
95193	AS.17226	PIPE	jack to jack (Lateral) ...	...	...	...	...	1	—	B	
95194	AS.17227	PIPE	jack to jack (Lateral) ...	...	...	...	...	1	—	B	
95195	AS.17228	PIPE	hydroloc valve (Top) to 3-way, rear end ...	...	...	...	...	1	—	B	
95196	AS.17229	PIPE	hydroloc valve (Top) to 3-way, rear end ...	...	...	...	...	1	—	B	
95197	AS.17230	PIPE	pump hose adaptor, O.S. to pump hose adaptor, N.S.	...	...	...	...	1	—	B	
95198	AS.17231	PIPE	reversing valve to selector valve ...	...	...	...	...	1	—	B	
95199	AS.17232	PIPE	bracket to 3-way ...	...	...	...	...	2	—	B	
95200	AS.17233	PIPE	bracket to 3-way ...	...	...	...	...	2	—	B	
95201	AS.17234	PIPE	hydroloc valve (Top) to bracket, N.S. ...	...	...	...	...	1	—	B	
95202	AS.17235	PIPE	hydroloc valve (Top) to bracket, N.S. ...	...	...	...	...	1	—	B	
95203	AS.17236	PIPE	selector valve to bracket ...	...	...	...	...	1	—	B	
95204	AS.17237	PIPE	selector valve to bracket ...	...	...	...	...	1	—	B	
95205	AS.17238	PIPE	centre to bottom hydroloc valve ...	...	...	...	...	1	—	B	
95206	AS.17239	PIPE	centre, hydroloc valve to 3-way ...	...	...	...	...	1	—	B	
95207	AS.17240	PIPE	bracket to 3-way, N.S. ...	...	...	...	...	1	—	B	
95208	AS.17241	PIPE	bracket to 3-way, N.S. ...	...	...	...	...	1	—	B	
95209	AS.17242	PIPE	hydroloc valve (Bottom) to bracket, N.S. ...	...	...	...	...	1	—	B	
95210	AS.17243	PIPE	centre to bottom hydroloc valve ...	...	...	...	...	1	—	B	
95211	AS.17244	PIPE	bottom hydroloc valve to 3-way ...	...	...	...	...	1	—	B	
95212	AS.17245	PIPE	bracket O.S. to 3-way ...	...	...	...	...	1	—	B	

EQUIPMENT, ANCILLARY
GROUND EQUIPMENT

Ref. No.	Part No.							No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
95213	AS.17246							1	—	B	
95214	AS.17247							1	—	B	
95215	AS.17248							1	—	B	
95216	AS.17249							1	—	B	
95246	HCP.16902							2	—	B	
95224	HC.26140F							2	—	A	
95135	AS.16245							1	—	B	
95125	AS.16577							2	—	C	
	LOCKHEED										
95617	2286							2	—	C	
95119	†							4	—	B	
95467	AS.18003/2							8	—	C	
95158	AS.17006							4	—	C	
95160	AS.17934							2	—	C	
95260	J.3704 R.H.							2	—	B	
95261	J.3705 L.H.							2	—	B	
95140	AS.16678							2	—	B	
95143	AS.16671							1	—	B	
95145	AS.16683							2	—	B	
95147	N.1738							2	—	B	
95156	AS.3729							4	—	B	
95137	N.1464							1	—	B	
95132	AS.17271							1	—	B	
95116	AS.16437							32	—	C	
95223	HC.42544							1	—	B	
16T/768	†							4	—	A	
16T/767	†							4	—	A	
95227	HC.19694A							7	—	A	
95228	HC.28085S							1	—	A	
95229	HC.42197							1	—	B	
95648	HC.42237							1	—	C	
16T/766	WDM.685							4	—	A	
95263	ALVIS AS.18152							1	—	A	
95356	ALVIS AS.18126							1	—	B	
	LOCKHEED										
95239	HC.34501/B							1	—	B	
95373	HC.34501/C							1	—	B	
95241	HC.24313							2	—	B	
95243	HC.27254							1	—	B	
95387	HC.35563							1	—	C	
95388	HC.23709							1	—	B	
95389	HC.34502/CB							2	—	B	
95383	HC.22379							3	—	B	
95390	No. 236							1	—	B	
95253	HC.1318							4	—	B	
95365	ALVIS AS.18360							4	—	B	
95344	AS.18119							4	—	B	
	LOCKHEED										
27BA/8794	AVA.63/C							1	—	B	
27BA/8826	AVA.63/B							1	—	B	
95394	HC.1000							2	—	B	
95395	HC.2449							2	—	B	

EQUIPMENT, ANCILLARY
GROUND EQUIPMENT

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
95348	ALVIS AS.18143	CLIP, spring, roof	...	...	...	...	...	2	—	B	
	LOCKHEED										
95381	HC.42472	CONNECTION, 3-way, $\frac{1}{4}$ "	...	...	...	...	...	1	—	B	
95385	HC.11835	CONNECTION, 3-way, $\frac{3}{8}$ "	...	...	...	...	...	1	—	B	
27BA/8759	AVA.57/B	COUPLING, Avery, $\frac{1}{4}$ ", half union pressure line	...	...	...	...	...	1	—	B	
27BA/8760	AVA.57/C	COUPLING, Avery, $\frac{3}{8}$ ", half union return line	...	...	...	...	...	1	—	B	
95361	ALVIS AS.18354	COVER, L.H.	...	...	...	...	...	1	Canvas	B	
95362	AS.18355	COVER, R.H.	...	...	...	...	...	1	Canvas	C	
95363	AS.18356	COVER, front	...	...	...	...	...	1	—	C	
42L/	†	ENGINE, Villiers, Mk. 25 with reduction gear,	...	...	...	...	...	1	—	A	
		S.5309									
	LOCKHEED										
95367	HC.44240	FITTING, bulkhead, $\frac{1}{4}$ "	...	...	...	...	...	1	—	B	
95368	HC.44242	FITTING, bulkhead, $\frac{3}{8}$ "	...	...	...	...	...	1	—	B	
95257	KL.44521	GASKET, $\frac{1}{4}$ " BSP	...	...	...	...	...	9	—	B	
16L/10800	KL.44524	GASKET, banjo	...	...	...	...	...	4	—	B	
95258	KL.44528	GASKET, $\frac{3}{8}$ " BSP	...	...	...	...	...	6	—	B	
95391	KL.44523	GASKET, $\frac{1}{8}$ " BSF	...	...	...	...	...	1	—	B	
95392	KL.44532	GASKET, $\frac{1}{4}$ " BSF	...	...	...	...	...	1	—	B	
95259	KL.44535	GASKET, $\frac{1}{2}$ " BSP	...	...	...	...	...	1	—	B	
95393	KL.44543	GASKET, $\frac{3}{4}$ "	...	...	...	...	...	2	—	B	
95346	WAINE W.01928	HANDLE, roof	...	...	...	...	...	2	—	B	
	LOCKHEED										
95376	CM.3258/240	HOSE, $\frac{1}{2}$ " H.P., 20 ft. long pressure line	...	...	...	...	...	1	—	B	
95377	CM.373C/240	HOSE, $\frac{3}{8}$ ", 20 ft. long return line	...	...	...	...	...	1	—	B	
95378	CM.374F/18	HOSE, $\frac{1}{2}$ ", 18" long, pump suction	...	...	...	...	...	1	—	B	
95379	CM.326B/11	HOSE, $\frac{1}{4}$ ", 11" long, pump suction	...	...	...	...	...	1	—	B	
95354	ALVIS AS.18113	LUG, and base, assembly, foot pedal	...	...	...	...	...	1	—	B	
95343	AS.18124	Nut, support leg	...	...	...	...	...	4	—	B	
	LOCKHEED										
95369	HCP.11505	NUT, for $\frac{3}{8}$ " bulkhead fitting	...	...	...	...	...	1	—	B	
95370	KL.46002	NUT, for $\frac{1}{4}$ " bulkhead fitting	...	...	...	...	...	1	—	B	
95380	HC.2446	OUTLET, straight, $\frac{3}{8}$ "	...	...	...	...	...	2	—	B	
95382	HC.2060	OUTLET, straight, $\frac{1}{4}$ "	...	...	...	...	...	1	—	B	
95384	HC.14027	OUTLET, straight, $\frac{3}{8}$ "	...	...	...	...	...	1	—	B	
95352	ALVIS AS.18118	PEDAL, foot, assembly, c/w pad	...	...	...	...	...	1	—	B	
95347	AS.18139	PIN, roof hinge	...	...	...	...	...	2	—	B	
95353	AS.18121	PIN, joint, foot pedal and control valve adaptor	...	...	...	...	...	2	—	B	
95399	AS.18326	PIPE, control valve to 3-way, $\frac{1}{4}$ " o/d. x 20 SWG	...	...	...	...	...	1	—	B	
		x 13" long, c/w nuts									
95400	AS.18327	PIPE, 3-way to relief valve, $\frac{1}{4}$ " o/d. x 20 SWG	...	...	...	...	...	1	—	B	
		x 29" long, c/w nuts									
95401	AS.18328	PIPE, 3-way to bulkhead fitting, $\frac{1}{4}$ " o/d. x 20 SWG	...	...	...	...	...	1	—	B	
		x 24" long, c/w nuts									
95402	AS.18329	PIPE, tank to bulkhead fitting, $\frac{3}{8}$ " o/d. x 18 SWG	...	...	...	...	...	1	—	B	
		x 22" long, c/w nuts									
95403	AS.18330	PIPE, tank to relief valve, $\frac{3}{4}$ " o/d. x 18 SWG	...	...	...	...	...	1	—	B	
		x 18" long, c/w nuts									
95404	AS.18331	PIPE, relief valve to 3-way, $\frac{3}{8}$ " o/d. x 18 SWG	...	...	...	...	...	1	—	B	
		x 29 $\frac{1}{2}$ " long, c/w nuts									
95405	AS.18332	PIPE, 3-way to control banjo, $\frac{3}{8}$ " o/d. x 18 SWG	...	...	...	...	...	1	—	B	
		x 11" long, c/w nuts									

EQUIPMENT, ANCILLARY
GROUND EQUIPMENT

Ref. No.	Part No.							No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
95406	AS.18333						PIPE, 3-way to control valve outlet connection, $\frac{3}{8}$ " o/d. x 18 SWG x $3\frac{1}{2}$ " long, c/w nuts	1	—	B	
95349	AS.18142						PLATE, roof spring clip	2	—	B	
	LOCKHEED										
95386	HCP.16901						PLUG, $\frac{1}{4}$ " BSP	1	—	B	
95360	FP.7508						PUMP, fluid	1	—	A	
95345	ALVIS AS.18133						ROOF, plate, assembly, complete	1	—	C	
	LOCKHEED										
95396	K.17603						SCREW, self tapping, pipe clip	8	—	C	
95350	ALVIS AS.18144						STOWAGE, bin	1	—	B	
95364	AS.18357						STRAP, for cover	5	—	B	
95342	AS.18125						STUD, support leg	4	—	C	
95341	AS.18116						SUPPORT, leg, assembly	4	—	B	
	LOCKHEED										
95357	HC.29615						TANK, fluid supply, 3 gallons	1	—	B	
95359	HC.26260D						VALVE, blow off	1	—	B	
95358	HC.28085U						VALVE, control (Mechanically operated)	1	—	B	
95366	ALVIS AS.18359						WASHER	15	—	C	
	LOCKHEED										
95371	K.19210						WASHER, spring, for $\frac{1}{4}$ " bulkhead fitting	1	—	C	
95372	K.19213						WASHER, spring, for $\frac{3}{8}$ " bulkhead fitting	1	—	C	
95340	ALVIS AS.18120						WHEEL, and axle, assembly, c/w tyre	2	—	A	
	—						TROLLEY, BOMB LOADING CONVERSION SET	—	—	—	
							Spares for:—				
	LOCKHEED										
95244	33438						ADAPTOR	5	—	B	
95249	HC.23364						BANJO, $\frac{5}{8}$ " pipe	4	—	B	
95383	HC.22379						BANJO, $\frac{3}{8}$ " pipe	1	—	B	
95253	HC.1318						BOLT, banjo	5	—	C	
95323	ALVIS AS.18233						BRACKET, Avery, coupling	1	—	B	
95324	AS.18234						BRIDGE, protector	1	—	B	
	AS.18239						BRIDGE, protector (Made from AS.17724 Ref. 95339 with one $\frac{3}{32}$ " dia. hole)	1	—	B	
	LOCKHEED										
27BA/8832	AVA.64/B						CAP, blanking, $\frac{1}{4}$ "	1	—	C	
27BA/8775	AVA.64/C						CAP, blanking, $\frac{3}{8}$ "	1	—	C	
27BA/8899	AVA.58/B						COUPLING, Avery fixed half, $\frac{1}{2}$ " pressure line	1	—	C	
27BA/8750	AVA.55/C						COUPLING, Avery fixed half, $\frac{3}{8}$ " return line	1	—	C	
	HC.20402						FITTING, outlet, $\frac{5}{8}$ " pipe, BSP	3	—	—	
95257	KL.44521						GASKET, $\frac{1}{4}$ " BSP	9	—	C	
16L/10800	KL.44524						GASKET, banjo	5	—	C	
27M/	AVX.273						OLIVE, $\frac{1}{4}$ "	1	—	—	
27M/8983	AVX.265						OLIVE, $\frac{3}{8}$ "	1	—	C	
95382	HC.2060						OUTLET, straight, $\frac{1}{4}$ " pipe, BSP	1	—	B	
16L/2460	1234						PIECE, 3-way	1	—	B	
95330	ALVIS AS.18361						PIPE, $\frac{5}{8}$ " o/d. x 42" long	1	—	B	
95331	AS.18362						PIPE, $\frac{5}{8}$ " o/d. x 16" long	1	—	B	
95332	AS.18363						PIPE, $\frac{5}{8}$ " o/d. x 13" long	1	—	B	
95333	AS.18364						PIPE, $\frac{5}{8}$ " o/d. x 11" long	1	—	B	
95334	AS.18365						PIPE, $\frac{5}{8}$ " o/d. x 10" long	1	—	B	
95335	AS.18366						PIPE, $\frac{5}{8}$ " o/d. x 5" long	1	—	B	
95336	AS.18367						PIPE, $\frac{1}{2}$ " o/d. x $12\frac{1}{2}$ " long	1	—	B	
95337	AS.18368						PIPE, $\frac{3}{8}$ " o/d. x $13\frac{1}{2}$ " long	1	—	B	

EQUIPMENT, ANCILLARY GROUND EQUIPMENT

Ref. No.	Part No.	Description						No Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	LOCKHEED										
95622	HC.15236	PLUG,	end,	pump	cylinder	...	...	1	—	B	
95338	HC.44871	RESTRICTOR	...	...	...	...	...	2	—	A	
16L/9752	18234	TUBE,	nut,	$\frac{5}{16}$ "	...	...	...	14	—	C	
27M/4699	ADS.174A	TUBE,	nut,	$\frac{1}{4}$ "	...	...	...	1	—	C	
27M/4310	ADS.174E	TUBE,	nut,	$\frac{3}{8}$ "	...	...	...	1	—	C	
	239	TUBE,	nut,	$\frac{3}{8}$ "	...	...	...	1	—	—	
	31385	TUBE,	nut,	$\frac{1}{4}$ "	...	...	...	1	—	—	
95326	HC.44213	VALVE,	change-over	...	...	...	...	1	—	A	
95327	HC.26907	VALVE,	non-return	...	...	...	...	1	—	A	
1C/6239	†	WRENCH,	torque,	for	attachment	bolts	...	1	—	A	
1C/6447	†	WRENCH,	torque,	for	pilot's	canopy	...	1	—	A	
	JENKS BROS.										
1L/156	E.V.T. 360	WRENCH,	torque,	for	explosive	bolts,	canopy to fuselage, attachment (Mod. 2536)	1	—	C	
25633	ALVIS AS.17026	YOKE,	bar	towing	...	...	...	1	—	B	
	—	TRANSPORTATION EQUIPMENT	...	...	...	...	...	—	—	—	
95279	†	BEAM,	transportation,	fuselage	nose	(43G/SAL/180)		1	Deal	B	
95280	†	BEAM,	transportation,	mid-section,	front	fuselage (43G/SAL/180)		1	Deal	B	
95281	†	BEAM,	transportation,	fuselage,	rear	section (Rear) (43G/SAL/181)		1	Deal	B	
95282	†	BEAM,	transportation,	fuselage,	rear	section (Front) (43G/SAL/181)		1	Deal	B	
95285	†	BEAM,	transportation,	fuselage,	rear	section (Rear) (43G/SAL/182)		1	Ash	B	
95289	†	BEAM,	transportation,	main	plane	outer, port (43G/SAL/194)		1	Ash	B	
95290	†	BEAM,	transportation,	main	plane	outer, starboard (43G/SAL/194)		1	Ash	B	
95291	†	BEAM,	transportation	(support	blocks),	main	plane (43G/SAL/195)	2	R.S.J.	B	
95286	†	BLOCK,	transportation,	main	plane,	front (43G/SAL/185)		2	Ash	B	
95287	†	BLOCK,	transportation,	main	plane	rear (43G/SAL/185)		2	Ash	B	
95288	†	BLOCK,	transportation,	main	plane,	centre (43G/SAL/185)		2	Ash	B	
95283	†	PEDESTAL,	transportation,	tail	plane	(43G/SAL/183)		1	M.S.	C	
95284	†	PEDESTAL,	transportation,	tail	plane	(43G/SAL/184)		2	M.S.	B	
NOTE:— The number off shown is the quantity required for the transportation of one aircraft											

⁴⁵⁸
Pages ~~447~~ to 456 not issued
₄₅₅


CANBERRA B Mk 6

Page 457


EQUIPMENT ANCILLARY
GROUND EQUIPMENT

Ref. No.	Part No.	1	2	3	4	5	6	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
											M.R. L.M.	
SUMMARY OF STOCK ITEMS USED ON GROUND EQUIPMENT, ASSEMBLY												
28D/9133012	A25/3C	Bolt,	2	BA	...	...	...	...	...	—	—	C
28D/1200119	A25/4C	Bolt,	2	BA	...	...	...	...	...	—	—	C
28D/1215085	AS.1246/12½C	Bolt,	2	BA	...	...	...	...	...	—	—	C
28D/1212801	AS.1248/10C	Bolt,	2	BA	...	...	...	...	...	—	—	C
28D/1214258	AS.1248/28B	Bolt,	4	BA	...	...	...	...	...	—	—	C
28M/1006473	A27/CT	Nut,	2	BA	...	...	...	...	...	—	—	C
28M/1007403	A27/ET	Nut,	4	BSF	...	...	...	...	...	—	—	C
28M/10327	AGS.2002/B/1	Nut, stiff,	4	BA	...	...	...	...	...	—	—	C
28P/19176	SP.90/G6	Pin, split,	3	dia. x 1" long	...	...	...	...	...	—	—	C
28P/9528015	SP.90/G8	Pin, split,	3	dia. 1¼" long	...	...	...	...	...	—	—	C
28S/9995324	A32/A16	Screw,	6	BA	...	...	...	...	...	—	—	C
28W/9419466	SP.13/J	Washer	...	...	...	...	...	...	...	—	—	C
28W/9419468	SP.13/N	Washer	...	...	...	...	...	...	...	—	—	C
28W/9419475	SP.15/C	Washer	...	...	...	...	...	...	...	—	—	C


Plate G.E.1




E. A1. 88. 77



E. A3. 88. 205




E. A3. 88. 157




E. A1. 88. 73




ELECTRO HYDRAULICS
T. 1342/75




E. A3. 88. 91
E. A3. 88. 92



E. A3. 88. 153








E. A3. 88. 15




E. A3. 88. 79


Plate G.E.2



INBOARD { E. A1. 88. 91A
E. A1. 88. 92A
OUTBOARD { E. A1. 88. 91D
E. A1. 88. 92D



INBOARD { E. A1. 88. 91B
E. A1. 88. 92B
OUTBOARD { E. A1. 88. 91E
E. A1. 88. 92E



INBOARD { E. A1. 88. 91C
E. A1. 88. 92C
OUTBOARD { E. A1. 88. 91F
E. A1. 88. 92F