

RESTRICTED


1st Edition

2.  
A.P.4335C—P.N.

T.P.

# PILOT'S NOTES

# VENOM N.F.3



Prepared by Direction  
of the  
Minister of Supply

Promulgated by Order  
of the  
Air Council

*J. R. C. Helmore J. H. Barrow*

*not in charge  
to H.P.B.*

RESTRICTED

## RESTRICTED

AIR MINISTRY  
May, 1956

Amendment List No. 1  
to A.P.4335C—P.N.  
*Pilot's Notes*

### V E N O M N. F. 3.

- NOTE.—1. Incorporation of this Amendment List must be certified by inserting the date of incorporation and initials in the spaces provided on page 1.
2. When a manuscript amendment is made, the adjacent margin should be endorsed with the AL number, viz., "A.L.1."
3. When the Amendment List is fully incorporated, *affix* this sheet to the inside front cover of the Notes.

PAGE	PARA.	AMENDMENT
1	NOTES TO USERS	<i>Amend</i> first paragraph by gummed slip herewith.
1	LIST OF ASSO- CIATED PUBLI- CATIONS	Item 5 <i>amend</i> to read 1641F. Item 12 <i>amend</i> to read 2538 HA.
12	7, line 2	<i>Amend</i> "16 pints" to read "18 pints".
13	11(i)	<i>Amend</i> by gummed slip herewith.
14	11(ii) contd.	<i>Amend</i> by gummed slip herewith.
17	16(i)d, line 13	<i>Delete</i> "when in manual".
18	18(iii)	<i>Amend</i> by gummed slip herewith.
22	27(ii) last line	<i>Amend</i> "white" to read "black".
26	—	<i>Amend</i> by gummed page herewith.
28	38	<i>Amend</i> by gummed slip herewith.
29	—	<i>Amend</i> by gummed page herewith.
31	—	<i>Amend</i> by gummed page herewith.
32-33	44	<i>Amend</i> by two gummed slips herewith.
39	52	<i>Amend</i> NOTES by gummed slip herewith.
42	57(i) line 1	<i>Amend</i> "speds" to read "speeds".
45	—	<i>Amend</i> by gummed page herewith.
48	65	<i>Amend</i> by gummed slip herewith.
49	66(ii) (d)	<i>Delete</i> from "If difficulty" to "open position".
49	66(ii) (g) IMPOR- TANT	<i>Delete</i> this note.
50	—	<i>Amend</i> by gummed page herewith.
51	—	<i>Amend</i> by gummed page herewith.
53	70(i)	<i>Amend</i> by gummed slip herewith.
54	74	<i>Add</i> at end of line 4 "(on regulator)".

## RESTRICTED

**RESTRICTED**

**NOTES TO USERS**

A.L.1  
Notes to  
Users  
Page 1

These Notes are complementary to A.P.129 (6th Edition) Flying, and assume a thorough knowledge of the chapters which are relevant to the operation of this type of aircraft (see A.M.O. A.293/55).

Additional copies may be obtained by the Station Publications Officer by application on R.A.F. Form 294A, in quadruplicate, to Command Headquarters for onward transmission to A.P.F.S. (see A.P. 113A). The number of this publication must be quoted in full A.P.4335C.—P.N.

Comments and suggestions should be forwarded to the Officer Commanding, Handling Squadron, Royal Air Force, Boscombe Down, Wiltshire.

**AMENDMENTS**

Amendment lists will be issued as necessary and will be gummed for affixing to the inside front cover of these notes. Each amendment list will, where applicable, be accompanied by gummed slips for sticking in the appropriate places in the text. Incorporation of an amendment list must be certified by inserting the date of incorporation and initials below.

A.L. NO.	INITIALS	DATE	A.L. NO.	INITIALS	DATE
1	<i>gfh.</i>	<i>18-4-57</i>	4		
2			5		
3			6		

**RESTRICTED**

## V E N O M N . F . 3

### LIST OF ASSOCIATED PUBLICATIONS

	A.P.	
Cine-camera and G.G.S. recorder ... ..	1355D	
Cold air unit ... ..	4340	
Electrical equipment manual ... ..	1095A to C	
Engine — Ghost Mk. 104 ... ..	4320B	
Hispano 20 mm. guns ... ..	1641 <del>B</del> F	A.
Hydraulic equipment — Lockheed ... ..	1803B, C	
Instrument manual ... ..	1275A to E	
Intercommunication A1961 ... ..	2876E	
Pneumatic compressor ... ..	1519	
Pneumatic equipment — Hymatic ... ..	4303C	
R.P. installations ... ..	2802A	
Transmitter — receiver TR1934 ... ..	2538HA	A.
Turbo starter — Teddington ... ..	1181	
Turbo starter cartridges ... ..	1661F	
Windscreen de-icing system ... ..	1464D	

## VENOM N.F.3

### LIST OF CONTENTS

Notes to Users ... ..	Page 1
List of associated publications ... ..	Page 2

### PART I—DESCRIPTION

Introduction ... ..	<i>Para.</i> 1
---------------------	-------------------

### FUEL AND OIL SYSTEMS

Fuel tanks ... ..	2
Fuel contents gauge ... ..	3
Fuel transfer system and indicators ... ..	4
Fuel feed to the engine ... ..	5
Fuel controls ... ..	6
Oil system ... ..	7

### ENGINE CONTROLS

Throttle control ... ..	8
Engine starting system ... ..	9
Relighting control ... ..	10
Engine fire-warning light and extinguishers ... ..	11
Engine instruments ... ..	12


### MAIN SERVICES

Hydraulic system ... ..	13
Pneumatic system ... ..	14
Electrical system ... ..	15

### AIRCRAFT CONTROLS

Flying and trimming controls ... ..	16
Flying controls locking gear ... ..	17
Undercarriage ... ..	18
Flaps ... ..	19
Airbrakes ... ..	20
Wheel brakes ... ..	21

MAIN DIMENSIONS — WING SPAN 42' 9"  
 LENGTH (OVERALL) 36' 8"  
 HEIGHT 6' 6"



VENOM NF 3

## COCKPIT EQUIPMENT

	<i>Para.</i>
Access to cockpit ... ..	22
Hood operation ... ..	23
Hood jettisoning ... ..	24
Cockpit lighting ... ..	25
Seat and harness adjustment ... ..	26
Oxygen system ... ..	27
Cockpit air conditioning ... ..	28
Windscreen de-icing ... ..	29
Direct-vision panel ... ..	30
Windscreen wiper ... ..	31
Anti-G equipment ... ..	32
Emergency equipment ... ..	33

## FLIGHT AND NAVIGATION EQUIPMENT

Flight and navigation instruments ... ..	34
External lighting ... ..	35

## SIGNALS EQUIPMENT

Wireless installation ... ..	36
Radar installation ... ..	37

## ARMAMENT EQUIPMENT

Guns ... ..	38
Gunsight ... ..	39
Cameras ... ..	40

## PART II—LIMITATIONS

Engine limitations — Ghost Mk.104 ... ..	41
Flying limitations ... ..	42

## PART III—HANDLING

External checks ... ..	43
C.G. data ... ..	44
Cockpit checks ... ..	45
Management of the fuel system ... ..	46
Starting the engine ... ..	47
Checks after starting ... ..	48

	<i>Para.</i>
Checks before taxiing ... ..	49
Taxiing ... ..	50
Checks before take-off ... ..	51
Take-off ... ..	52
Climbing ... ..	53
General flying ... ..	54
Flying at reduced speed ... ..	55
Flying in conditions of severe turbulence ... ..	56
Stalling ... ..	57
High-speed flight ... ..	58
Aerobatics ... ..	59
Spinning ... ..	60
Circuit and landing ... ..	61
Instrument approach ... ..	62
Going round again ... ..	63
Checks after landing ... ..	64
Stopping the engine ... ..	65

#### P A R T I V — E M E R G E N C Y H A N D L I N G

Engine failure and relighting in flight ... ..	66
Action in the event of fire ... ..	67
Flying in manual control ... ..	68
Hydraulic pump failure ... ..	69
Emergency operation of the undercarriage ... ..	70
Emergency operation of the flaps ... ..	71
Hood jettisoning ... ..	72
Generator failure ... ..	73
Loss of cabin pressure ... ..	74
Landing with one full tip tank ... ..	75
Drop tank jettisoning ... ..	76
Forced landing ... ..	77
Flapless landing ... ..	78
Ditching ... ..	79
Abandoning ... ..	80

#### P A R T V — O P E R A T I N G D A T A

Pressure error corrections ... ..	81
Take-off distances ... ..	82
Fuel consumptions ... ..	83
Flight planning data ... ..	84

## PART VI—ILLUSTRATIONS

						<i>Fig.</i>
Cockpit—Port side	...	...	...	...	...	1
Cockpit—Forward view		...	...	...	...	2
Cockpit—Starboard side		...	...	...	...	3

This file was downloaded  
from the RTFM Library.  
Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)  
Please see site for usage terms,  
and more aircraft documents.

