

CONTENTS

Leading particulars

Introduction

Section 1—Controls and exits	Chapter 1—Pilot's controls and equipment 2—Not applicable 3—Emergency controls, equipment and exit
Section 2—Ground handling and preparation for flight	Chapter 1—Ground handling 2—Preparation for flight 3—Loading and C.G. data 4—General servicing
Section 3—Airframe	Chapter 1—Fuselage 2—Main planes 3—Tail unit 4—Flying controls 5—Landing gear 6—Hydraulic system 7—Not applicable 8—Air conditioning system 9—De-icing system 10—Oxygen system 11—Emergency system 12—Not applicable 13—Anti-'G' system
Section 4—Power unit installation	Chapter 1—Power unit 2—Fuel system 3—Not applicable 4—Not applicable 5—Fire protection system
Section 5—Electrical installation and instrument installation	Chapter 1—Electrical system 2—Instrument installation
Section 6—Radio installation	Chapter 1—Wireless installation 2—Radar installation
Section 7—Armament installation	Chapter 1—Pyrotechnics 2—R.P. equipment 3—Guns 4—Bombing equipment

RESTRICTED

(A.L.47, Aug. 57)

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

