

FUSELAGE—SEAT INSTALLATION

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
	D.190915	SEAT INSTALLATION, ASSEMBLY ...					—	—		
6D/1465	—	Cable , operating bracket anchor section ...					1	—		
6D/1651	—	Clip , harness, swivel type ...					1	—		
6D/1698	Aerolex	Clip ...					1	—		
27VA/4553	Dunlop	Hose , anti-G, assembly ...					1	—		
	ACM.17992									
2692	F.175134	Packing ...					4	DTD.610	MR/C	
27L/50019	Martin Baker	Rail , guide ...					1	—		
	D/MBEU/121/HK									
27L/50018	Martin Baker	Seat , Mk. 2H ...					1	—		
	B/MBEU/122/HK									
6D/1464	—	Socket , anchor, outer housing ...					1	—		
6D/1642	—	Socket , quick release, oxygen, Mk. 7 ...					1	—		
6D/1579	—	Tubing , low pressure, flexible ...					1	—		

FUSELAGE-SEAT INSTALLATION

Ref. No.	Part No.	Description								No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5	6	7	8				
		SUMMARY OF STOCK ITEMS											
28D/12569	A25.10.E	Bolt, 1/2"	B.S.F.	...	...	...	...	...	...	—	—	—	
28D/14526	A57.6.E	Bolt, 1/2"	B.S.F.	...	...	...	...	...	...	—	—	—	
28M/14536	A58.E.T.	Nut, 1/2"	B.S.F.	...	...	...	...	...	...	—	—	—	
28M/12928	A27.E.P.	Nut, 1/2"	B.S.F.	...	...	...	...	...	...	—	—	—	
28W/12406	SP.15.E	Washer, 1/2"	i/d	...	...	...	...	...	...	—	—	—	
28W/12297	SP.16.E	Washer, 1/2"	i/d	...	...	...	...	...	...	—	—	—	

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

