

3rd Edition

AP 4347 F-PN

RESTRICTED

Pilot's Notes
Hunter F Mk 6

RESTRICTED

AMENDMENTS

Amendment lists will be issued as necessary and should be inserted in the appropriate place in the Notes. New or amended paragraphs will be indicated by triangles positioned in the text thus: ◀.....▶ to show the extent of the amended text, and thus ▶◀ to show where text has been deleted. When a page is issued or re-issued by amendment the number of the Amendment will appear at the bottom of the page. When a chapter is issued or re-issued in a completely revised form the triangles will not appear. Incorporation of an Amendment list must be certified by inserting the date of its issue, the date of incorporation and signature below.

Amdt. list		Signature	Date of Incorporation	Amdt. list		Signature	Date of Incorporation
No.	Date			No.	Date		
1.				7.			
2.				8.			
3.				9.			
4.				10.			
5.				11.			
6.				12.			

Comments and suggestions regarding Pilot's Notes should be forwarded to the Officer Commanding, Handling Squadron, Royal Air Force, Boscombe Down, Wiltshire.

July, 1961

AP.4347F-PN

PILOT'S NOTES HUNTER F. MK.6.

Prepared by Direction
of the
Minister of Aviation





Promulgated by Command
of the
Air Council

Henry Hausman

h. v. beam

RESTRICTED

AMENDMENTS

Amendment lists will be issued as necessary and should be inserted in the appropriate places in the Notes. New or amended paragraphs will be indicated by triangle thus:   to show the amount of the amended text and thus:   to show where text has been deleted. When a page is issued in a completely revised form the triangles will not appear. Each amendment list will give a list of all Special Flying Instructions and/or modifications which are covered thereby.

Incorporation of an amendment list must be certified by inserting date of incorporation and initials below.

Amendment List		Initials	Date of incorporation
No.	Date		
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			

RESTRICTED

NOTES TO USERS

1. These Notes are complementary to A.P. 129 (6th Edition), Flying. It is assumed that all concerned have a thorough knowledge of the chapters of A.P. 129 relevant to the operation of this type of aircraft (see A.M.O. A.293/55).

2. The limitations in Part II are mandatory and must never be exceeded. The contents of the other Parts of the book are mainly advisory, but instructions containing the word "must" are to be regarded as mandatory.

3. Throughout this publication the following conventions apply :

(a) Words in capital letters indicate the actual markings on the controls concerned.

(b) The numbers quoted in brackets after items in the text refer to illustrations in Part VI.

(c) Unless otherwise stated, all airspeeds, Mach numbers and accelerometer readings quoted are "Indicated."

(d) Fuel poundage figures are all calculated at 7.7. lb./gallon (Normal AVTAG).

4. Additional copies may be obtained by the station publications officer by application on R.A.F. Form 294A in quadruplicate to Command Headquarters for onward transmission to A.P.F.S. (see A.P. 113A). The number of this publication must be quoted in full—A.P.4347F - P.N. (3rd Edition).

5. Comments and suggestions should be forwarded to Officer Commanding, R.A.F., Handling Squadron, Boscombe Down, Wilts.

RESTRICTED


HUNTER F.6

LIST OF ASSOCIATED AIR PUBLICATIONS AND AIR DIAGRAMS


<i>Title</i>	<i>A.P. No.</i>
Aden 30 mm. guns	1641S
Avon Mk. 20300 series E.C.U.	4481C
Cine cameras and accessories	1355D
Ejection seats, R.A.F. aircraft, Mk. 3 series	4288C
Electrical equipment manuals	4343 series
Fuel system components—Lucas	4282A
Gyro gunsights	1275E
Hydraulic equipment, Dowty	1803D
Hydraulic servicing trolley	2306B
Instrument manuals	1275 series
Powered flying control units—Fairey	4601A
Pressure cabin testing, servicing trolley	2306G
Pressurising and air conditioning equipment	4340
Pressure fuelling equipment	4511
Radio compass	2530M
Rotol accessory gearboxes and drives	2240A
Starting systems for aero engines	1181 series
Telebriefing	2876G
Undercarriage equipment, Dowty	1803E

	<i>A.D. No.</i>
Cockpit pressure, heating and ventilation	6445V
Ejection and safety precautions	5037
Electrical installation	6363
Hood jettison mechanism	5673
Flying controls	6445C
Fuel system	6445F
Gun package installation	5676

RESTRICTED



ACCESS PANELS



ACCESS PANELS

List of Contents

INTRODUCTION

PART I. DESCRIPTION AND MANAGEMENT OF SYSTEMS

CHAPTER 1. Fuel System

DESCRIPTION	<i>Para.</i>
Tanks	1
Fuel feed system—general	2
Booster pumps and fuel recuperator	3
Fuel proportioner	4
Filter de-icing	5
Rear tanks explosion protection system	6

CONTROLS AND INDICATORS

L.P. fuel cock	7
Booster pump controls and indicators	8
Fuel contents gauges	9
Transfer system controls and indicators	10
Fuel level indicators	11
Drop tank jettison controls	12
Pressure refuelling and defuelling controls	13
Explosion protection control	14

NORMAL USE OF THE SYSTEM

Pre-flight checks of the system	15
Use of the system in flight	16
Unusable fuel	17

MALFUNCTIONING OF THE SYSTEM

Booster pump failure	18
Transfer failure	19
Transfer changeover failure	20
Fuel gauge errors	21

CHAPTER 2. Engine Controls and Instruments

DESCRIPTION

Avon 203 engine	1
Variable incidence guide vanes and air bleed valves	2
Starting system	3
Engine fire-extinguisher	4

RESTRICTED

	<i>Para.</i>
CONTROLS AND INDICATORS	
Throttle/H.P. fuel cock	5
Starting controls	6
Relighting control	7
Top temperature control	8
Engine instruments	9
Engine anti-icing	10
Management of the engine anti-icing system	11

CHAPTER 3. Electrical System

DESCRIPTION	
D.C. supplies	1
Standby D.C. supplies	2
A.C. supplies	3
CONTROLS AND INDICATORS	
Generator controls and indicators	4
Main battery control	5
Standby battery controls	6
A.C. supply—controls and indicators	7
Warning indicators	8
NORMAL USE OF THE SYSTEM	
Pre-flight procedures	9
MALFUNCTIONING OF THE SYSTEM	
Resetting No. 1 inverter in flight	10
Single generator failure	11
Double generator failure	12
Double generator and battery failure	13

CHAPTER 4. Hydraulic System

DESCRIPTION	
Hydraulic system	1
MALFUNCTIONING OF THE SYSTEM	
Partial hydraulic failure	2
Complete hydraulic failure	3

CHAPTER 5. Powered Flying Controls and Trimmers

DESCRIPTION	
Flying controls—Mod. 686, 687 aircraft	1
Flying controls—pre-mod. 686, 687 aircraft	2
Hydraulic power reserve	3
Tailplane and elevator	4
Tailplane and elevator interconnection	5
Aileron gear change	6

CONTROLS AND INDICATORS

Aileron and elevator power—controls and indicators	7
Manual emergency selector buttons (Mod. 502)	8
Tailplane—controls and indicator	9
Tailplane and elevator interconnection—selector and indicator	10
Aileron feel and trim	11

NORMAL USE OF THE POWERED CONTROLS

Pre-flight checks	12
Checks after landing—mod. 686, 687 aircraft	13

MALFUNCTIONING OF THE POWERED CONTROLS

Bypass booster failures	14
False anchorages—pre-mod. 686, 687 aircraft	15
Tailplane malfunctioning	16

CHAPTER 6. Other Aircraft Controls

Rudder pedals adjustment and rudder trim	1
Flying controls locking gear	2
Undercarriage normal control	3
Undercarriage emergency control	4
Flaps normal control	5
Flaps emergency control	6
Airbrake control	7
Wheelbrakes control	8
Braking parachute control	9

CHAPTER 7. General Equipment and Controls

Hood control	1
Hood jettisoning	2
Cockpit pressurisation, heating and demisting	3
Management of cockpit pressurisation.	4
Internal lighting	5

	<i>Para.</i>
External lighting	6
Accelerometer	7
Pressure head heater	8
Emergency equipment	9

CHAPTER 8. Aircrew Equipment Assembly and Oxygen System

General	1
-------------------	---

EJECTION SEAT

Ejection seat Mk. 2H or 3H	2
Ejection gun and firing handles	3
Barostat/G-stop time delay	4
Manual separation control	5
Leg restraint cords	6

ANTI-G SUIT SYSTEM

Anti-G suit system	7
------------------------------	---

OXYGEN SYSTEM

Oxygen system—general	8
Mk. 17D or Mk. 17E regulator	9
Emergency bottle	10

USE OF AIRCREW EQUIPMENT ASSEMBLY

Strapping in procedure	11
Normal exit procedure	12
Forced landing	13
Abandoning and ditching	14

EMERGENCY USE OF THE OXYGEN SYSTEM

Toxic fumes	15
Regulator indicator failure	16
Regulator failure	17
Use of the emergency bottle	18

CHAPTER 9. Radio and Radar Controls

V.H.F. equipment	1
IFF Mk. 3	2
IFF Mk. 10 (Mod. 794)	3
DME Rebecca Mk. 7 or Mk. 8	4
Radar ranging	5

*Para.***CHAPTER 10.—Armament and Camera Installation**

Gyro gunsight Mk. 5 or Mk. 8	1
Gun firing	2
Armament safety plug	3
G90 and recorder cameras	4
Bomb/RP release and drop tank jettisoning (Post Mod. 378)	5
Bomb/RP release and drop tank jettisoning (Pre Mod. 378)	6

PART II—LIMITATIONS**CHAPTER 1. Engine Limitations**

Engine limitations—Avon 203	1
-------------------------------------	---

CHAPTER 2. Airframe Limitations

General—all configurations	1
Clean aircraft—in Power	2
Drop tanks—in Power	3
Gun firing	4
With RP's—in Power	5
With bombs—in Power	6
Braking parachute	7
Manual flying	8

PART III—HANDLING**CHAPTER 1. Preparation for Flight**

External checks	1
Cockpit and pre-start checks	2

CHAPTER 2. Starting, Taxying and Take-off

Starting the engine	1
Checks after starting	2
Taxying	3
Checks before take-off	4
Take-off	5
Engine handling at take-off	6
Abandoning take-off	7

RESTRICTED

CHAPTER 3. Handling in Flight

Climbing	1
Engine handling	2
Flying controls	3
Flying with external stores	4
Flying for endurance	5
Flying at reduced speed	6
Flying with the hood open	7
Flying in turbulent conditions	8
Stalling	9
G-stalling	10
Spinning	11
Flying at high airspeed	12
Flying at high mach number	13
Aerobatics	14
Descent	15

CHAPTER 4. Circuit Procedure and Landing

Circuit procedure	1
Landing	2
Instrument approach	3
Flapless landing	4
Crosswind landing	5
Checks after landing	6
Stopping the engine	7

CHAPTER 5. Flying in Manual

Selecting Manual	1
Flying in Manual	2
Landing in Manual	3
Reselecting Power	4

CHAPTER 6. Target Towing

Limitations	1
Take-off	2
Precautions during towing	3
Target release	4

PART IV—EMERGENCY PROCEDURES**CHAPTER 1—Engine Emergency Procedures**

Engine seizure	1
Engine flame-out	2
Relighting	3
Action in the event of fire	4

CHAPTER 2. Airframe Emergency Procedures

Action in the event of hydraulic failure	1
Action in the event of complete electrical failure	2

Chapter 2—continued

	<i>Para.</i>
Combined electric and hydraulic failure	3
Inverter failures	4
Fuel system failures	5
Emergency operation of the tailplane	6
Aileron trim malfunction in Manual	7
Hood jettisoning	8
Drop tank jettisoning	9
Cockpit pressure and oxygen failures	10
Undercarriage and flaps emergency operation	11
Wheelbrakes emergency operation	12

CHAPTER 3. Abandoning and Emergency Landing Procedures

Ejecting from the aircraft	1
Manual separation from the seat	2
Manual bale-out	3
Flame-out landing procedure	4
Landing with the undercarriage in abnormal positions	5
Landing with a burst tyre	6
Ditching	7

PART V—FLIGHT PLANNING DATA**CHAPTER 1. Loading and CG Data**

CG limits	1
Effects of consumption of expendable stores	2
Loading data	3

CHAPTER 2. Operating Data

Pressure error corrections	1
Fuel consumption	2
Take-off distances	3
Landing distances	4
Flight planning tables	5

PART VI—ILLUSTRATIONS

	<i>Fig.</i>
Cockpit—Port side	1
Cockpit—Forward view	2
Cockpit—Starboard side	3

RESTRICTED

INTRODUCTION

1. The Hunter F Mk. 6 is a single-seat, high-speed aircraft powered by a single Avon Mk.203 axial-flow gas turbine engine
2. Four Aden 30-mm. guns are fitted in a removable pre-armed armament package in the underside of the front fuselage. Provision is made for the carriage of bombs and R.P.'s.
3. The fully-powered ailerons and elevator both have Manual reversion : an electric follow-up tail is provided.
4. The cockpit, which is fully pressurised, is equipped with a Mk. 2H or 3H ejection seat.
5. Access to the cockpit is normally gained via a special ladder supplied as ground equipment. A single emergency footstep is located on the port side of the fuselage below the cockpit.

6. The principal dimensions of the aircraft are :—

Length, overall	45ft. 10½in.
Height, overall	13ft. 4in.
Wing span	33ft. 8in.
Tailplane span	11ft. 10in.

7. Modifications

The following modifications are referred to in the text.

Mod. No.	Effect of Modification
9	Inboard pylon, removable parts pre mod 228
375	Flight instruments, inverter circuit revised
378	Mk. 8 gunsight in lieu of Mk. 5
452	Powered controls switching revised
463	Inboard pylon, removable parts post mod 228
502	Powered controls, emergency Manual selection
592	Nose undercarriage, rear door anchorage improved
598	Nose undercarriage, doors etc reinforced
645	Inboard gun chutes revised
646	Outboard gun chutes revised
686	Aileron bypass boosters introduced
687	Elevator bypass boosters introduced
765	Provision for banner target towing
785	Braking parachute introduced
794	I.F.F. Mk. 10 in lieu of Mk. 3
848	Cockpit indicator for brake parachute
873	Auto stabiliser rendered inoperative
907	Tailplane actuator circuit revised
ES 421	Mk. 7A emergency oxygen bottle introduced
ES 491	G stop introduced on ejection seat
ES 1150	Mk. 7G emergency oxygen bottle introduced

RESTRICTED



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

ENGINE
INHIBITED
DO NOT
TURN
PROP