

CHAPTER I WIRELESS INSTALLATION

LIST OF GROUPS

	Group
A. R. I. 5491 (TR. 1934- 1935) airborne relay installation	A
A. R. I. 18049 (V. H. F. Homing) installation	B
A. 1961 (Intercom.) installation	C




Fig. 2 A.R.I. 5491 (TR 1934 -

RESTRICTED

GENERAL INFORMATION

LIST OF CONTENTS

	Para.
Introduction	1
Illustrations	2

REMOVAL AND ASSEMBLY

General	3
Units	4

LIST OF ILLUSTRATIONS

	Fig.
Location of Radio and Radar Controls	1

Introduction

1. This Chapter describes the A.R.I. 5491 (TR1934-1935) airborne relay (V.H.F.), A.R.I.18049 (V.H.F. Homing and A1961 (Intercom) installations in the aircraft). Each group describes the installation concerned, the location of the units, the method of servicing and references to the relevant Air Publications in which more detailed information may be found.

Illustrations

2. Each group also contains illustra-

tions and diagrams which show component layout, equipment location and cable routing.

REMOVAL AND ASSEMBLY

General


3. On every occasion that it is necessary to remove or install an item of equipment, the aircraft must previously be rendered electrically safe. The procedure for this is laid down

in the General Information group of Sect.5, Chap.1 of this Volume.

Units

4. The method of removal of the Units is generally self-evident, and assembly is normally the reverse procedure to removal. However, reference should be made to each group which contains details of special procedures, where these are necessary.

ME 0601-3/1



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.