

CONTROLS
AUTO-PILOT

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4			M.R.	
AUTO-PILOT EQUIPMENT MK. 10									
Spares for :—									
AUTO-PILOT EQUIPMENT UNDER PILOT'S FLOOR (V6954)									
Spares for :—									
6T/204	—	Amplifier, type A				1	—	A	E1/1
	12V6099	Box, junction				1	—	A	E1/2
6T/1672	—	Card, link setting, amplifier unit				1	—	A	E1/3
6T/444	—	Card, link setting, approach coupling				1	—	A	E1/4
6T/445	—	Card, link setting, (height section)				1	—	A	E1/5
6T/1815	—	Card, link setting, coupling unit (Mod. 1426)				1	—	A	E1/6
6T/401	—	Detector, roll error, type A				1	—	A	E1/6
5582	SMITH'S P132/EAP	Mounting, bomb coupling unit				1	—	B	E1/7
5580	SMITH'S P115/EAP	Mounting, amplifier, type No. 2				1	—	B	E1/8
5581	SMITH'S P125/EAP	Mounting, coupling unit, type No. 2				1	—	B	E1/9
6T/302	SMITH'S EAP/5658	Nut, special for gyro unit				1	—	C	
6T/402	—	Tray, roll error detector				1	—	A	E1/10
6T/201	—	Unit, gyro, type A				1	—	A	E1/11
6T/346	—	Unit, coupling approach, type A				1	—	A	E1/12
6T/212	—	Unit, condenser, type No. 2				1	—	A	E1/13
6T/217	—	Unit, coupling bomb type B				1	—	A	E1/14
6T/303	EAP/5659	Washer, special, for gyro unit				1	—	C	
6T/214	SMITH'S XAC.1760	Controller, auto-pilot on pilot's centre, console				1	—	A	E1/15
6T/218	—	Indicator, remote trim on pilot's panel port and starboard				1	—	A	E1/16
6T/232	—	Mounting, for servo motors				3	—	A	E1/17
6T/307	—	Motor, servo, type C, elevator and aileron in power compartment and rudder in bomb bay				3	—	A	E1/18
6T/216	—	Selector, heading on pilot's centre instrument panel				1	—	A	E1/19
6T/213	SMITH'S No.XAC.1750	Switch, unit auto-pilot, on pilot's retractable centre console				1	—	A	E1/20
5CW/5844	DUNLOP ACM.18230/2	Switch, cut-out, emergency disengagement at auto-pilot, part of pilot's control handle				1	—	A	E1/21

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

