

ELECTRICAL INSTALLATION
CONSOLE, PORT, IN CREW'S NACELLE

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4			M.R.	
		CONSOLE AND MOUNTING, PORT, IN CREW'S NACELLE (1V6569)							F4/1
4702	1V6572	Spares for :— BOX, CONTROL, ENGINE STARTING, GROUP				1	—	B	F4/2
	3V5945	Spares for :— COVER, GROUP				1	—		F4/3
5CW/4222	—	Guard, switch				1	—	B	F4/4
	752SS6000	Label, " On "				1	DTD213		
	359SS6001	Label, " Off "				1	DTD213		
	889SS6001	Label, " Ignition Starting ", etc.				1	L59		
4703	4V6572	Switch, cross-over (made from Rotax D10102 with modified knob)				1	—	B	F4/6
5CW/4403	—	Switch, solenoid				1	—	A	F4/7
5CW/4184	—	Switch, toggle				2	—	B	F4/8
	33V6569	BRACKET, MOUNTING, I.L.S. CONTROL UNIT, GROUP				2	—		F4/9
4487	35V6569	BRACKET, C/W CLIP, GROUP (Pre-Mod. 646)				1	—	C	
	5Z9704	Clip, spring, for container				1	—		F4/11
27H/3224	—	Container				1	—	B	F4/12
27H/2316	—	Funnel				1	—	B	F4/13
6B/408	—	Panel, control, compass				1	—	A	F4/14
8040	1V9207	PANEL, CONTROL, BOMB DOORS AND JETTISON, GROUP (Mod. 456)				1	—	B	F4/15
		Spares for :—							
5CW/5765	—	Guard, switch (Mod. 456)				1	—	B	F4/16
5CW/4227	—	Guard, switch				1	—	B	F4/17
	887SS6001	Label, " Emergency Bomb Jettison "				1	L59		
	26SS6002	Label, " Open-Auto-Close "				1	L59		
	29SS6002	Label, " Normal, Emergency Bomb Door Control "				1	L59		
	30SS6002	Label, " Norm "				1	L59		
	453SS6002	Label, " Override "				1	DTD213		
	454SS6002	Label, " Jettison "				1	DTD213		
5CW/936	—	Switch, type B...				1	—	B	F4/18

**ELECTRICAL INSTALLATION
CONSOLE, PORT, IN CREW'S NACELLE**

Ref. No.	Part No.	Description				No. off	Mati. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4			M.R.	
		PANEL, CONTROL, BOMB DOORS AND JETTISON (V6570 & V9207) (Cont'd)							
SCW/4861	—	Switch, single pole, 3-way (Mod. 456) ...				1	—	B	F4/19
	4V6570	SWITCH, GROUP ...							F4/20
		Consisting of :—							
	890SS6001	Label, " Closed " ...				1	L59		
SCW/4199	891SS6001	Label, " Open " ...				1	L59		
	—	Switch, double pole ...				1	—	B	
	BARBER & COLEMAN								
28W/9419448	AGS2035/B	Washer, spring (Mod. 456) ...				8	—	C	
	1T4267	PANEL, LIMIT HEIGHT AND I.L.S. ATTENUATOR, GROUP (Mod. 256) (For Breakdown, See :—Radio and Radar—I.L.S. Installation)				1	—		F4/21
	1V7910	PANEL, SIDE, GROUP (Mod. 258) (For Breakdown, See :—Equipment, Aircraft—Instrument Panels)				1	—		F4/22
	46V6569	PLATE, SWITCH MOUNTING, GROUP				1	—		F4/23
6D/2294MK17E	—	Regulator, oxygen ... (See:—Services-Oxygen)				1	—	A	F4/24
SCW/2451	—	Switch, dimmer, type " R " ...				1	—	A	F4/25
	B.T.H.								
SCW/5992	X2251569/1	Switch, dimmer, 28 step-3 gang ...				1	—	A	F4/26
10L/263	—	Unit, I.L.S. control ...				1	—	A	F4/27
10L/16322	—	Unit, V.H.F. control ...				1	—	A	F4/28

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

