

ELECTRICAL INSTALLATION  
REAR PORTION—FUSELAGE

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of	Plate and Illust'n No.
		1	2	3	4			St. M.R.	
		<b>ELECTRICAL INSTALLATION, REAR PORTION FUSELAGE, R.C.M. (V8635)</b>							
		Spares for:—							
5X/9008	—	Adaptor, lug, 4-way ... ..				5	—	C	
	ULTRA ELEC. A431	Amplifier, temperature control (Mod. 903) ...				4	—	A	
5CZ/6253	—	Block, terminal, 5-way ... ..				1	—	C	
5X/9402803	1V5650	Block, terminal, L.D. ... ..				10	—	C	
26FP/8735	11V8493	Block, terminal ... ..				4	—	C	
	10V6354	Bracket ... ..				1	L72		
	49V6352	Bracket ... ..				1	L72		
	2312V6384	CABLE, No. 2 AMPLIFIER TO TB. 1144 AND TB. 1209, GROUP				1	—		
	2313V6384	CABLE, No. 3 AMPLIFIER TO TB. 1144 AND TB. 1209, GROUP				1	—		
	2315V6384	CABLE, No. 4 AMPLIFIER TO TB. 1145 AND TB. 1209, GROUP				1	—		
	2316V6384	CABLE, No. 2 AMPLIFIER TO TB. 1145 AND TB. 1209, GROUP				1	—		
	2317V6384	CABLE, No. 3 AMPLIFIER TO TB. 1144 TB. 1145 AND TB. 1209, GROUP				1	—		
	2318V6384	CABLE, No. 1 AMPLIFIER TO TB. 1144 AND TB. 1209, GROUP				1	—		
	2319V6384	CABLE, No. 4 AMPLIFIER TO TB. 1144, TB. 1145 AND TB. 1209, GROUP				1	—		
	2539V6384	CABLE, TB. 1209 TO EARTH, GROUP				1	—		
	3008V6384	CABLE, TB. 1209-A TO RELAY 612-CA, GROUP				1	—		
	3009V6384	CABLE, TB. 1209-E TO RELAY 613-CA, GROUP				1	—		
	3145V6384	CABLE, TB. 1295 TO EARTH, GROUP				1	—		
	3204V6384	CABLE, TB. 1323 TO EARTH, GROUP				1	—		
	3208V6384	CABLE, FUSE 1104 TO RELAY 624, GROUP				1	—		
	3209V6384	CABLE, FUSE 1096 TO RELAY 620, GROUP				1	—		
	3215V6384	CABLE, FUSE 1100 TO RELAY 627, GROUP				1	—		
	3237V6384	CABLE, A.C. GROUND SOCKET TO RELAY 656, GROUP				1	—		

ELECTRICAL INSTALLATION  
REAR PORTION—FUSELAGE

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4			M.R.	
	3238V6384	CABLE, A.C. GROUND SOCKET TO 68P, GROUP				1	—		
	3239V6384	CABLE, A.C. GROUND SOCKET TO EARTH, GROUP				1	—		
	3240V6384	CABLE, FUSE 1097 TO RELAY 621, GROUP				1	—		
	3241V6384	CABLE, FUSE 1098 TO RELAY 622, GROUP				1	—		
	3242V6384	CABLE, FUSE 1105 TO RELAY 623, GROUP				1	—		
	3243V6384	CABLE, FUSE 1106 TO RELAY 625, GROUP				1	—		
	3244V6384	CABLE, FUSE 1099 TO RELAY 630, GROUP				1	—		
	3359V6384	CABLE, TB. 1344 TO No. 1 ENGINE THERMO COUPLE, GROUP				1	—		
	3360V6384	CABLE, TB. 1344 TO No. 2 ENGINE THERMO COUPLE, GROUP				1	—		
	3361V6384	CABLE, TB.1345 TO No. 3 ENGINE, GROUP				1	—		
	3362V6384	CABLE, TB.1345 TO No. 4 ENGINE, GROUP				1	—		
	3399V6384	CABLE, TB.1322 TO EARTH, GROUP ...				1	—		
	3499V6384	CABLE, TB. 424 C. TO TB. 1337 C. GROUP				1	—		
	5571V6384	CABLE, No. 1 AMPLIFIER TO TB. 1145 AND TB. 1209, GROUP				1	—		
	5944V6384	CABLE, TB. 663 TO EARTH, GROUP ...				1	—		
	5945V6384	CABLE, TB. 664 TO EARTH, GROUP ...				1	—		
	5946V6384	CABLE, TB. 663 AND TB. 673 TO RUDDER MOTOR, GROUP				1	—		
	5947V6384	CABLE, TB. 664 AND TB. 674 TO RUDDER MOTOR, GROUP				1	—		
	5948V6384	CABLE, TB. 597 TO STARBOARD TAIL NAVIGATION LIGHT, GROUP				1	—		
	5949V6384	CABLE, TB. 597 TO PORT TAIL, NAVIGATION LIGHT, GROUP				1	—		

**ELECTRICAL INSTALLATION**  
**REAR PORTION—FUSELAGE**

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4			M.R.	
	5950V6384	CABLE, No. 3 LAMP TO No. 19 LAMP, GROUP				1	—		
	5951V6384	CABLE, No. 3 LAMP TO No. 19 LAMP, GROUP				1	—		
	5952V6384	CABLE, No. 3 LAMP TO EARTH, GROUP				1	—		
	5955V6384	CABLE, No. 1 ENGINE THERMO COUPLE TO JUNCTION BOX, GROUP				1	—		
	5958V6384	CABLE, No. 2 ENGINE THERMO COUPLE TO JUNCTION BOX, GROUP				1	—		
	5961V6384	CABLE, No. 3 ENGINE THERMO COUPLE TO JUNCTION BOX, GROUP				1	—		
	5964V6384	CABLE, No. 4 ENGINE THERMO COUPLE TO JUNCTION BOX, GROUP				1	—		
	5989V6384	CABLE, TB. 1310 TO No. 1 RESISTOR, GROUP				1	—		
	5990V6384	CABLE, TB. 1310 TO No. 4 RESISTOR, GROUP				1	—		
	5991V6384	CABLE, TB. 1310 TO No. 2 RESISTOR, GROUP				1	—		
	5992V6384	CABLE, TB. 1310 TO No. 3 RESISTOR, GROUP				1	—		
	5993V6384	CABLE, RELAY 612 TO No. 1 RESISTOR, GROUP				1	—		
	5994V6384	CABLE, RELAY 612 TO No. 4 RESISTOR, GROUP				1	—		
	5995V6384	CABLE, RELAY 613 TO No. 2 RESISTOR, GROUP				1	—		
	5996V6384	CABLE, RELAY 613 TO No. 3 RESISTOR, GROUP				1	—		
	5997V6384	CABLE, No. 4 AMPLIFIER TO No. 4 RESISTOR AND RELAY 612, GROUP				1	—		
	5998V6384	CABLE, No. 1 AMPLIFIER TO No. 1 RESISTOR AND RELAY 612, GROUP				1	—		
	5999V6384	CABLE, No. 3 AMPLIFIER TO No. 3 RESISTOR AND RELAY 613, GROUP				1	—		
	6000V6384	CABLE, No. 2 AMPLIFIER TO No. 2 RESISTOR AND RELAY 613, GROUP				1	—		
	6026V6384	CABLE, No. 1 AMPLIFIER TO JUNCTION BOX, GROUP				1	—		
	6027V6384	CABLE, TEST PLUG TO RESISTOR AND JUNCTION BOX, GROUP				1	—		

ELECTRICAL INSTALLATION  
REAR PORTION—FUSELAGE

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of	Plate and Illust'n No.
		1	2	3	4			St. M.R.	
	6028V6384	CABLE, No. 1 SERVO POTENTIOMETER TO JUNCTION BOX, GROUP				1	—		
	6029V6384	CABLE, TEST PLUG TO TB. 1345 RESISTOR AND JUNCTION BOX, GROUP				1	—		
	6030V6384	CABLE, No. 2 AMPLIFIER TO JUNCTION BOX, GROUP				1	—		
	6031V6384	CABLE, TEST PLUG TO EARTH, TB. 1344, RESISTOR AND JUNCTION BOX, GROUP				1	—		
	6032V6384	CABLE, No. 2 SERVO POTENTIOMETER TO JUNCTION BOX, GROUP				1	—		
	6033V6384	CABLE, No. 3 AMPLIFIER TO JUNCTION BOX, GROUP				1	—		
	6034V6384	CABLE, TEST PLUG TO EARTH, TB. 1345 RESISTOR AND JUNCTION BOX, GROUP				1	—		
	6035V6384	CABLE, No. 3 SERVO POTENTIOMETER TO JUNCTION BOX, GROUP				1	—		
	6036V6384	CABLE, No. 4 SERVO POTENTIOMETER TO JUNCTION BOX, GROUP				1	—		
	6037V6384	CABLE, No. 4 AMPLIFIER TO JUNCTION BOX, GROUP				1	—		
	6108V6384	CABLE, No. 1 SERVO POTENTIOMETER TO 26P AND EARTH, GROUP				1	—		
	6109V6384	CABLE, No. 2 SERVO POTENTIOMETER TO 26P AND EARTH, GROUP				1	—		
	6110V6384	CABLE, No. 3 SERVO POTENTIOMETER TO 26P AND EARTH, GROUP				1	—		
	6111V6384	CABLE, No. 4 SERVO POTENTIOMETER TO 26P AND EARTH, GROUP				1	—		
	3351V7909	CABLE, LAMP 20 TO LAMP 21, GROUP				1	—		
	3352V7909	CABLE, LAMP 21 TO LAMP 22, GROUP				1	—		
	3353V7909	CABLE, LAMP 22 TO LAMP 23, GROUP				1	—		
	3355V7909	CABLE, LAMP 19 TO LAMP 20, GROUP				1	—		
	3393V7909	CABLE, TAIL SCANNER TO RELAY 546, GROUP				1	—		
	3394V7909	CABLE, ACTUATOR TO RELAY 546 EARTH, 1 & 2F3394, GROUPS				1	—		

ELECTRICAL INSTALLATION  
REAR PORTION—FUSELAGE

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
					M.R.	
		1 2 3 4				
	3395V7909	CABLE, 44P TO EARTH, GROUP ...	1	—		
	3424V7909	CABLE, TEMPERATURE BULB TO TB. 1337, GROUP	1	—		
	3426V7909	CABLE, 44P TO LOW TEMPERATURE SWITCH, GROUP	1	—		
	3427V7909	CABLE, EARTH TO FREON UNIT, GROUP	1	—		
	3435V7909	CABLE, 44P TO TB. 1336, GROUP...	1	—		
	3442V7909	CABLE, 44P TO FREON METER, GROUP	1	—		
	3579V7909	CABLE, COCKING SWITCH TO DOOR (1) SWITCH, GROUP	1	—		
	3580V7909	CABLE, COCKING SWITCH TO 84P, GROUP	1	—		
	3584V7909	CABLE, No. 2 JETT. ACTUATOR TO 84P AND DOOR SWITCH, GROUP	1	—		
	3587V7909	CABLE, DOOR MICROSWITCH TO 84P, GROUP	1	—		
	3592V7909	CABLE, No. 1 PARACHUTE STREAM ACTUATOR TO TB. 881, GROUP	1	—		
	3593V7909	CABLE, No. 2 PARACHUTE STREAM ACTUATOR TO TB. 882, GROUP	1	—		
	3658V7909	CABLE, TB. 1337 TO EARTH, GROUP	1	—		
	7950V7909	CABLE, TB. 882 TO 84P, GROUP...	1	—		
	7990V7909	CABLE, 44P TO TB. 878, GROUP...	1	—		
	7991V7909	CABLE, 44P TO TB 879, GROUP...	1	—		
	8007V7909	CABLE, 84P TO EARTH, GROUP...	1	—		
	8145V7909	CABLE, RELAY 546 TO EARTH, GROUP	1	—		
	8146V7909	CABLE, TB 881 TO 84P, GROUP...	1	—		
	8147V7909	CABLE, No. 1 JETT. ACTUATOR TO 84P AND DOOR SWITCH, GROUP	1	—		
	8148V7909	CABLE, TB. 1336 TO PRESSURE SWITCH, GROUP	1	—		

ELECTRICAL INSTALLATION  
REAR PORTION—FUSELAGE

Ref. No.	Part No.	Description				No. off	Mati. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4			M.R.	
	8149V7909	CABLE, No. 2 DOOR MICROSWITCH TO 84P, GROUP				1	—		
	8150V7909	CABLE, SHACKLE MICROSWITCH TO 84P, GROUP				1	—		
	8159V7909	CABLE, DOOR MICROSWITCH TO JETT ACTUATOR MICROSWITCH, GROUP				1	—		
	8233V7909	CABLE, COCKING SWITCH TO JETT ACTUATOR SWITCH, GROUP				1	—		
	8243V7909	CABLE, No. 2 PUMP TO 4P, GROUP ...				1	—		
	8244V7909	CABLE, No. 1 PUMP TO 4P, GROUP ...				1	—		
	8248V7909	CABLE, LAMP 23 TO EARTH, GROUP ...				1	—		
	8298V7909	CABLE, No. 1 DOOR MICROSWITCH TO 84P, GROUP				1	—		
	8299V7909	CABLE, JETT ACTUATOR MICROSWITCH TO 84P, GROUP				1	—		
	8430V7909	CABLE, PARACHUTE INDICATOR TO 84P, GROUP				1	—		
	8484V7909	CABLE, 4P TO FREON UNIT, GROUP				1	—		
	AS4806/25	Capping, cable trough 25" long... ..				6	—		
	AS4806/45	Capping, cable trough 45" long ... ..				2	—		
5X/1965	—	Cap, screening ... ..				4	—	C	
	ULTRA ELEC. W383. M2139	Cradle, for amplifier (Mod. 903) ... ..				8	—		
	3SS4657	Clip, cable, 0-22" dia. ... ..				2	Nylon		
11421	4SS4657	Clip, cable, 1/4" dia. ... ..				1	Nylon	C	
	5SS4657	Clip, cable, 0-3" dia. ... ..				2	Nylon		
11428	6SS4657	Clip, cable, 5/8" dia. ... ..				7	Nylon	C	
9598	7SS4657	Clip, cable, 3/4" dia. ... ..				7	Nylon	C	
26FP/14407	8SS4657	Clip, cable, 7/8" dia. ... ..				7	Nylon	C	
26FP/14408	9SS4657	Clip, cable, 1" dia. ... ..				2	Nylon	C	
10686	14SS4657	Clip, cable, 1 1/8" dia. ... ..				8	Nylon	C	
	15SS4657	Clip, cable, 1 1/4" dia. ... ..				6	Nylon		
	AS4580/1	Clip, nylastic ... ..				22	—		
	AS4580/2	Clip, nylastic ... ..				28	—		
	AS4580/3	Clip, nylastic ... ..				38	—		
	AS4580/4	Clip, nylastic ... ..				30	—		
	AS4580/5	Clip, nylastic ... ..				2	—		
5X/9402794	—	Cover, S-way TB. ... ..				1	—	C	
5L/9953271	—	Filament ... ..				2	—	B	
5L/9952276	—	Filament, 24V., 10 watt, for aft navigation lights				2	—	B	
5L/9952604	—	Filament, 24V., 80 watt, for downward identification lamp				1	—	B	

**ELECTRICAL INSTALLATION  
REAR PORTION—FUSELAGE**

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of	Plate and Illust'n No.
		1	2	3	4			St. M.R.	
10H/O590111	—	Fuse, 3 amp.	...	...	...	5	—	C	
10H/O590112	—	Fuse, 5 amp.	...	...	...	24	—	C	
10H/O590113	—	Fuse, 7 amp.	...	...	...	3	—	C	
10H/O590122	—	Fuse, 10 amp.	...	...	...	12	—	C	
10H/O590124	—	Fuse, 20 amp.	...	...	...	9	—	C	
10H/24209	50IIIT	Fuse, 50 amp.	...	...	...	3	—	C	
5CX/446	—	Lamp, cockpit	...	...	...	2	—	B	
5X/9402800	—	Link, commoning, 10 amp., type A	...	...	...	4	—	C	
		<b>MOUNTING, RELAYS AND RESISTORS (1V9383)</b>							
		Spares for:—							
26FP/8735	1V5650	Block, terminal	...	...	...	1	—	C	
	2V9383	<b>BRACKET, MOUNTING, RELAYS AND RESISTOR BANK, GROUP</b>				1	—		
		Spares for:—							
	612SS6003	Label, "612"	...	...	...	1	—		
	613SS6003	Label, "613"	...	...	...	1	—		
	2984V6384	<b>CABLE, RELAY 612 TO RESISTOR, GROUP</b>				1	—		
	2985V6384	<b>CABLE, TB. 1310 TO RESISTOR, GROUP</b>				1	—		
	2987V6384	<b>CABLE, RELAY 612 TO RESISTOR, GROUP</b>				1	—		
	2988V6384	<b>CABLE, TB. 1310 TO RESISTOR, GROUP</b>				1	—		
	2992V6384	<b>CABLE, RELAY 613 TO RESISTOR, GROUP</b>				1	—		
	2993V6384	<b>CABLE, TB. 1310 TO RESISTOR, GROUP</b>				1	—		
	2995V6384	<b>CABLE, RELAY 613 TO RESISTOR, GROUP</b>				1	—		
	2996V6384	<b>CABLE, TB. 1310 TO RESISTOR, GROUP</b>				1	—		
5CW/5500	—	Relay, type 10B, No. 2	...	...	...	2	—	A	
10W/Z113361	—	Resistor, 33 ohms	...	...	...	4	—	C	
5X/6623	15V5650	Socket, single	...	...	...	4	—	C	
		<b>PANEL GROUND A.C. SOCKET (V8636)</b>							
		Spares for:—							
10421	2V8636	<b>DOOR ACCESS GROUP</b>				1	—	C	
		Spares for:—							
28FP/107	FJ4/30	Fastener	...	...	...	2	—	C	
28FP/294	GF4/150	Grommet	...	...	...	2	—	C	
	2dV8636	Hinge (make from AS1878)	...	...	...	1	—		

**ELECTRICAL INSTALLATION  
REAR PORTION—FUSELAGE**

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4			M.R.	
		<b>PANEL, GROUND A.C. SOCKET (V8636)</b> (Contd.)							
	14Z7504	Hook	...	...	...	1	DTD364B		
	3V8636	<b>PANEL, MOUNTING, GROUP</b>				1	—		
	FILMS & EQUIP. LTD. KD/066/56D	Plug, external power, 115-200V.	...	...	...	1	—		
	1V8638	<b>PANEL, 200V. POWER, 68P STARBOARD, GROUP</b>				1	—		
		Spares for:—							
26FP/8735	1V5650	Block, terminal	...	...	...	1	—	C	
10511	3V8638	<b>CONNECTOR, BRAID, L3-T3, GROUP</b>				1	—	C	
10512	4V8638	<b>CONNECTOR, BRAID, L2-T2, GROUP</b>				1	—	C	
10513	5V8638	<b>CONNECTOR, BRAID, L1-T1, GROUP</b>				1	—	C	
10514	1V8633	<b>FUSEBOARD, RED PHASE, GROUP</b>				1	—	B	
10515	2V8633	<b>FUSEBOARD, YELLOW PHASE, GROUP</b>				1	—	B	
10516	3V8633	<b>FUSEBOARD, BLUE PHASE, GROUP</b>				1	—	B	
		Spares for:—							
	6V8633	<b>BUSBAR, LONG, GROUP</b>				1	—		
	7V8633	<b>BUSBAR, SHORT, GROUP</b>				1	—		
	5V8633	Fuseboard	...	...	...	1	—		
7639	14V7357	Fuseholder	...	...	...	8	—	C	
	ENGINEERING & LIGHT. EQUIP. 2444A	Fuseholder	...	...	...	10	—	B	
5CZ/5459	INSULOID LTD. No. 1	Nut, cap	...	...	...	16	—	C	
7643	15V7357	Pedestal, 1-65" long	...	...	...	15	—	C	
7640	16V7357	Pedestal, 2" long	...	...	...	1	—	C	
7641	36V7357	Washer, insulating	...	...	...	10	Nylon	C	
	1V9806	<b>LOOM, CABLE, GROUP</b>				1	—		
	1V8634	<b>PANEL, LESS EQUIPMENT, GROUP</b>				1	—		
5X/6622	14V5650	Socket, double	...	...	...	1	—	C	
5X/6623	15V5650	Socket, single	...	...	...	3	—	C	
5CW/6453	—	Switch, relay, type 9B	...	...	...	1	—	A	
5CW/6283	—	Switch, magnetic, type 6Y, No. 2	...	...	...	2	—	A	

**ELECTRICAL INSTALLATION  
REAR PORTION—FUSELAGE**

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4			M.R.	
	1V8629	<b>PANEL, FUSE, 14P PORT, GROUP</b> ...				1	—		
		Spares for:—							
26FP/8735	1V5650	Block, terminal ... ..				1	—	C	
5CW/	ROTAX D6702/2	Contactor ... ..				3	—	B	
5CZ/5459	ENGINEERING & LIGHT. EQUIP. 2444A	Fuseholder ... ..				18	—	B	
	1V9479	<b>LOOM, CABLE, GROUP</b> ... ..				1	—		
7643	INSULOID LTD. No. 1	Nut, cap ... ..				9	—	C	
	2V8629	<b>PANEL, COMPLETE WITH LABELS, GROUP</b>				1	—		
7640	15V7357	Pedestal, 1-65" long ... ..				9	—	C	
7641	16V7357	Pedestal, 2" long ... ..				9	—	C	
5X/6623	15V5650	Socket, single ... ..				3	—	C	
		<b>PANEL, CONTACTOR 4P IN REAR PORTION (1V10081)</b>							
		Spares for:—							
26FP/8735	1V5650	Block, terminal ... ..				1	—	C	
5CW/6477	ROTAX D6702/2	Contactor ... ..				1	—	A	
5CW/4779 10644	— 6V9472	Contactor ... ..				1	—	A	
	1323V7728	Cover, contactor ... ..				2	—	C	
	1321V7728	Label, " TB. 1323 " ... ..				1	DTD213		
		Label, " TB. 1321 " ... ..				1	DTD213		
	1V10831	<b>LOOM, CABLE, GROUP</b> ... ..				1	—		
	4V10081	<b>PANEL, LESS EQUIPMENT, GROUP</b>				1	—		
		Spares for:							
	623SS6003	Label, " 623 " ... ..				1	L59		
	624SS6003	Label, " 624 " ... ..				1	L59		
	625SS6003	Label, " 625 " ... ..				1	L59		
	626SS6003	Label, " 626 " ... ..				1	L59		
	627SS6003	Label, " 627 " ... ..				1	L59		
	628SS6003	Label, " 628 " ... ..				1	L59		
	630SS6003	Label, " 630 " ... ..				1	L59		
	635SS6003	Label, " 635 " ... ..				1	L59		
5CW/6148	ROTAX F4909/1	Relay, C.B. ... ..				1	—	A	
5CW/6098	PLESSEY 7CZ/105411 1 or 2	Relay ... ..				1	—	A	
5CW/6099	PLESSEY 7CZ/103739/ 1 or 2	Relay ... ..				1	—	A	
5X/6622	14V5650	Socket, double ... ..				3	—	C	
5X/6623	15V5650	Socket, single ... ..				4	—	C	

**ELECTRICAL INSTALLATION**  
**REAR PORTION—FUSELAGE**

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of	Plate and Illust'n No.
		1	2	3	4			St. M.R.	
		<b>PANEL, RELAY, PARACHUTE RELEASE CIRCUIT, 84P, PARACHUTE CONTAINER, REAR SECTION (1V10106)</b>							
		Spares for:—							
26FP/8375	1V5650	Block, terminal	...	...	...	1	—	C	
	1335V7728	Label, "TB. 1335 "	...	...	...	1	DTD213		
	1V9597	LOOM, CABLE, GROUP	...	...	...	1	—		
	2V10106	<b>PANEL, LESS EQUIPMENT, GROUP</b>				1	—		
		Spares for:—							
	649SS6003	Label, " 649 "	...	...	...	1	L59		
	650SS6003	Label, " 650 "	...	...	...	1	L59		
	651SS6003	Label, " 651 "	...	...	...	1	L59		
	652SS6003	Label, " 652 "	...	...	...	1	L59		
	653SS6003	Label, " 653 "	...	...	...	1	L59		
	654SS6003	Label, " 654 "	...	...	...	1	L59		
	655SS6003	Label, " 655 "	...	...	...	1	L59		
	700SS6003	Label, " 700 "	...	...	...	1	L59		
	701SS6003	Label, " 701 "	...	...	...	1	L59		
28M/10739	AGS2013/A11	Nut, anchor, 6 B.A.	...	...	...	2	—	C	
28M/10239	AGS2013/B11	Nut, anchor, 4 B.A.	...	...	...	26	—	C	
	3aV10106	Panel, mounting	...	...	...	1	L72		
	AS2230/202	Rivet	...	...	...	4	—		
28Q/10566	AS2230/303	Rivet, $\frac{1}{16}$ " dia. x $\frac{3}{16}$ " csk. hd.	...	...	...	52	—	C	
28Q/12696	AS2227/202	Rivet, $\frac{1}{16}$ " dia. x $\frac{1}{2}$ " snap hd.	...	...	...	18	—	C	
	PLESSEY								
5CW/6099	7CZ/103739/1	Relay	...	...	...	5	—	A	
	PLESSEY								
5CW/6098	7CZ/105411/1	Relay	...	...	...	4	—	A	
5X/6622	14V5650	Socket, double	...	...	...	2	—	C	
5X/6623	15V5650	Socket, single	...	...	...	1	—	C	
	20V8635	<b>PANEL, MOUNTING, TERMINAL BLOCKS, GROUP</b>				2	—		
		Spares for:—							
26FP/8735	1V5650	Block, terminal	...	...	...	1	—	C	
4247	1V6691	Block, terminal	...	...	...	1	—	C	
5X/6622	14V5650	Socket, double	...	...	...	1	—	C	
6A/4725	—	Potentiometer, servo	...	...	...	4	—	B	
	<b>ELECTRONIC COMPONENTS</b>								
5CZ/5425	22515	Resistor, $\frac{1}{2}$ ohm	...	...	...	4	—	B	
5X/6623	15V5650	Socket, single	...	...	...	31	—	C	
5X/9402799	—	Socket, double	...	...	...	5	—	C	
10173	SS4088	Terminal, earth	...	...	...	2	—	C	

**ELECTRICAL INSTALLATION  
REAR PORTION—FUSELAGE**

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4			M.R.	
<b>TROUGHS, CABLE IN REAR PORTION (V8628)</b>									
	13V8628	<b>BRACKET, MOUNTING, GROUP</b>				<b>4</b>	—	<b>MR</b>	
	37V8628	Cleat, at former 442-5°, port ... ..				1	L72	<b>MR</b>	
	38V8628	Cleat, at former 442-5°, starboard ... ..				1	L72	<b>MR</b>	
	35V8628	Cleat, at former 461-5°, port ... ..				1	L72	<b>MR</b>	
	36V8628	Cleat, at former 461-5°, starboard ... ..				1	L72	<b>MR</b>	
	33V8628	Cleat, at former 472-5°, port ... ..				1	L72	<b>MR</b>	
	34V8628	Cleat, at former 472-5°, starboard ... ..				1	L72	<b>MR</b>	
	27V8628	Cleat, at former 487-5° ... ..				2	L72	<b>MR</b>	
	28V8628	Cleat, at former 487-5° ... ..				2	L72	<b>MR</b>	
	9V8628	Cleat, at former 22-25° ... ..				2	L72	<b>MR</b>	
	10V8628	Cleat, at former 22-25° ... ..				2	L72	<b>MR</b>	
	11V8628	Cleat, at former 46-75°, aft face ... ..				2	L72	<b>MR</b>	
	12V8628	Cleat, at former 46-75°, aft face ... ..				2	L72	<b>MR</b>	
	15V8628	Cleat, at former 46-75°, forward face ... ..				2	L72	<b>MR</b>	
	16V8628	Cleat, at former 46-75°, forward face ... ..				2	L72	<b>MR</b>	
	19V8628	Cleat, at former 71-25°, port ... ..				1	L72	<b>MR</b>	
	20V8628	Cleat, at former 71-25°, starboard ... ..				1	L72	<b>MR</b>	
	22V8628	Cleat, at former 71-25°, port ... ..				1	L72	<b>MR</b>	
	23V8628	Cleat, at former 71-25°, starboard ... ..				1	L72	<b>MR</b>	
	17V8628	Cleat, at former 71-25°, port ... ..				1	L72	<b>MR</b>	
	18V8628	Cleat, at former 71-25°, port ... ..				1	L72	<b>MR</b>	
	21V8628	Cleat, at former 95-75° ... ..				1	L72	<b>MR</b>	
	24V8628	Cleat, at former 95-75° ... ..				1	L72	<b>MR</b>	
	25V8628	Cleat, at former 120-25° ... ..				1	L72	<b>MR</b>	
	26V8628	Cleat, at former 120-25° ... ..				1	L72	<b>MR</b>	
	47SS4620	Trough, cable, 47" long ... ..				2	—		
	27SS4620	Trough, cable, 27" long ... ..				2	—		
	25SS4620	Trough, cable, 25" long ... ..				2	—		
	48SS4620	Trough, cable, 48" long ... ..				1	—		
		(Supplied in 36" lengths, Ref. No. 26DC/5947)							
	35V6356	<b>Washer, tab for temperature control amplifier attachment (Mod. 713)</b>				<b>16</b>	S511		

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

