

**RADIO AND RADAR INSTALLATION
GEE INSTALLATION**

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of St. M.R.	Plate and Illust'n No.
		1	2	3	4				
GEE INSTALLATION (T3411)									
Spares for :—									
10AD/153	—	Adaptor, aerial feeder, type 145				1	—	B	
	3H2586	Aerial				1	—		
10D18543	—	Box, junction, type 359A				1	—	A	
10D/18545	—	Box, junction, type 361A				1	—	A	
	4T3484	Bracket, aerial feeder adaptor				1	L72		
10HA/13912	—	Connector, indicator to waveform generator				1	—	B	
10HA/13914	—	Connector, waveform generator to 11P. plug 436				1	—	B	
10HA/13915	—	Connector, receiver to plug break 199 at rear pressure bulkhead				1	—	B	
10HA/13913	—	Connector, plug break 199 to aerial plug break				1	—	B	
10HA/13916	—	Connector, aerial to plug break				1	—	B	
10HB/1131	—	Connector, indicator to receiver				1	—	B	
10HB/1132	—	Connector, waveform generator to receiver ...				1	—	B	
CRATE, MOUNTING GEE RECEIVER AND WAVEFORM GENERATOR (T3690) (See Radio and Radar installation—Crates and Conduits)									
10V/16045	—	Generator, waveform, type 72				1	—	A	
10Q/16058	—	Indicator, type 26				1	—	A	
10D/16876	—	Receiver, type R3673				1	—	A	

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

