

**RADIO AND RADAR INSTALLATION  
HIGH FREQUENCY INSTALLATION**

Ref. No.	Part No.	Description				No. off	Mati. Spec.	Cl. of	Plate
		1	2	3	4			St.	and
								M.R.	Illust'n
									No.
<b>HIGH FREQUENCY INSTALLATION (T4053)</b>									
Spares for :—									
5X/9402147	—	Block, terminal, no. 398				1	—	C	
5X/9402793	—	Block, terminal, no. 400				1	—	C	
	298T3434	CABLE, TERMINAL BLOCK 400 TO EARTH, GROUP				1	—		
	327T3434	CABLE, TERMINAL BLOCK 400 TO CONTACT BREAKER, GROUP				1	—		
	312T3434	CABLE, TERMINAL BLOCK 400 TO TERMINAL BLOCK 398, GROUP				1	—		
	297T3434	CABLE, TERMINAL BLOCK 400 TO TERMINAL BLOCK 398, GROUP				1	—		
	295T3434	CABLE, SWITCH TO EARTH, GROUP				1	—		
8109	204T3434	CABLE, PLUG 464 TO MORSE KEY AND TO SWITCH, GROUP				1	—	B	
	213T3434	CABLE, MORSE KEY TO EARTH, GRP.				1	—		
10HA/16884	—	Connector, Selector 7003 to control unit 7216				1	—	B	
10HA/16894	—	Connector, junction box 4191 to remote control unit 4189				1	—	B	
10HA/16880	—	Connector, power and radio unit 4192 to terminal blocks 298 and 400				1	—	B	
10HA/16877	—	Connector, power and radio unit 4192 to panel 5J				1	—	B	
10HA/15652	—	Connector, shorting plug 3J				1	—	B	
10HA/16888	—	Connector, power and radio unit 4192 to transmitter T4188				1	—	B	
10HA/16876	—	Connector, power and radio unit 4192 to transmitter T4188				1	—	B	
10HA/15339	—	Connector, control unit 4190 to power and radio unit				1	—	B	
10HA/16886	—	Connector, control unit 4190 to transmitter T4188				1	—	B	
10HA/16887	—	Connector, control unit 4190 to transmitter T4188				1	—	B	
10HA/16879	—	Connector, receiver R4187 to power and radio unit 4192				1	—	B	
10HA/16883	—	Connector, control unit 4190 to selector unit 7003				1	—	B	
10HA/16878	—	Connector, receiver R4187 to terminal block 398				1	—	B	
10HA/16882	—	Connector, control unit 4190 to junction box 4191				1	—	B	
10HA/15346	—	Connector, receiver R4187 to junction box 4191				1	—	B	
10HA/16895	—	Connector, voltage regulator to terminal blocks 398 and 400				1	—	B	
10HA/16885	—	Connector, selector unit 7003 to bulkhead break plug 489				1	—	B	

**RADIO AND RADAR INSTALLATION  
HIGH FREQUENCY INSTALLATION**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
					M.R.	
1	2	3	4			
<b>HIGH FREQUENCY INSTALLATION (T4053) (Cont'd)</b>						
		Spares for :—				
10HA/16890	—	Connector, control unit 4190 to bulkhead break plug 490	1	—	B	
10HA/16891	—	Connector, bulkhead break plug 490 to matching unit	1	—	B	
10HA/16892	—	Connector, tuning unit to bulkhead break plug 489	1	—	B	
10HA/16893	—	Connector, matching unit to tuning unit ...	1	—	B	
<b>MOUNTING, TUNING &amp; MATCHING UNIT (T4298)</b>						
		Spares for :—				
10AJ/73	A.V.A. Ltd. 2306	Absorber, vibration ... ..	4	—	B	
	3T4298	BRIDGE, GROUP ... ..	1	—		
	4T4298	BAR, CLAMPING ... ..	1	—		
8760	416T3434	CABLE, TUNING TO MATCHING UNIT, GROUP	1	—	C	
5996	26T4072	Clip, 1/8" x 7/8" long ... ..	1	—	C	
5997	27T4072	Clip, 1/2" x 3" long ... ..	1	—	C	
5998	2T4298	Feeder, aerial, copper tube, 22g x 1/2" o.d. x 39" long ... ..	1	—	C	
5991	8T4072	FRAME, TROLLEY, GROUP ... ..	1	—	B	
	11T4298	Member, side ... ..	1	—		
	12T4298	Member, side ... ..	1	—		
	23T4298	Piece, distance ... ..	4	L65		
9574	7T4072	Ring, clamping ... ..	1	L16	C	
5992	21T4072	Roller ... ..	4	BSS927	C	
5994	1T4167	TROLLEY, H.F. AERIAL, TUNING UNIT, GROUP	1	—	B	
		Spares for :—				
	7T4167	Lanyard ... ..	1	—		
10AJ/249	—	Tray, mounting, type 9056 ... ..	1	—	A	
10D/19833	—	Unit, aerial tuning, type 7016 ... ..	1	—	A	
10B/16858	—	Unit, matching, type 7949 (Pre-Mod. 626)...	1	—	A	
<b>UNIT, MATCHING (16T4298)</b>						
		Spares for :—				
9476	16aT4298	Adaptor ... ..	5	BSS249	C	
10B/16858	—	Unit, matching ... ..	1	—	A	
5995	20T4072	Washer, special ... ..	4	S1	C	
<b>MOUNTING, H.F. EQUIPMENT S.T.R.18/B2 (T4039)</b>						
		Spares for :—				
10D/19066	—	Box, junction, type 4191 ... ..	1	—	A	
	S.T.C. LTD. L93997/205	Tray, mounting, transmitter—power unit—voltage regulator	1	—		
	S.T.C. LTD. L93997/206	Tray, mounting, receiver—control—selector units	1	—		

**RADIO AND RADAR INSTALLATION  
HIGH FREQUENCY INSTALLATION**

Ref. No.	Part No.	Description				No. off	Matl. Spec.	Cl. of St.	Plate and Illust'n No.
		1	2	3	4			M.R.	
		<b>MOUNTING, H.F. EQUIPMENT S.T.R.18/B2 (T4039) (Cont'd)</b>							
10AR/438	—	Morse-key, type F	...	...	...	1	—	A	
		<b>PANEL, R/T (S2006)</b>							
		Spares for:—							
5CY/2564	—	Breaker-circuit, type A6	...	...	...	1	—	A	
5CY/4520	—	Cover, circuit breaker	...	...	...	1	—	C	
5CW/4179	—	Switch	...	...	...	1	—	A	
50C/6010	—	Regulator, voltage H.F.	...	...	...	1	—	A	
10D/19604	—	Receiver, H.F. type R4187	...	...	...	1	—	A	
8154	10T4072	Socket, mounting...	...	...	...	1	—	C	
9573	1T4071	Socket, P.T.F.E., H.F.	...	...	...	1	—	C	
	10T4298	Strip, braiding, 15" long (Pre-Mod. 626)	...	...	...	1	—		
	17T4298	Strip, braiding, 17" long (Mod. 626)	...	...	...	1	—		
	11T4298	Strip, braiding, 15" long (Pre-Mod. 626)	...	...	...	1	—		
	18T4298	Strip, braiding, 16½" long (Mod. 626)	...	...	...	1	—		
	12T4298	Strip, braiding, 17" long (Pre-Mod. 626)	...	...	...	1	—		
	19T4298	Strip, braiding, 18½" long (Mod. 626)	...	...	...	1	—		
	13T4298	Strip, braiding, 29½" long (Pre-Mod. 626)	...	...	...	1	—		
	20T4298	Strip, braiding, 31½" long (Mod. 626)	...	...	...	1	—		
	14T4298	Strip, braiding, 29½" long (Pre-Mod. 626)	...	...	...	1	—		
	21T4298	Strip, braiding, 31½" long (Mod. 626)	...	...	...	1	—		
9728	15T4298	Strip, braiding, 10½" long	...	...	...	1	—	C	
	31T4298	Strip, braiding, 11" long	...	...	...	1	—		
	22T4298	Stud, special	...	...	...	4	S1		
10D/19065	—	Transmitter, H.F.	...	...	...	1	—	A	
10L/16204	—	Unit, control, type 4189	...	...	...	1	—	A	
10L/293	—	Unit, control, type 7216	...	...	...	1	—	A	
10L/16205	—	Unit, control, type 4190	...	...	...	1	—	A	
10D/19067	—	Unit, power and radio, type 4192	...	...	...	1	—	A	
10D/19248	—	Unit, selector, type 7003	...	...	...	1	—	A	

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

