CONSOLE, PORT, IN CREW'S NACELLE

Ref. No.	Part No.	Description 1 2 3 4	No. off	Matl. Spec.	Cl. of St. M.R.	Plate and Illust'n No.
		CONSOLE, AND MOUNTING, PORT, IN CREW'S NACELLE (1V9145) AND (19V9145) WITH BLUE STEEL				
		Spares for:—				
12059	1V11481	BOX, ENGINE STARTING CONTROL, GROUP (Mod. 1320)	1	—	C	FE1/1
		Spares for:—				
5X/6200370	1V5650	Block, terminal	3	—	C	FE1/2
5L/9959122	PAGE A260	Bulb	4	—	C	FE1/3
5CW/6386317	PAGE B186	Connector, socket	4	—	C	
	13V11481	COVER, BOX, GROUP	1	—		FE1/4
	DOWTY D7617Y	Flap, safety	1	—		FE1/5
	PAGE A223	Guard, switch	1	—		FE1/6
5CZ/4335793	DOWTY C5175Y MK58	Indicator, magnetic	2	—	C	FE1/7
	22V5650	Jumper	4	—	MR	FE1/8
	1V11419	LOOM, CABLE, GROUP	1	—		
	2V11481	PANEL, LESS EQUIPMENT, GROUP	1	—		
		Spares for:—				
	347SS6030	Label, off	1	—		
	348SS6030	Label, air, cross feed	1	—		
	350SS6030	Label, OFF ignition	1	—		
	351SS6030	Label, ON	2	—		
	352SS6030	Label, normal	1	—		
	353SS6030	Label, rapid	1	—		
	436SS6030	Label, rapid start	1	—		
	437SS6030	Label, gyro, hold off	1	—		
	873SS6004	Label, engine start	1	—		
	7V11481	Plate, mounting	1	—		FE1/9
	5V11481	Plate, plug	1	L52		FE1/10
5X/4491487	14V5650	Socket, double	5	—	C	
5X/4491488	15V5650	Socket, single	2	—	C	
	DOWTY DN1260.1A 1.1.B	Switch, single pole	1	—		FE1/11
5CW/4408063	DOWTY DN1260.2N 3.1.B OR	Switch	2	—	C	FE1/12
	DN1260.2N 3.1.C	Switch	2	—		

ELECTRICAL INSTALLATION

CONSOLE, PORT, IN CREW'S NACELLE

Ref. No.	Part No.	Description 1 2 3 4	No. off	Matl. Spec.	Cl.of St. M.R.	Plate and Illust'n No.
		BOX, ENGINE STARTING CONTROL, GROUP (1V11481) (Mod. 1320) (Continued)				
5CW/2007871	C5162Y Mk. 2	Switch, button, type A	1	—	B	FE1/13
5CW/9438526	C5162Y Mk. 3	Switch, button, type B	1	—	B	FE1/14
5CW/4400278	PAGE C180A2	Switch	4	—	B	FE1/15
5CW/6386300	PAGE A258	Sleeve, cable	1	—	C	
5CW/5060	D5194Y	Shroud	1	—	C	FE1/16
22788	34V6569	Case, map	1	—	C	FE1/17
5L/9959118	—	Filament, for indicators, bomb door panel	2	—	C	FE1/18
5CW/4222	ZA2401	Guard, switch, fin folding	1	—	C	
	286SS6065	Label (Mod. 2144)	2	—		
	1V9301	PANEL, BOMB DOOR JETTISON, GROUP, (Pre-Mod. 748)	1	—		
	1V11134	PANEL, BOMB DOOR JETTISON, GROUP (Mod. 1139) WITHOUT BLUE STEEL	1	—		FE1/19
13710	2V11134	PANEL, BOMB DOOR JETTISON, GROUP, (Mod. 1139) WITH BLUE STEEL	1	—	C	
		Spares for:—				
5CW/4405620	HV3710	Cap, helvyn	2	—	C	FE1/20
	9S2042	Cap, helvyn	1	—		
5CW/1039506	ZA2402/1	Guard, switch	2	—	C	FE1/21
11544	7V10911	GUARD, SWITCH, GROUP	1	—		FE1/22
5CX/1050488	PAGE C500/B7	Lamp, indicator, green	1	—	C	FE1/23
5CX/1038082	PAGE C500/C7	Lamp, indicator, amber	1	—	C	FE1/24
	1V9127	LOOM, CABLE, GROUP (Pre-Mod. 748)	1	—		
	1V11112	LOOM, CABLE, GROUP (use only with item 1V11134)	1	—		
	1V11113	LOOM, CABLE, GROUP (use only with item 2V11134)	1	—		
	3V9301	PANEL, LESS LOOM, GROUP (Pre-Mod. 748)	1	—		
11592	1V11133	PANEL, LESS EQUIPMENT, GROUP	1	—	C	
		Spares for:—				
	26SS6002	Label, open auto closed	1	—		
8897	29SS6002	Label, bomb door control	1	—		
8914	30SS6002	Label, normal	1	—		
	283SS6030	Label, bomb release safety lock	1	—		
	453SS6002	Label, override	1	—		
	454SS6002	Label, jettison	1	—		
	887SS6001	Label, emergency bomb jettison	1	—		
5CW/4405757	ROTAX N135531/1	Plate, shroud, fixing	2	—	C	FE1/25
5CW/4405756	ROTAX N135530	Shroud	1	—	C	FE1/26

CONSOLE, PORT, IN CREW'S NACELLE

Ref. No.	Part No.	Description 1 2 3 4	No. off	Matl. Spec.	Cl. of St. M.R.	Plate and Illust'n No.
		PANEL, BOMB DOOR JETTISON, GROUP (1 & 2V11134) (Mod. 1139) (Cont'd.)				
	4V6570	SWITCH, GROUP	1	—		FE1/27
		Spares for:—				
	890SS6001	Label	1	—		
	891SS6001	Label	1	—		
5CW/1047696	—	Switch, double pole	1	—		FE1/28
5CW/936	E.I.7857	Switch, type "B"	1	—	C	FE1/29
5CW/4861	D10002	Switch, single pole	1	—	B	FE1/30
5CW/4400052	N.S.F. LTD. 8373/B3	Switch, two pole	1	—	B	FE1/31
		PANEL, P.F.C., GROUP (V8795)	—	—		FE1/32
		Spares for:—				
	PAGE A259	Filament	21	—		
5CX/1050488	PAGE C500/B/7	Indicator, lamp (Mod. 1928)	1	—	C	FE1/33
	1V13051	LOOM, CABLE, GROUP (Mod. 1928)	1	—		
7624	1V9030	PANEL, LESS EQUIPMENT, GROUP	1	—	C	
		Spares for:—				
7625	5V8796	COVER, INSPECTION, GROUP	1	—	C	FE1/34
		Spares for:—				
28FP/9488815	A4/30	Fastener, Dzus	9	—	C	
28FP/9430915	GA4/250	Grommet, Dzus	9	—	C	
	11V8795	Panel, top	1	L72		FE1/35
7626	5V8795	SHROUD, CENTRE SWITCH, GROUP	1	—	C	FE1/36
7627	6V8795	SHROUD, BOTTOM, SWITCH, GROUP	4	—	C	FE1/37
22787	13V8795	SHROUD, SWITCH, GROUP (Mod. 1073)	1	—	C	FE1/38
5CW/5060	D5194Y	Shroud, re-set switches	4	—	C	FE1/39
1510074	WINGROVE & ROGERS TS1/06	Strip, terminal	2	—	C	
1510075	WINGROVE & ROGERS TS1/08	Strip, terminal	2	—	C	
5CW/1095293	PAGE C181/C5	Switch	7	—	B	FE1/40
5CW/4400277	PAGE C750/C5	Switch	10	—	B	FE1/41
5CW/9348526	C5162Y Mk. 3	Switch, type "B"	3	—	B	FE1/42
5CW/6362390	C5162Y Mk. 4	Switch, type "C"	1	—	B	FE1/43

ELECTRICAL INSTALLATION

CONSOLE, PORT, IN CREW'S NACELLE

Ref. No.	Part No.	Description (1 2 3 4)	No. off	Matl. Spec.	Cl. of St. M.R.	Plate and Illust'n No.
		PANEL, P.F.C., GROUP (V8795) (Cont'd.)				
5CW/7223	N.S.F. LTD. 8820/B106	Switch, yaw damper	1	—	C	FE1/44
5CW/4400297	PAGE C675/C5	Switch	1	—	C	FE1/45
5CW/4400253	PAGE C180/E5	Switch	2	—	C	FE1/46
5CW/4408124	DOWTY D.2	Switch (Mod. 1928)	1	—	B	FE1/47
	1V13167	PANEL, ABANDON AIRCRAFT SWITCH, GROUP (Mod. 2007)	—	—		FE1/48
		Spares for:—				
	9S2042	Cap, helvyn	1	—		
	285SS6065	Label (Mod. 2144)	1	—		
	1V13637	LOOM, CABLE, GROUP	1	—		
	2SS4624	Plate, shroud fixing	1	—		FE1/49
	2SS4625	Plate, shroud fixing	1	—		FE1/50
5CW/4405758	ROTAX N136930	Shroud	1	—	C	FE1/51
5CW/1047692	—	Switch	1	—	C	FE1/52
5CW/4408132	DOWTY E.1	Switch	1	—	B	FE1/53
5CW/4400085	N.S.F. LTD. 8295/B109	Switch	1	—	C	FE1/54
5CW/4408108	DOWTY AS10512B-3	Switch	1	—	B	FE1/55
5CW/4408124	DOWTY D.2	Switch	1	—	B	FE1/56
	15V9145	Plate, cover	1	—		FE1/57
	12V9145	Plate, mounting	1	—		FE1/58
	13V9145	Plate, mounting	1	—		FE1/59
6D/2383	OP5290	Regulator, oxygen, Mk. 21B (Mod. 1387)	1	—	A	FE1/60
6D/2671	OP6450	Regulator, oxygen, Mk. 17F (Mod. 1961 S.O.O.)	1	—	A	FE1/61

CONSOLE, PORT, IN CREW'S NACELLE

Ref. No.	Part No.	Description (1 2 3 4)	No. off	Matl. Spec.	Cl. of St. M.R.	Plate and Illust'n No.
	PLESSEY					
5CZ/4337688	7CZ/107201	Selector, temperature	1	—	B	FE1/62
5CW/4405514	—	Switch, dimmer	1	—	C	FE1/63
	THORN					
5CW/4705121	01-0063	Switch, push button (Mod. 1900)	1	—	B	FE1/64
	A.E.I.					
5CW/4405072	X2251569/1	Switch, dimmer, with Blue Steel	1	—	A	FE1/65
5CW/1047695	—	Switch, fin folding, with Blue Steel	1	—	C	FE1/66
5CW/4408104	A-6	Switch, RT/1 tone (Mod. 2057)	1	—	B	FE1/67
10L/1948320	1T6654	Unit, T.F.R. control (Mods. 2057, 2375) (Pre Mod. 2422)	1	—	A	FE1/68
5CW/4408715	2TL1-70N	Switch (Honeywell)	1	—	B	
	8T6654	Unit, T.F.R. control (Mod. 2422)	1	—		
5CW/6344143	126-2TOTC	Switch (Dowty)	1	—	B	
10L/16320	—	Unit, intercom, control, type 7681 (Pre-Mod. 2304)	1	—	A	FE1/69
10L/16856	—	Unit, intercom, control, type 7681B (Mod. 2304)	1	—	A	
10L/16720	—	Unit, Mk. VII, radio altimeter, type 16095	1	—	A	FE1/70
5821-99-942-8543	—	Unit, U.H.F. control (Mod. 2007)	1	—	A	FE1/71
	NORMALAIR					
27KD/4631315	513390	Valve, manual control	1	—	B	FE1/72

ELECTRICAL INSTALLATION

SUMMARY OF STANDARD ITEMS

Ref. No.	Part No.	Description 1 2 3 4	No. off	Matl. Spec.	Cl. of St. M.R.	Plate and Illust'n No.

ELECTRICAL INSTALLATION

SUMMARY OF STANDARD ITEMS

Ref. No.	Part No.	Description 1	2	3	4	No. off	Matl. Spec.	Cl. of St. M.R.	Plate and Illust'n No.
28D	9436920	15							
28D	1007979	8							
28D	1214865	4							
28D	1214880	8							
28D	9128739	36							
28D	8337	23							
28D	1218385	4							
28D	9142406	2							
28D	1212793	2							
28D	1213052	2							
28FP	9488815	9							
28FP	9430915	9							
28M	9403517	10							
28M	10286	56							
28M	10287	19							
28M	10288	15							
28M	10281	2							
28M	10328	2							
28M	9435559	6							
28M	9434253	18							
28M	9434251	8							
28M	9435067	1							
28M	9434252	16							
28M	12421	1							
28M	13774	4							
28S	9419453	8							
28S	1200049	4							
28S	9419437	8							
28S	1006960	4							
28S	1200080	1							
28S	1012450	4							
28S	1017747	6							
28S	1008327	7							
28S	1200055	4							
28S	1200053	1							
28S	1011783	3							
28S	1214163	16							
28S	9994993	4							
28W	9419446	84							
28W	9419401	35							
28W	9419454	5							
28W	9419465	11							
28W	9419402	15							
28W	9419473	3							
28W	9419486	4							
28W	9419186	4							
28W	9419185	4							
28W	120641	44							

PLATE No FE I
ISSUE 2



ELECTRICAL INSTALLATION
CONSOLE, PORT, IN CREW'S NACELLE

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.