


CANBERRA T Mk 17

PILOT'S NOTES

THIS DOCUMENT IS THE PROPERTY OF HER BRITANNIC MAJESTY'S GOVERNMENT, and is issued for the information of such persons only as need to know its contents in the course of their official duties. Any person finding this document should hand it in to a British forces unit or to a police station for its safe return to the MINISTRY OF DEFENCE, D MOD Sy, LONDON SW1A 2HB, with particulars of how and where found. THE UNAUTHORISED RETENTION OR DESTRUCTION OF THE DOCUMENT IS AN OFFENCE UNDER THE OFFICIAL SECRETS ACTS OF 1911-1989. (When released to persons outside Government service, this document is issued on a personal basis and the recipient to whom it is entrusted in confidence, within the provisions of the Official Secrets Acts of 1911-1989, is personally responsible for its safe custody and for seeing that its contents are disclosed only to authorised persons).

BY COMMAND OF THE DEFENCE COUNCIL



Prepared by Royal Air Force Handling Squadron

UK RESTRICTED

Intentionally Blank

UK RESTRICTED

UK RESTRICTED

Ministry of Defence (Air)
July 1986

Reprint of
AP101B-0417-15

CANBERRA T Mk 17

REPRINT OF PILOT'S NOTES

1. This reprint of the Pilot's Notes for the Canberra T Mk 17 (to AL 13 standard) should be placed in an anonymous 4-ring, A5 size binder. The 3-ring binder used for the previous issue is now obsolete, and the reprint has therefore been carried out in A5 size.
2. All copies of the previous issue (November 1967) of the Pilot's Notes are now obsolete and should be destroyed.
3. The major change introduced into the reprint under AL 13 is the addition of Supplement No 1. This Supplement describes the changes to the ECM, navigation, and communications equipment brought about by the incorporation of Mod 5466.

UK RESTRICTED

AMENDMENT RECORD SHEET

Record the incorporation of each Amendment List in the publication by signing against the appropriate AL No and inserting the date of incorporation.

AL No	Amended By	Date
1 to 13	Already incorporated	
14	<i>[Signature]</i>	11/1/89
15	<i>[Signature]</i>	7/8/90
16	<i>[Signature]</i>	8/2/92
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		
32		
33		
34		

Intentionally Blank

NOTES TO USERS

1 This book is divided by marker cards, as follows:

Preliminary Matter

Part 1 Description and
Management of
Systems

Part 2 Limitations

Part 3 Handling

Part 4 Emergencies

Part 5 Illustrations

Where applicable, the parts are divided into chapters as listed on the marker cards. A Folio Sheet reference number is at the top left-hand corner of each sheet, each Part starting at FS1.

2 The limitations quoted in Part 2 are mandatory and are not to be exceeded except in an emergency. Instructions containing the word 'must' are also mandatory.

3 This book and its associated Flight Reference Cards aim to provide the best operating instructions and advice currently available. Although they provide guidance for most eventualities, they are not substitutes for sound judgement and good airmanship; moreover, they assume an adequate knowledge of the pertinent volumes of AP 3456 Series (Flying). Furthermore, circumstances might require aircrew to depart from or modify the prescribed procedure, and drills. Consequently the Pilot's Notes and Flight Reference Cards should not be regarded as documents which are to be adhered to inflexibly at all times — other than as explained in para 2 above.

4 Amendment Lists will be issued as necessary and each amendment list instruction sheet will state the main purpose of the amendment and will include a list of modifications covered in the text. New or amended matter of importance will be indicated by symbols in the text thus: ◀ ▶ or thus ◆....◆ to show the extent of amended text and thus ▶▶ or thus ◆◆ to show where text has been deleted. The number of the amendment list by which a sheet was initially issued, or re-issued, will appear at the bottom of the front pages and any amendment marks on either page forming a sheet will relate to that amendment. However, when a new chapter is issued with an amendment list or an existing chapter is completely revised, the fact will be indicated

within the heading of the chapter and the amendment marks will not appear on the pages.

5 The following conventions are observed throughout this Book:

- (a) The actual markings on controls are indicated in the text by capital letters.
- (b) Unless otherwise stated all airspeeds, mach numbers, accelerations, temperatures and altitudes quoted are indicated values.
- (c) **WARNINGS** are inserted only when the serious consequences of not following a certain procedure might otherwise be overlooked.
- (d) Information which requires to be emphasised is printed in italics.
- (e) Notes are inserted to clarify the reason for a procedure or to give information which, while not essential to the understanding of the subject, is useful to the reader.
- (f) Cross references given in the text refer to chapters in the same part unless otherwise stated.

Modification numbers are only referred to in the text when it is necessary to differentiate between pre- and post-mod states. For ease of reference, a list of the modifications mentioned in the text is included in these preliminary pages, with a cross reference to the location in the text of the modification details.


7 This book is complementary to the Flight Reference Cards (AP 101B-0417-14) and the Operating Data Manual (AP 101B-0417-16) for the aircraft.

IMPORTANT

Comments and suggestions should be forwarded to the Officer Commanding, Royal Air Force, Handling Squadron, Boscombe Down, Salisbury, SP4 0JF.

FS1A

CANBERRA T MK.17



RESTRICTED

CAMERA T.M.T.



Intentionally Blank

REVERSE SIDE OF EACH PAGE

REVERSE SIDE OF EACH PAGE

LIST OF FOLIO SHEETS

This list shows all the Folio Sheets which should be present in these Pilot's Notes at AL16. Sheets which should have manuscript amendments are marked with an asterisk.

<i>Folio Sheet</i>	<i>Issued by</i>	<i>Folio Sheet</i>	<i>Issued by</i>
Preliminaries		Part 1 Chapter 4	
Title Page	AL15 ✓	FS15	AL4 ✓
Amendment Record Sheet	AL13 ✓	FS16	AL6 ✓
AIL Record	AL14 ✓	FS17	AL4 ✓
FS1	AL12 ✓	Part 1 Chapter 5	
FS1A	Initial Issue ✓	FS18	AL4 ✓
FS1B	AL16 ✓	FS19	AL14 ✓
FS2	AL14 ✓	FS20	AL14 ✓
FS3	AL14 ✓	FS20A	AL14 ✓
FS4	AL16 ✓	Part 1 Chapter 6	
FS5	AL16 ✓	FS21	AL9 ✓
FS6	AL16 ✓	FS21A	AL16 ✓
Part 1		Part 1 Chapter 7	
Marker Card	AL4 ✓	FS22	AL16
Part 1 Chapter 1		FS23	AL16
FS1	AL16 ✓	FS24	AL16
FS2	AL16	FS25	AL16
FS3	AL16	FS26	AL16
FS4	AL16	FS27	AL16
FS5	AL16	FS27A	AL16
FS6	AL16	FS27B	AL16 ✓
FS7	AL16	Part 1 Chapter 8	
FS7A	AL16 ✓	FS28	AL15 ✓
Part 1 Chapter 2		FS29	AL16 ✓
FS8	AL9 ✓	FS30	AL16 ✓
FS9	Initial Issue ✓	FS30A	AL15 ✓
FS10	AL9 ✓	Part 1 Chapter 9	
FS11	AL16 ✓	FS31	AL9 ✓
Part 1 Chapter 3		FS32	AL9 ✓
FS12	AL16 ✓	FS33	AL9 ✓
FS13	AL16 ✓	Part 1 Chapter 10	
FS14	AL4 ✓	FS34	AL5 ✓
		FS35	AL2 ✓

(continued)

List of Folio Sheets - *continued*

<i>Folio Sheet</i>	<i>Issued by</i>	<i>Folio Sheet</i>	<i>Issued by</i>
Part 1 Chapter 11		Part 3 Chapter 3	
FS36	AL11 ✓	FS10	AL16 ✓
FS37	AL9 ✓	FS11	AL16 ✓
FS38	AL6 ✓	FS12	AL16 ✓
FS38A	AL6 ✓	FS13	AL16 ✓
FS39	AL9 ✓	FS14	AL16 ✓
FS40	AL6 ✓		
FS41	AL7 ✓	Part 3 Chapter 4	
FS42	AL7 ✓	FS15	AL16 ✓
		FS16	AL16 ✓
Part 2		FS17	AL16 ✓
Marker card	Initial issue ✓		
Part 2 Chapter 1		Part 4	
FS1	AL16 ✓	Marker card	Initial issue ✓
FS1A	AL16 ✓		
Part 2 Chapter 2		Part 4 Chapter 1	
FS2	AL16 ✓	FS1	AL16 ✓
FS3	AL16 ✓	FS2	AL16 ✓
Part 2 Chapter 3		Part 5	
FS4	AL14 ✓	Marker card	Initial Issue ✓
FS5	AL14 ✓		
FS6	AL14 ✓	Part 5 Chapter 1	
FS7	AL14 ✓	FS1	AL16 ✓
FS8	AL14 ✓	FS2	AL6 ✓
Part 3		FS3	AL4 ✓
Marker card	Initial Issue ✓	FS4	AL4 ✓
Part 3 Chapter 1		FS5	AL4 ✓
FS1	AL5 ✓	FS6	AL4 ✓
FS2	AL6 ✓	FS7	AL4 ✓
		FS8	AL4 ✓
Part 3 Chapter 2		Supplement 1	
FS3	AL12 ✓	Marker card	AL14 ✓
FS3A	AL14 ✓	FS1	AL16 ✓
FS3B	AL14 ✓	FS2	AL16 ✓
FS4	AL6 ✓	FS3	AL14 ✓
FS5	AL6 ✓	FS4	AL14 ✓
FS6	AL6 ✓	FS5	AL15 ✓
FS7	AL9 ✓	FS6	AL14 ✓
FS8	AL6 ✓	FS7	AL14 ✓
FS8A	AL6 ✓	FS8	AL16 ✓
FS9	AL4 ✓	FS9	AL13 ✓
FS9A	AL14 ✓	FS10	AL13 ✓
		FS11	AL13 ✓

INTRODUCTION**1 General**

The Canberra T Mk 17 is employed in the electronic countermeasures (ECM) training role. It is powered by two Avon Mk 102 engines. Three crew (pilot, navigator and air electronics officer (AEO)) are normally carried.

2 Electrical System

(a) DC is provided by two 28-volt, engine-driven generators and four 12-volt batteries connected in series-parallel. If the main DC supplies fail an emergency battery supplies various emergency circuits.

(b) AC is supplied by two turbo-alternators driven by air from the compressor on each engine. Either alternator can supply the entire AC load required in flight, but provision is made for alternative supplies to instruments by two inverters. A dedicated inverter supplies Omega. ◆

3 Fuel System

Fuel is carried in three fuselage tanks and may be augmented by wing tip tanks. The forward and centre tanks are self-sealing and the rear tank is a crash-proof collapsible bag. Fuel can be fed, via LP pumps, from the fuselage tanks to either engine.

4 Hydraulic System

Hydraulic power, produced by two hydraulic pumps, one on each engine accessory gearbox, is used to operate the undercarriage, flaps, airbrakes, wheelbrakes and air inlet scoops. A handpump circuit is provided for emergency lowering of the undercarriage and to charge the wheelbrakes accumulator if the main system fails.

5 Engines

The Avon Mk 102 engine is a turbo-jet having a twelve-stage axial-flow compressor directly coupled to a two-stage turbine. It gives approximately 6500 lb static thrust at sea level. The throttle controls incorporate a fast idling stop, set at approximately 4800 RPM, below which the turbo-alternators come off line.

6 Aircraft Controls

The rudder, aileron and elevator controls are conventional and manually operated. The variable incidence tailplane, rudder trim tab and the aileron bias system, are electrically operated. To provide adequate clearance for the pilot during ejection, a snatch unit pulls the control column forward automatically when the pilot ejects. Selectors for undercarriage, flaps, airbrakes and air inlet scoops are electrically actuated.

7 Flight Instruments, Radio and Radar

Flight instruments are conventional. A combined omnibearing selector and deviation indicator combines the functions of a VOR bearing selector and ILS deviation indicator. Radio and radar equipment includes UHF, VHF, HF, VOR/ILS, radio compass (ADF), radio altimeter, Tacan, IFF/SSR and Green Satin (pre-Mod 5466) and, post-Mod 5466, an Omega system. A radio mixing system, incorporating intercom, is provided. ♦♦ Communications recording equipment is installed. ♦

8 Equipment Compartments

(a) Three bays for various items of aircraft equipment are aft of the cabin pressure bulkhead. The upper equipment bay is above the nose undercarriage well and access to it is via a removable hatch on top of the fuselage. The left and right equipment bays are on either side of the nose undercarriage well, with access doors in the fuselage wall.

(b) Additional equipment may be carried in two packs in the pack bay in the lower centre fuselage and in wing tip pods which may be fitted in lieu of wing tip tanks.

9 Fire Protection

Fire detection, warning and extinguishing systems are fitted for each engine and for the pack bay. Two non-toxic hand-operated fire extinguishers are in the cabin. Provision is made for automatic operation of the engine and pack bay extinguishers in crash conditions.

10 Doors and Emergency Exits

The entrance door, pilot's canopy and navigator's hatch are all jettisonable and serve as emergency exits. The navigator's hatch is automatically jettisoned when either the navigator or AEO eject.

11 Ejection Seats

All three crew are provided with ejection seats incorporating single lever ejection. The pilot ejects through the canopy.

12 Oxygen System

Oxygen is carried in bottles in the upper equipment bay and supplied to crew members via Mk 17 pressure demand regulators. An emergency oxygen bottle is fixed to each ejection seat.

13 Air Conditioning and Pressurization

The air conditioning and pressurization systems are supplied by air bleed from the engine compressors. The temperature is controlled by a mixing valve by means of which a proportion of hot air from the compressors is passed through coolers in the inner plane leading edge and a cold air unit in the left inner plane.

14 Location of Controls and Indicators

(a) The location of controls and indicators is referred to in these notes by reference to the following panels and compartments.

Left wall)	
Take-off panel)	
Left console)	
Left front panel)	
Flight instrument panel)	Cockpit
Engine instrument panel)	
Engine starter panel)	
Right instrument panel)	
Coaming panel)	
Electrical control panel (front face))	

Left wall)	
Navigator's instrument panel)	
Coaming panel)	Cabin
AEO's control unit panel)	
Right wall)	
Electric control panel (rear face))	

(b) The location of controls is illustrated in Part 5.



MODIFICATIONS MENTIONED IN THE TEXT

<i>Mod No</i>	<i>Title</i>	<i>Location</i>		
		<i>Part</i>	<i>Chapter</i>	<i>Para</i>
◆ 5466	Introduces new ECM equipment plus Omega	Supplement 1		
5541	Introduces pack bay overheat warning light	1	8	13
SEM				
175	Introduces sealed lead-acid batteries	1	1	4
185	Introduces high intensity strobe lights	1	8	7 ◆

ASSOCIATED AIR PUBLICATIONS

Canberra T Mk 17 Flight Reference Cards	...	AP 101B-0417-14
Canberra T Mk 17 Operating Data Manual	...	AP 101B-0417-16
Canberra T Mk 17 Aircraft, General and Technical Information	AP 101B-0417-1A & 1B
Avon Mk 1 Aero-Engine and Avon Mk 10201 Engine Change Units	AP 102C-1522-1

LEADING PARTICULARS

Principal Dimensions

	<i>Feet Inches</i>	
Span without wing-tip tanks/pods	64	0
Span with wing-tip tanks/pods	65	6
Length overall	67	4
Height to top of fin	15	7
Height to top of canopy (unladen aircraft)	8	8

Undercarriage

Mainwheel Units (two)

Type	Single wheel, inwards retracting
Shock absorber	Oleo pneumatic
Nitrogen pressure	Refer to AP 101B- ⁰⁴⁰⁰ / _{0400A} -5A2
Fluid	OM-15 (NATO H-515)
Capacity	12 pints
Tyre pressure	Refer to AP 101B- ⁰⁴⁰⁰ / _{0400A} -5A2
Brakes	
Pressure at reducing valve	2500 ⁺⁰ / ₋₁₀₀ PSI
Pressure at brakes	1500 ⁺¹⁵⁰ / ₀ PSI

Nosewheel Unit

Type	Twin wheel, non-steerable castoring, rearward retracting
Shock absorber	Levered suspension, liquid spring
Pressure (wheels off ground)	1500 PSI
Fluid	OM-15 (NATO H-515)
Capacity	1.5 pints
Tyre pressure	Refer to AP 101B- ⁰⁴⁰⁰ / _{0400A} -5A2

Hydraulic System

Fluid	OM-15 (NATO H-515)
Capacity of system	31 pints (approximately)
Capacity of tank	2 gallons
Pumps (two)	Lockheed Mk 9
Accumulator charging gas	Nitrogen
Thermal relief valve setting	3450 ±100 PSI (See Part 1, Chap 3)

LIST OF ABBREVIATIONS USED IN THE TEXT

AC	Alternating current	KVA	Kilovolt amps
ACU	Acceleration control unit	KW	Kilowatt
ADF	Automatic direction finding	lb	Pound
AEO	Air electronics officer	LP	Low pressure
AGL	Above ground level		
AUW	All up weight	M	Mach number
BCF	Bromochlorodifluoromethane	MEP	Main electrical panel ◆
BPC	Barometric pressure control	MHz	Megahertz
BTB	Busbar tie circuit breaker	MI	Magnetic indicator
BTDU	Breach time delay unit	NMBS	Normal maximum braking speed
BTRU	Barostatic time release unit	OBS	Omit-bearing selector
CG	Centre of gravity	ODM	Operating Data Manual
CHAG	Chain arresting gear	PSI	Pounds per square inch
DAGS	Drift angle groundspeed	PVAG	Purpose use arresting gear
DC	Direct current	QRF	Quick release fitting
DV	Direct vision	RHAG	Rotary hydraulic arresting gear
ECM	Electronics countermeasures	RMI	Radio magnetic indicator
EMBS	Emergency maximum braking speed	RPM	Revolutions per minute
EOA	Engine out allowance	SSR	Secondary surveillance radar
FFFD	Fault free fire detection	TAS	True airspeed
FRC	Flight Reference Cards	T/R	Transmitter/receiver
GPB	Ground power circuit breaker	UHF	Ultra high frequency
GPI	Ground position indicator	UVPSU	Undervolt and phase sequencing unit
HF	High frequency	VCH	Visual committal height
HP	High pressure	VHF	Very high frequency
HT	High tension	VLF	Very low frequency
IAS	Indicated airspeed	VOR	VHF omni-directional radio
IPF	Identification friend or foe	VSC	Variation setting control range
ILS	Instrument landing system		
JPT	Jet pipe temperature		

LIST OF ABBREVIATIONS USED IN THE TEXT

AC	Alternating current	kVA	Kilovolt amps
ACU	Acceleration control unit	kW	Kilowatt
ADF	Automatic direction finding		
AEO	Air electronics officer	lb	Pound
AGL	Above ground level	LP	Low pressure
AUW	All up weight		
		M	Mach number
BCF	Bromochlorodifluoromethane	◆ MEP	Main electrical panel ◆
BPC	Barometric pressure control	MHz	Megahertz
BTB	Busbar tie circuit breaker	MI	Magnetic indicator
BTDU	Breech time delay unit		
BTRU	Barostatic time release unit	NMBS	Normal maximum braking speed
CG	Centre of gravity	OBS	Omni-bearing selector
CHAG	Chain arresting gear	ODM	Operating Data Manual
DAGS	Drift angle groundspeed	PSI	Pounds per square inch
DC	Direct current	PUAG	Purpose use arresting gear
DV	Direct vision		
		QRF	Quick release fitting
ECM	Electronics countermeasures		
ECP	Electrical control panel	RHAG	Rotary hydraulic arresting gear
EMBS	Emergency maximum braking speed	RMI	Radio magnetic indicator
		RPM	Revolutions per minute
EOA	Engine out allowance		
		SSR	Secondary surveillance radar
FFFD	Fault free fire detection		
FRC	Flight Reference Cards	TAS	True airspeed
		T/R	Transmitter/receiver
GPB	Ground power circuit breaker		
GPI	Ground position indicator	UHF	Ultra high frequency
		UVPSU	Undervolt and phase sequencing unit
HF	High frequency		
HP	High pressure	VCH	Visual committal height
HT	High tension	VHF	Very high frequency
Hz	Hertz (cycles per second)	VLF	Very low frequency
		VOR	VHF omni-directional radio range
IAS	Indicated airspeed	VSC	Variation setting control
IFF	Identification friend or foe		
ILS	Instrument landing system		
JPT	Jet pipe temperature		

UK RESTRICTED

Intentionally Blank

UK RESTRICTED

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

