

Chapter 64

TIME DELAY SWITCH, ROTAX, TYPE D 8443

LIST OF CONTENTS

	Para.		Para.
Introduction...	1	Installation ...	11
Description ...	2	Servicing ...	13
Switch mechanism ...	3	Coil resistance test...	15
Operation ...	6	Voltage drop tests ...	16
Sequence of operation ...	10	Insulation resistance tests ...	17

LIST OF ILLUSTRATIONS

	Fig.		Fig.
D 8443, time delay switch ...	1	Winding mechanism ...	3
Switch assembly ...	2	Diagram of internal connections ...	4

LEADING PARTICULARS

Operating voltage ...	16-29-V. d.c.
Winding current (average) ...	0.5 ampere at 24-V.
Contact voltage ...	28-V. d.c.
Contact rating...	8 amperes
Operational temperature range ...	-40 deg. C. to +70 deg. C.
Operational ceiling ...	60,000 ft.
Length ...	4.625 in.
Width ...	3.750 in.
Height ...	3.322 in.
Weight ...	1 lb. 12 oz.

Introduction

1. The Rotax D 8443 time delay switch is designed so that, when operated, it automatically controls the making and breaking of one pair of normally open contacts and one pair of normally closed contacts in a predetermined sequence, re-setting itself at the end of a 36 second cycle for further action when required. It is primarily for use in starter control circuits for gas turbine engines, where the sequence is initiated by depressing the starter push switch in the pilot's or engineer's position.

DESCRIPTION

2. The switch mechanism is housed within two light alloy castings which are




Fig. 1. D 8443 time delay switch

(A.L.81, Sep. 56)

RESTRICTED

bolted together to form a waterproof and flameproof housing (*fig. 1*). The leads are brought out through a waterproof multiple grommet in the base casting. The switch mechanism is secured to the base casting by three hexagon head bolts which locate in three mounting pillars.

Switch mechanism

3. An auto-relay and a winding mechanism are fixed to the underside of a mounting plate situated just below the rim of the base casting and the circuit contacts, as well as their operating cams (*para. 4*) are mounted above the plate. The auto-relay operates a ratchet which winds a pre-loaded clock type main spring. The main spring drives a camshaft (concentric with the ratchet wheel), an escapement mechanism accurately controlling its speed of rotation.

4. The camshaft is carried by two frictional bearings and projects through the mounting plate from the winder side where it carries the main spring, ratchet wheel and escapement drive wheel, to the contact side (*para. 3*) where it carries two moulded cams. The cams

operate the two moving contacts via contact followers.

5. The primary and main supply contacts of the auto-relay circuit (*fig. 4*) are mounted on the winder side of the mounting plate (*fig. 3*). They are operated by metal cams, the primary contacts cam rotating with the camshaft and the main supply contacts cam rotating with the ratchet wheel. The two moving contacts are interlocked so that, when the main supply contacts have closed, the primary contacts open, but, when the main supply contacts open the primary contacts remain open until allowed to close by their cam.

Operation

6. The diagram of internal connections (*fig. 4*) shows the contacts in their normal positions: i.e., with the switch set before commencing a cycle. Contacts 1 and 2 are those for controlling the external circuit, making contact between leads 3B(+) (28-V d.c.) and 4C. and between 2M(P) (28-V d.c.) and 5D respectively for predetermined periods during the 36 second cycle (*para. 10*).




Fig. 2. Switch assembly

RESTRICTED

Contacts 3 are the interrupter contacts of the auto-relay, being operated by a pin attached to the armature, and contacts 4 and 5 are the primary contacts and main supply contacts. Lead 1A(—) is the negative of the auto-relay.

7. The cycle is commenced by connecting 28-V d.c. to the lead 2M(P) (i.e., by depressing the starter button) thereby making a circuit through the auto-relay coil via the interrupter contacts. The interrupter contacts open immediately the armature is attracted to the relay core so that the coil is again de-energized, the armature returns to normal under the action of its return spring and the interrupter contacts again close. In this way, the armature is made to vibrate.

8. The auto-relay armature has a driving spring which engages the teeth of the ratchet wheel and moves the wheel round one tooth per vibration. The main-spring commences unwinding immediately the ratchet wheel begins to wind but, owing to the restriction of the escapement mechanism, the winding is much quicker than the unwinding and a winding period of 3 seconds is sufficient for a total cycle of 36 seconds.

9. After about five vibrations of the armature, the ratchet wheel has rotated

sufficiently for its cam to close the main supply contacts and open the primary contacts. The reason for this arrangement is that the primary contacts can be connected to supply via the overspeed relay (when the unit is used as part of a starter panel) so that the cycle can commence only after the starter has begun to rotate. When the cycle has begun, however, the main supply contacts connect the auto-relay directly to supply so that the full cycle is completed and the switch reset in the event of the overspeed relay dropping out before the end of the winding period. After the winding period of approximately 3 seconds the main supply contacts open. The primary contacts close in preparation for a fresh cycle just before the camshaft comes to rest.

Sequence of operation

10. The sequence of operation of the circuit contacts (1 and 2) is as follows:—

Contacts 2 close	10 ± 0.5 seconds after commencement of cycle
Contacts 1 open	13 ± 1 seconds after commencement of cycle
Contacts 2 open	30 ± 1 seconds after commencement of cycle
Contacts 1 close	34 ± 1 seconds after commencement of cycle
The time of cycle is 36 ± 1 seconds.	




Fig. 3. Winding mechanism

(A.L.81, Sep. 56)

INSTALLATION

11. There are four stub mounting feet on the underside of the base casting each tapped 4 B.A. for attachment to a mounting plate. The fixing centres form a rectangle 2.000 in. by 3.500 in.

12. When supplied from Stores, the switch has five free leads, 12 in. in length, for connection to its associated equipment. Each lead is identified by a sleeve bearing its full designation.

SERVICING

13. Make an external visual inspection to ensure that the switch has not sustained damage and that it is in good condition. Ensure that the castings are firmly clamped together, that the grommet has not perished and that the insulation of the leads is sound.

14. Ensure that the switch functions satisfactorily in its circuit and then apply the following tests, for which all the leads should be disconnected from associated equipment.

Coil resistance tests

15. The resistance of the auto-relay coil, measured between leads 1A(—) and 2M(P) and corrected to 20 deg. C. ambient temperature, should be 6.7 ohm. \pm 0.5 ohm.

Voltage drop tests

16. Measure the potential drop across leads 3B(+) and 4C (contacts 1) and between leads 2M(P) and 5D (contacts 2) with 8 amperes flowing. The potential drop in each test should not exceed 0.2 volt.

Note . . .

Since contacts 2 are normally open it will be necessary to test them while a cycle is in progress. They are closed for a period of approximately 20 seconds per cycle.

Insulation resistance tests

17. Measure the insulation resistance between the following points, using a 250-V. insulation resistance tester. A reading of at least 50,000 ohm should be obtained in each test.

- (1) Lead 1A(—) and lead 3B(+)
- (2) Lead 1A(—) and lead 5D
- (3) Lead 4C and lead 5D
- (4) Frame and all leads

Note . . .

The value of insulation resistance given above applies to units being tested under normal workshop conditions. Due allowance should be made for climatic conditions of the locality and of the aircraft servicing area or dispersal point where tests are being applied. In particularly damp climates, the readings may be low enough to give apparently sufficient reason for rejection and in these instances discretion should be exercised.




Fig. 4. Diagram of internal connections

RESTRICTED