

## INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.
<b>ARMAMENT</b>		
Not Applicable ... ..	—	B.1/2
<b>CONTROLS</b>		
Aileron Controls in Wing, Port ... ..	E.A1.45.13	DA.1
Aileron Controls in Wing, Starboard ... ..	E.A1.45.14	DB.1
Engine Controls in Nose Fuselage ... ..	E.G4.47.103	CB.1
Engine Controls in Wing, Port ... ..	E.B6.47.293	CC.1
Engine Controls in Wing, Starboard ... ..	E.B6.47.295	CD.1
Engine Controls in Centre Fuselage ... ..	E.B6.47.297	CA.1
Flap Operating Mechanism, Port... ..	E.A1.20.701	DC.1
Flap Operating Mechanism, Starboard ... ..	E.A1.20.700	DD.1
Flying Controls in Centre Fuselage ... ..	E.A3.45.379	DE.1
Flying Controls in Cockpit ... ..	E.G4.45.103	DF.1
Flying Controls in Rear Fuselage ... ..	E.A3.45.385	DG.1
<b>ELECTRICAL, INSTALLATION</b>		
Electrical Equipment in Centre Fuselage ... ..	E.G4.81.2807	EA.1
Electrical Equipment in Front Fuselage ... ..	E.G4.81.2805	EB.1
Electrical Equipment in Rear Fuselage ... ..	E.G4.81.2811	EC.1
Electrical Equipment in Wing, Port ... ..	E.G4.81.2809	ED.1
Electrical Equipment in Wing, Starboard ... ..	E.G4.81.2810	EE.1
Electrical Equipment in Port Wing Tip ... ..	E.A1.81.19	ED.15
Electrical Equipment in Starboard Wing Tip ... ..	E.A1.81.20	EE.17
<b>EQUIPMENT, AIRCRAFT</b>		
Equipment in Pressure Cabin ... ..	E.G4.80.1301	G.1
Equipment in Rear Fuselage ... ..	E.G4.83.7	H.1
<b>EQUIPMENT, ANCILLARY</b>		
Ground Equipment ... ..	E.A1.88.2	F.1
<b>EQUIPMENT, SPECIAL ROLE</b>		
Not Applicable ... ..	—	HA.1/2
<b>FUSELAGE</b>		
Centre Portion ... ..	E.G4.00.507	JA.1
Centre Structure (Pre-Mod. 1018) ... ..	E.G4.11.211	JA.5
Centre Structure (Post-Mod. 1018) ... ..	E.G4.11.201	JA.21
Front Portion ... ..	E.G4.10.505	JB.1
Front Structure ... ..	E.G4.00.701	JB.5
Rear Fuselage and Tail Unit ... ..	E.G4.00.509	JC.1
<b>MAINPLANE</b>		
Aileron, Port ... ..	E.A9.24.1	LB.1
Aileron, Port (Mod. 5100) ... ..	E.A9.24.165	LB.1
Aileron, Port (Mod. 5119) ... ..	E.A9.24.171	LB.1
Aileron, Starboard ... ..	E.A9.24.2	MB.1
Aileron, Starboard (Mod. 5100) ... ..	E.A9.24.166	MB.1
Aileron, Starboard (Mod. 5119) ... ..	E.A9.24.172	MB.1
Inner Flap, Port ... ..	E.A9.25.3	LD.1
Inner Flap, Starboard ... ..	E.A9.25.4	MD.1
Outer Flap, Port ... ..	E.A9.25.1	LD.1
Outer Flap, Starboard ... ..	E.A9.25.2	MD.1
Undercarriage Door C/W mechanism, Port ... ..	E.A1.20.10733	LC.1
Undercarriage Door C/W mechanism, Starboard ... ..	E.A1.20.10734	MC.1
Wing, Port ... ..	E.G4.00.511	LA.1
Wing, Starboard ... ..	E.G4.00.512	MA.1
Wing Structure, Port ... ..	E.G4.20.701	LF.1
Wing Structure, Starboard ... ..	E.G4.20.702	MF.1
Wing Tip, Port ... ..	E.A1.00.67	LE.1
Wing Tip, Starboard ... ..	E.A1.00.68	ME.1

## INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.
<b>MISCELLANEOUS, ATTACHMENTS</b>		
Centre Fuselage to Rear Fuselage ... ..	E.B6.00.25	N.1
Controls to Rudder and Elevator ... ..	E.A1.00.63	N.1
Drop Tank to Wing, Port ... ..	E.A1.00.81	N.1
Drop Tank to Wing, Starboard ... ..	E.A1.00.82	N.1
Fin to Fuselage ... ..	E.A1.00.55	N.1
Front Fuselage to Centre Fuselage ... ..	E.A1.00.23	N.2
Plate, Tailplane, Sealing ... ..	E.B6.00.61	N.2
Rear Fairing to Fuselage ... ..	E.A1.00.59	N.2
Rudder to Fin and Fuselage ... ..	E.A1.00.57	N.2
Tailplane to Rear Fuselage ... ..	E.B6.00.53	N.2
Wing to Fuselage Port (Pre-Mod. 1018) ... ..	E.A1.00.21	N.3
Wing to Fuselage, Port (Mod. 1018) ... ..	E.B6.00.21	N.4
Wing to Fuselage, Starboard (Pre-Mod. 1018) ... ..	E.A1.00.22	N.4
Wing to Fuselage, Starboard (Mod. 1018) ... ..	E.B6.00.22	N.5
<b>POWER, INSTALLATION</b>		
Engine Cowling, Port ... ..	E.A6.50.493	PA.1
Engine Cowling, Starboard ... ..	E.A6.50.495	PA.7
Engine Mountings and Attachments, Port ... ..	E.A1.51.1	PB.1
Engine Mountings and Attachments, Starboard ... ..	E.A1.51.2	PB.3
RA7, Engine Installation, Port ... ..	E.A6.00.13	PC.1
RA7, Engine Installation, Starboard ... ..	E.A6.00.14	PC.5
<b>RADAR, INSTALLATION</b>		
A.R.I.5610, Rebecca 4, Installation (Pre-Mod. 5195) ... ..	E.G4.82.1071	QA.1
A.R.I.5885, Blue Silk, Installation ... ..	E.G4.82.1057	QB.1
A.R.I.18107/3, Tacan, Installation ... ..	E.G4.82.1009	QD.1
A.R.I.23134, I.F.F./S.S.R., Installation ... ..	E.G4.82.1005	QC.1
<b>RADIO, INSTALLATION</b>		
A.R.I.18011, I.L.S., Installation ... ..	E.G4.82.1051	RE.1
A.R.I.23021, A.D.F., Installation ... ..	E.G4.82.1043	RA.1
A.R.I.23076, Decca Mk. 1, Installation ... ..	E.G4.82.1011	RB.1
A.R.I.23090/9, Collins H.F., Installation ... ..	E.G4.82.1007	RD.1
A.R.I.23099, Ultra UA60, Installation ... ..	E.G4.82.1013	RF.1
A.R.I.23143/1 & 23143/4, Twin P.T.R.175, Installation ... ..	E.G4.82.1003	RG.1
Equipment and Wiring, Radio Relay Box ... ..	E.G4.82.1087	RC.1
Zero Reader, Installation ... ..	E.G4.82.1067	RH.1

## INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.
<b>SERVICES</b>		
Pages Not Issued ... ..	—	SA
Air Ventilated Suit System ... ..	E.G4.75.425	SB.1
Cabin Pressure System in Centre Fuselage ... ..	E.B6.75.5	SC.1
Cabin Pressure and Cold Air Pipes, Across Bomb Bay ... ..	E.G4.75.17	SC.5/6
Cabin Pressure System in Front Fuselage ... ..	E.G4.75.403	SD.1
Cabin Pressure and Cold Air System in Port Wing ... ..	E.B6.75.825	SE.1
Cabin Pressure and Cold Air System in Starboard Wing ... ..	E.B6.75.781	SF.1
Cold Air Supply to Pilot ... ..	E.A3.74.21	SG.1
Demister System in Centre Fuselage (Camera Window) ... ..	E.G4.75.427	SH.1
Demister System in Front Fuselage ... ..	E.G4.76.101	SH.5
Equipment in Inner Wing Leading Edge, Port ... ..	E.B6.00.363	SI.1
Equipment in Inner Wing Leading Edge, Starboard ... ..	E.G4.00.513	SJ.1
Fire Protection System in Fuselage ... ..	E.G4.60.1	SK.1
Fire Protection System in Port Wing ... ..	E.A1.60.3	SL.1
Fire Protection System in Starboard Wing ... ..	E.A1.60.4	SM.1
Fuel System in Centre Fuselage ... ..	E.A3.57.67	SN.1
Fuel System in Rear Fuselage ... ..	E.B7.57.293	SN.19
Fuel System in Port Wing ... ..	E.B6.57.17	SO.1
Fuel System in Port Inner Wing ... ..	E.B6.57.71	SO.7
Fuel System in Port Wing Tip ... ..	E.A1.57.257	SO.9
Fuel System in Starboard Wing ... ..	E.B6.57.18	SP.1
Fuel System in Starboard Inner Wing ... ..	E.B6.57.151	SP.7
Fuel System in Starboard Wing Tip ... ..	E.A1.57.258	SP.9
Pages Not Issued ... ..	—	SQ.
Hydraulic Equipment in Centre Fuselage ... ..	E.B6.73.5	SR.1
Hydraulic Equipment in Front Fuselage ... ..	E.G4.73.103	SS.1
Hydraulic Equipment in Port Wing ... ..	E.G4.73.7	ST.1
Hydraulic Equipment in Starboard Wing ... ..	E.G4.73.8	SU.1
Hydraulic Equipment in Inner Wing Leading Edge, Port ... ..	E.B6.73.395	SV.1
Hydraulic Equipment in Inner Wing Leading Edge, Starboard ... ..	E.B6.73.397	SW.1
Oxygen System ... ..	E.G4.71.301	SX.1
Pitot and Static Pipes in Front Fuselage ... ..	E.G4.80.1317	SY.3
Pitot and Static Pipes in Centre Fuselage ... ..	E.B6.80.169	SY.7
Pitot and Static Pipes in Port Main Plane ... ..	E.A3.80.659	SY.9
Static Pipe Run in Cabin Pressure System ... ..	E.G4.75.421	SY.1
<b>TAIL UNIT</b>		
Rudder, c/w Tab (Pre-Mod. 5043) ... ..	E.A3.33.1	TA.1
Rudder, c/w Tab (Mod. 5043) ... ..	E.A3.00.5397	TA.1
Tailplane and Elevators ... ..	E.A9.00.21	TB.1

INDEX OF ASSEMBLIES

Assembly	Drawing No.	Page No.
<b>TANKS</b>		
Fuselage Fuel Tanks ... ..	—	UB.1
Jettison Wing Fuel Tank, Port (Pre-Mod. 2395) ... ..	E.A3.00.505	UA.1
Jettison Wing Fuel Tank, Port (Mod. 2395) ... ..	E.B6.00.347	UA.3
Jettison Wing Fuel Tank, Starboard (Pre-Mod. 2395) ... ..	E.A3.00.506	UA.5
Jettison Wing Fuel Tank, Starboard (Mod. 2395) ... ..	E.B6.00.348	UA.5
300 Gallon Fuel Tank, Installation ... ..	E.A3.56.453	UD.1
Tank, Integral, Port ... ..	E.A1.20.3505	UC.1
Tank, Integral, Starboard ... ..	E.A1.20.3506	UC.11
<b>UNDERCARRIAGE</b>		
Main Undercarriage, Port ... ..	E.A1.40.727	WA.1
Main Undercarriage, Starboard ... ..	E.A1.40.728	WB.1
Nosewheel ... ..	E.A9.40.1	WC.1

CANBERRA E Mk. 15

Page 5

# INDEX OF ASSEMBLIES ILLUSTRATIONS

Assembly	Drawing No.	Page No.
<b>CONTROLS, ENGINE</b>		
Front Fuselage ... ..	...	C.1
Throttle Box ... ..	...	C.2
Centre Fuselage ... ..	...	C.3
Port Main Plane ... ..	...	C.4
Starboard Main Plane ... ..	...	C.5
<b>CONTROLS, FLYING</b>		
Front Fuselage ... ..	...	D.1
Pilot's Control Column ... ..	...	D.2
Pilot's Rudder Pedals ... ..	...	D.3
Control Levers ... ..	...	D.4
Centre Fuselage ... ..	...	D.5
Rear Fuselage ... ..	...	D.6
Aileron, Main Plane ... ..	...	D.7
Flap Operating Mechanism ... ..	...	D.8
<b>EQUIPMENT, AIRCRAFT</b>		
Map Readers Seat ... ..	...	GH.1
Map Readers Seat Detail ... ..	...	GH.2
Pilot's Sunblind ... ..	...	GH.3
Seating in Pressure Cabin ... ..	...	GH.4
<b>FUSELAGE</b>		
Front Fuselage, Nose Undercarriage Doors ... ..	...	JB.1
<b>MAIN PLANES</b>		
Undercarriage Doors ... ..	...	LM.1
Alterations to Mainplane Structure ... ..	...	LM.2
<b>POWER PLANT</b>		
Engine Mountings ... ..	...	P.1
Engine Cowling Attachments ... ..	...	P.2

# INDEX OF ASSEMBLIES ILLUSTRATIONS

Assembly	Drawing No.	Page No.
<b>SERVICES</b>		
Air Ventilated Suit ... ..	...	S.1
Box, Gear, Port Main Plane ... ..	...	S.2
Box, Gear, Starboard Main Plane ... ..	...	S.3
Cabin Pressure, Front Fuselage ... ..	...	S.4
Cabin, Pressure, Front Fuselage Detail ... ..	...	S.5
Cabin Pressure, Centre Fuselage ... ..	...	S.6
Cabin Pressure, Port Main Plane ... ..	...	S.7
Cabin Pressure, Starboard Main Plane ... ..	...	S.8
Cold Air to Pilot ... ..	...	S.9
Demisting System ... ..	...	S.10
Demisting System, Detail ... ..	...	S.11
Fuel System, Centre Fuselage ... ..	...	S.12
NOT ISSUED ... ..	...	S.13
Hydraulic System, Front Fuselage ... ..	...	S.14
Hydraulic System, Nose Wheel ... ..	...	S.15
Hydraulic System, Reservoir ... ..	...	S.16
Hydraulic System, Centre Fuselage ... ..	...	S.17
Hydraulic System, Centre Fuselage Detail ... ..	...	S.18
Hydraulic System, Main Planes ... ..	...	S.19
Hydraulic System, Main Planes Detail ... ..	...	S.20
Oxygen System, Pressure Cabin ... ..	...	S.21
Oxygen System, Pressure Bulkhead to Frame 23 ... ..	...	S.22
Oxygen System, Main Planes ... ..	...	S.23
<b>TANKS</b>		
Jettisonable Wing Tanks ... ..	...	U.1
300 Gallon Tank ... ..	...	U.2
300 Gallon Tank Detail ... ..	...	U.3
Integral Tanks ... ..	...	U.4
Integral Tanks Detail ... ..	...	U.5
<b>UNDERCARRIAGE</b>		
Main Undercarriage ... ..	...	W.1
Main Undercarriage Oleo Leg ... ..	...	W.2
Main Undercarriage Side Stay ... ..	...	W.3
Nose Wheel ... ..	...	W.4
Nose Wheel ... ..	...	W.5
Nose Wheel ... ..	...	W.6