AP101B-1000-5A3 F Chapter 2 (1st Edition)

## FUNCTIONAL CHECKS AND TESTS

## List of Contents

SP No	List of Contents Title
100 101 102 103 104 105 106 107 <b>108</b>	ARI 23232 - Radar Altimeter - Test. Not Allocated. UHF Standby - Installation. Intercom - Installation. (External). Telebrief - Installation. UHF and UHF Homing (PTR 177) Installation. ILS - Installation. U/VHF and VHF Homing (PTR 175) - Installation. ARI 23329/1, Sonar Locator Beacon - Self Test.
299	Not Allocated.

