

AMENDMENT RECORD SHEET

To record the incorporation of an Amendment List in this publication, sign against the appropriate A.L. No. and insert the date of incorporation.

A.L. No.	Amended by	Date
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13	R. BENTLEY	7/9/76
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		

A.L. No.	Amended by	Date
25		
26		
27		
28		
29		
30		
31		
32		
33		
34	R. BENTLEY	7/9/76
35		
36		
37		
38		
39		
40		
41		
42		
43	G. Tasker	10 4 78
44	J. Grace	16.6.80
45	C. Davies	30 3 80
46	M. Anderson	29 8 85
47		22 7 86
48		2/2/89

A.L. No.	Amended by	Date
49		14/5/91
50		14/5/92
51		
52		
53		
54		
55		
56		
57		
58		
59		
60		
61		
62		
63		
64		
65		
66		
67		
68		
69		
70		
71		
72		

RESTRICTED

(Continued overleaf)

A.L. No.	Amended by	Date
73		
74		
75		
76		
77		
78		
79		
80		
81		
82		
83		
84		
85		
86		
87		
88		
89		
90		
91		
92		
93		
94		
95		
96		
97		
98		
99		
100		

A.L. No.	Amended by	Date
101		
102		
103		
104		
105		
106		
107		
108		
109		
110		
111		
112		
113		
114		
115		
116		
117		
118		
119		
120		
121		
122		
123		
124		
125		
126		
127		
128		

A.L. No.	Amended by	Date
129		
130		
131		
132		
133		
134		
135		
136		
137		
138		
139		
140		
141		
142		
143		
144		
145		
146		
147		
148		
149		
150		
151		
152		
153		
154		
155		
156		

RESTRICTED

RESTRICTED

*A.P. 101B-1309-1B
A.L. 44, Sept. 79*

LETHAL WARNING

- ❖ 1. Modern aircraft have many equipments, e.g. assisted escape systems, explosive release units, high energy igniter units etc. which, if operated inadvertently or worked on without due care, can cause loss of life and/or damage to the aircraft. Before anyone enters a cockpit or starts work on an aircraft the individual himself is responsible for ensuring that:
 - 1.1 All safety devices are correctly fitted.
 - 1.2. No units or switches with which the individual is not fully conversant are touched.
- 2. A lethal voltage is considered as one being equal to or in excess of 30 V a.c. (r.m.s.) or 50 V d.c..
- 3. Detailed safety precautions for each type of aircraft will be found in the relevant aircraft Servicing Schedules. ►

RESTRICTED

NOTE TO READERS

The subject matter of this publication may be affected by subsequent orders, Servicing Schedules, or by Volume 2 leaflets. If possible, Amendment Lists are issued to correct this publication accordingly but it is not always practicable to do so. When an Order, Servicing Schedule or leaflet contradicts any portion of this publication, the Order, Servicing Schedule or leaflet is to be taken as the overriding authority.

The inclusion of references to Items of equipment does not constitute authority for demanding the items.

Each leaf bears the date of issue and, when applicable, the number of the Amendment List with which it was issued. New or amended technical information on new leaves which are inserted when this publication is amended will be indicated by solid triangles positioned in the text. Triangles are placed thus ◀ ... ▶ to show the extent of amended text and thus ▶ ◀ to show where text has been deleted. With effect from amendment 46, all changes will be indicated by triangles positioned thus: ▶ ... ◀ . The triangles merely denote a change and not a mark of emphasis. When a Section or Chapter is issued in a completely revised form, the triangles will not appear.

The reference number of this publication was altered from A P 4347L & S, Vol.1, Book 2, to A P 101B-1309-1B in October 1967. No general revision of page captions has been undertaken, but the code number appears in place of the earlier A P reference on new or amended leaves subsequent to that date.

Many of the A P references in each individual Group "Table of Equipment and Air Publication reference" throughout this Air Publication will no longer apply due to the new A P coding system. A general revision of these Tables will be made in due course.

LIST OF ASSOCIATED AIR PUBLICATIONS

	A P
Aircraft tanks	106B-0200 Series
Aircraft wheels, tyres and brakes	104 Series
Avon Mk. 113 and 122 ECU	102C Series
Armament equipment	110 Series
▶ ARI 18124/1 UHF installation (pre Mod 1480)	116D-0133-1
ARI 23301/80 main UHF installation (Mod 1480)	116D-0154-1 ◀
ARI 23057 standby UHF installation	116D-0110-16
ARI 23288 (AD 120) VHF installation	116D-0150-1

ARI 18012 Tele-briefing installation	116N-0301-1
ARI 5848 IFF installation	114J-0800 Series
ARI 23134/3 IFF/SSR (Mod 1319)	114J-0101-16
ARI 18107 Tacan installation	116B-0304-1
Cameras and accessories	112P-0400 Series
Combustion starters for aero engines	103D-0100 Series
Ejection seats and escape equipment	109B Series
Electrical equipment manuals	113 Series
Fuel system components	103B-0001 Series
Fire extinguishers	107E-0400 Series
Gyro gun sights	112E-0001-1
High energy ignition units	113L-0100 Series
Hydraulic equipment, Dowty	105B Series
Hydraulic servicing trolley	105T-0100 Series
Instrument manuals	112 Series
Parachute and safety equipment	108 Series
Powered flying control units, Fairey	105D Series
Pressure cabin testing, servicing trolley	119F-0700 Series
Pressurizing and air conditioning equipment	107B-0001 Series
Pressure fuelling equipment	106D-0001 Series
Practice bomb carriers	110G-0100 Series
Rotol accessory gearboxes and drives	103C Series
Undercarriage equipment, Dowty	104 Series

LIST OF ASSOCIATED AIR DIAGRAMMS

	A D
Cabin pressure, heating and ventilation	5671
Ejection seat, danger points and rescue procedure	6038
Ejection seat safety precautions	5037
Ejection gun servicing	5731
Electrical installation	7598L & Z
ECU removal and installation	6655E
Flying controls and lubrication	6445C
Fuel system	6389
Hood jettison	5673
Hydraulic system (2 sheets)	6390
Jet efflux	6655X
Lubrication	5678
Radio installation	7598R & Y
Undercarriage adjustments	6014

LAYOUT OF A P 101B-1309-1B (Formerly A P 4347L & S, Vol.1, Book 2)

HUNTER GA MK. 11 AND PR MK. 11 AIRCRAFT

A P 101B-1309 Code No.		A P 4347L & S Reference
A P 101B-1309-1A	Aircraft servicing manual (Airframe, power unit and mechanical systems)	Vol 1, Book 1
A P 101B-1309-1B	Aircraft servicing manual (Electrical, instrument and radio installations)	Vol 1, Book 2
A P 101B-1309-2	General orders and modifications	Vol 2
A P 101B-1309-3A	Schedule of spare parts	Vol 3, Part 1
A P 101B-1309-3B	Appendix A (Schedule of airframe equipment)	Vol 3, Part 2
A P 101B-1309-3C	Scales of Unit equipment	Vol 3, Part 3
A P 101B-1309-4	Progressive servicing	Vol 4
A P 101B-1309-5	Periodic servicing	Vol 5
A P 101B-1309-6A	Repair and reconditioning instructions	Vol 6
A P 101B-1309-12	Ground handling notes	G.H.N.
A P 101B-1309-15	Pilot's notes	P.N.
A P 101B-1309-16	Operating data	O.D.



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.