

INDEX OF ASSEMBLIES

| Assembly | Drawing No. | Page No. |
|---|-------------|----------|
| AIRCRAFT | | |
| General Arrangement | EA3.00.1 | A.1 |
| CONTROLS ENGINE | | |
| Engine Controls in Centre Fuselage | EA1.47.125 | CA.1 |
| Engine Controls in Nose Fuselage | EA1.47.5 | CB.1 |
| Engine Controls in Wing, Port | EA3.47.21 | CC.1 |
| Engine Controls in Wing, Starboard | | CD.1 |
| CONTROLS FLYING | | |
| Aileron Controls in Wing, Port | EA1.45.13 | DD.1 |
| Aileron Controls in Wing, Starboard | EA1.45.14 | DE.1 |
| Flap Operating Mechanism, Port | EA1.20.701 | DF.1 |
| Flap Operating Mechanism, Starboard | EA1.20.700 | DG.1 |
| Flying Controls In Centre Fuselage | EA3.45.379 | DB.1 |
| Flying Controls in Cockpit | EA3.45.3 | DA.1 |
| Flying Controls in Rear Fuselage | EA3.45.385 | DC.1 |
| ELECTRICAL INSTALLATION | | |
| Electrical Equipment in Centre Fuselage | EA3.81.7 | EA.1 |
| Electrical Equipment in Front Fuselage (Pre-Mod. 4937) | EA3.81.5 | EB.1 |
| (Pre-Mod.5204) | | |
| Electrical Equipment in Front Fuselage (Mod. 4937 - S.O.O.) ... | EA3.81.7005 | EB.1 |
| Electrical Equipment in Front Fuselage (Mod. 5204 - S.O.O.) ... | EA3.81.8005 | EB.1 |
| Electrical Equipment in Rear Fuselage | EA1.81.8 | EC.1 |
| Electrical Equipment in Wing, Port | EA3.81.9 | ED.1 |
| Electrical Equipment in Wing, Starboard | EA3.81.10 | ED.1 |
| EQUIPMENT GROUND | | |
| Ground Equipment | EA1.88.2 | FA.1 |
| Transportation Equipment | | FA.7 |
| EQUIPMENT AIRCRAFT | | |
| Equipment in Pressure Cabin (Mod. 4937) (Pre-Mod. 5204) ... | EA3.80.7001 | GA.1 |
| Equipment in Pressure Cabin (Mod. 5204) | EA3.80.8001 | GA.1 |
| Equipment in Rear Fuselage | EA3.83.115 | GB.1 |

INDEX OF ASSEMBLIES

| Assembly | Drawing No. | Page No. |
|---|--------------|----------|
| FUSELAGE | | |
| Centre Fuselage | EA3.00.43 | KA.1 |
| Centre Fuselage Structure | EA1.11.1 | KA.3 |
| Front Fuselage | EA3.00.5 | KB.1 |
| Rear Fuselage | EA1.00.45 | KC.1 |
| MAINPLANES | | |
| Aileron, Port (Mod.875) | EA3.24.1 | LB.1 |
| Aileron, Starboard (Mod.875) | EA3.24.2 | LB.1 |
| Undercarriage Door, Port | EA1.20.10733 | LC.1 |
| Undercarriage Door, Starboard | EA1.20.10734 | LC.1 |
| Wing, Port | EA3.00.11 | LA.1 |
| Wing, Starboard | EA3.00.12 | LA.1 |
| Wing Structure, Port | EA3.20.1 | LE.1 |
| Wing Structure, Starboard | EA3.20.2 | LE.1 |
| Wing Tip, Port | EA1.00.67 | LD.1 |
| Wing Tip, Starboard | EA1.00.68 | LD.1 |
| MISCELLANEOUS ATTACHMENTS | | |
| Centre Fuselage to Front Fuselage | EA1.00.23 | N.1 |
| Centre Fuselage to Rear Fuselage | EA1.00.25 | N.1 |
| Controls to Elevator and Rudder | EA1.00.63 | N.1 |
| Fin to Fuselage | EA1.00.55 | N.1 |
| Rear Fairing to Fuselage | EA1.00.59 | N.2 |
| Rudder to Fin and Fuselage | EA1.00.57 | N.2 |
| Tailplane to Rear Fuselage | EA1.00.53 | N.2 |
| Tailplane Sealing Plates | | N.2 |
| Wing to Fuselage, Port | EA1.00.21 | N.3 |
| Wing to Fuselage, Starboard | EA1.00.22 | N.3 |
| POWER INSTALLATION | | |
| Engine Cowling, Port | EA1.50.395 | PA.1 |
| Engine Cowling, Starboard | EA1.50.396 | PP.1 |
| Engine Mountings and Attachments, Port | EA1.51.1 | PC.1 |
| Engine Mountings and Attachments, Starboard | EA1.51.2 | PD.1 |
| RA3 Engine Installation, Port | EA1.00.103 | PE.1 |
| RA3 Engine Installation, Starboard | EA1.00.104 | PF.1 |

INDEX OF ASSEMBLIES

| Assembly | Drawing No. | Page No. |
|---|-------------|----------|
| RADAR INSTALLATION | | |
| Green Satin and GPI Mk. 4, ARI 5851 (Mod 4868 - S.O.O.) . . . | 41083 | QD.1 |
| I.F.F. Mk. 10 (Mod. 1435) (Pre-Mod. 4868) (Pre-Mod. 4937) . . | EB6.90.211 | QA.1 |
| I.F.F./SSR 1520, ARI 23134/3 Cassor (Mod. 4868 - S.O.O.) . . | 41002 | QA.5 |
| I.F.F./SSR 1520, ARI 23134/3 (Mod. 4937) (Pre-Mod. 5204) | EA3.82.7013 | QA.5 |
| I.F.F./SSR 1520, ARI 23134/3 (Mod. 5204) | EA3.82.8013 | QA.5 |
| Rebecca, ARI 5610 (Pre-Mod. 4868) (Pre-Mod. 4937) | EA3.90.5 | QC.1 |
| Tacan, ARI 18107/18 (Mod. 4868 - S.O.O.) (Mod. 4924 - S.O.O.) | 40852 | QB.1 |
| Tacan, ARI 18107/18 (Mod.4937) (Pre-Mod 5204) | EA3.82.7009 | QB.1 |
| Tacan, ARI 18107/18 (Mod. 5204) | EA3.82.8009 | QB.1 |
| RADIO INSTALLATION | | |
| I.L.S., ARI 18011 (Mod. 4937) (Pre-Mod. 5204) | EA3.82.7007 | RC.10 |
| I.L.S., ARI 18011 (Mod. 5204) | EA3.82.8007 | RC.10 |
| Intercomm, ARI 18099 (Mod. 4868 - S.O.O.) | 31807 | RD.11 |
| Intercomm, ARI 18089 (Mod. 4937) (Pre-Mod 5204) | EA3.82.7003 | RD.7 |
| Intercomm, ARI 18089 (Mod. 5204) | EA3.82.8003 | RD.7 |
| PTR 175 and Standby U.H.F., ARI 23143 and 23159 (Mod. 4868 - S.O.O.) | 41087 | RC.5 |
| PTR 175 and Standby U.H.F., ARI 23143 (Mod 4937) (Pre-Mod. 5204) | EA3.82.7005 | RC.1 |
| PTR 175 and Standby U.H.F., ARI 23143 (Mod 5204) | EA3.82.8005 | RC.1 |
| Radio and Intercomm (Pre-Mod. 4868) (Pre-Mod. 4937) | EA3.82.1 | RD.1 |
| Radio and Intercomm (Mod. 3905 - S.O.O.) (Pre-Mod. 4868) (Pre-Mod 4937) | EA3.82.267 | RD.1 |
| Radio Compass, ARI 23022 (Mod. 1190 - S.O.O.) (Mod. 1191 - S.O.O.) (Pre-Mod. 4868) (Pre-Mod. 4937) | EA3.82.463 | RA.5 |
| Radio Compass, ARI 23023, AD 7092D (Mod. 4937) (Pre-Mod. 5204) | EA3.82.7011 | RA.1 |
| Radio Compass, ARI 23023, AD 7092D (Mod 5204) | EA3.82.8011 | RA.1 |
| Single I.L.S. Twin V.O.R., AD 260, ARI 23118 (Mod. 4868 - S.O.O.) | 41001 | RC.13 |
| U.H.F., ARI 18124/1 (Mod 3905 - S.O.O.) (Pre-Mod. 4868) (Pre-Mod. 4937) | EA3.82.227 | RC.7 |

INDEX OF ASSEMBLIES

| Assembly | Drawing No. | Page No. |
|---|--------------|----------|
| SERVICES | | |
| Air Ventilated Suit in Centre Fuselage (Mod.2717 - S.O.O.) ... | EA3.75.577 | SB.39 |
| Air Ventilated Suit, Mk.2 in Front Fuselage (Mod.2717-S.O.O.) ... | EA3.75.575 | SB.35 |
| Cabin Pressure System in Centre Fuselage (Pre Mod.2523) ... | EA3.75.5 | SB.13 |
| Cabin Pressure System in Centre Fuselage (Mod.2523-S.O.O.) ... | EA3.04.9559 | SB.13 |
| Cabin Pressure System in Front Fuselage (Pre Mod.2523) | EA3.75.141 | SB.1 |
| Cabin Pressure System in Front Fuselage (Mod.2535-S.O.O.) .. | EA3.04.9535 | SB.1 |
| Cabin Pressure System in Wing, Port (Pre Mod.2523) | EA3.75.7 | SB.21 |
| Cabin Pressure System in Wing, Port (Mod.2523 - S.O.O.) ... | EA3.04.9547 | SB.21 |
| Cabin Pressure System in Wing, Starboard (Pre Mod.2523) ... | EA3.75.8 | SB.16 |
| Cabin Pressure System in Wing, Starboard (Mod.2523 - S.O.O.) .. | EA3.04.10941 | SB.16 |
| C.A.U. System in Bomb Bay (Mod.2523 - S.O.O.) | EA3.04.10943 | SB.31 |
| Cold Air Supply to Pilot | EA3.74.21 | SB.33 |
| Demisting System | EA3.76.215 | SD.1 |
| Equipment in Inner Wing Leading Edge, Port | EA3.00.65 | SE.1 |
| Equipment in Inner Wing Leading Edge, Port | EA3.00.67 | SE.3 |
| Equipment in Inner Wing Leading Edge, Starboard | EA3.00.66 | SE.2 |
| Equipment in Inner Wing Leading Edge, Starboard | EA3.00.68 | SE.7 |
| Fire Protection System | EA1.60.1 | SF.1 |
| Fuel and Air Delivery Pipes in Wing Tip, Port | EA1.57.257 | SG.36 |
| Fuel and Air Delivery Pipes in Wing Tip, Starboard | EA1.57.258 | SG.36 |
| Fuel System in Centre Fuselage | EA3.57.67 | SG.1 |
| Fuel System in Wing, Port | EA1.57.727 | SG.23 |
| Fuel System in Wing, Starboard | EA1.57.728 | SG.23 |
| Fuel Transfer and Venting from 300 Gallon Tank (Mod.3757 - S.O.O.) | EA3.56.453 | SG.38 |
| Fuel Venting, Frames 30 to 40 | EB7.57.293 | SG.37 |
| Hydraulic equipment in Centre Fuselage (Pre-Mod.2523 - S.O.O.) | EA3.73.215 | SH.1 |
| Hydraulic equipment in Centre Fuselage (Mod.2523 - S.O.O.) .. | EA3.04.10971 | SH.1 |
| Hydraulic equipment in Front Fuselage | EA3.73.205 | SH.24 |
| Hydraulic equipment in Port Wing | EA3.73.539 | SH.41 |
| Hydraulic equipment in Starboard Wing | EA3.73.540 | SH.54 |
| Oxygen Cylinder Installation | EB6.71.11 | SJ.6 |
| Oxygen System | EA3.71.519 | SJ.1 |
| Oxygen System - Bomb Aimer | EA3.71.427 | SJ.1 |
| Oxygen System - Navigator | EA3.71.523 | SJ.3 |
| Oxygen System - Pilot | EA3.71.469 | SJ.8 |
| Pitot and Static System in Centre Fuselage | EA3.80.657 | SK.1 |
| Pitot and Static System in Front Fuselage (Pre-Mod.4937) (Pre-Mod.5204) | EA3.80.2411 | SK.2 |
| Pitot and Static System in Front Fuselage (Mod.4937 - S.O.O.) .. | EA3.80.7017 | SK.2 |
| Pitot and Static System in Front Fuselage (Mod.5204 - S.O.O.) .. | EA3.80.8017 | SK.2 |
| Pitot and Static System in Wing, Port | EA3.80.659 | SK.7 |

INDEX OF ASSEMBLIES

| | Assembly | Drawing No. | Page No. |
|---------------|--|---|--|
| TAIL UNIT | Rudder and Tab (Pre-Mod. 4478) Rudder and Tab (Mod. 4478) (Pre-Mod. 5043) Rudder and Tab (Mod. 5043) Tailplane and Elevators Tailplane and Elevators | EA3.33.1 EA3.00.1069 EA3.00.5397 EA1.00.19 EA3.00.5473 | TA.1 TA.1 TA.1 TB.1 TB.1 |
| TANKS | Jettisonable Wing Tip Fuel Tank, 250 Gallon, Port (Pre-Mod. 2395) Jettisonable Wing Tip Fuel Tank, 250 Gallon, Port (Mod. 2395) Jettisonable Wing Tip Fuel Tank, 250 Gallon, Starboard (Pre-Mod. 2395) Jettisonable Wing Tip Fuel Tank, 250 Gallon, Starboard (Mod. 2395) Ventral Fuel Tank, 300 Gallon, Aft Position (Mod. 432 - S.O.O.) Ventral Fuel Tank, 300 Gallon, Forward Position (Mod. 3757 - S.O.O.) | EA3.00.505 EB6.00.347 EA3.00.506 EB6.00.348 EA3.56.453 EA3.57.5041 | UA.1 UA.1 UA.1 UA.1 UB.1 UB.3 |
| UNDERCARRIAGE | Main Undercarriage Port Main Undercarriage, Starboard Nosewheel | EA1.40.1 EA1.40.2 EA9.40.1 | WA.1 WB.1 WC.1 |

R



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

