

AIRFRAME
MP 16(2)

MAINTENANCE PROCEDURES
COMPONENT REPLACEMENTS
CANBERRA PR9

AP101B-0409A-5A3A
2nd Edition
Sect 1
Chap 1

Maintenance Record

MOD Form 707MS
(Revised Jan 01)

Aircraft or Equipment
Serial No:

Date:

PORT ELEVATOR - REMOVAL

INFORMATION IN THE TOPIC 5A2 IS TO BE CONSULTED THROUGHOUT THE WORK DETAILED ON THIS CARD			Tradesman		Brief Details of suspected fault(s) and SNOW(s)	Supervisor	
BLOCK 1	AIRFRAME	Code	Man Hrs	Certification and TDM		Man Hrs	Certification and TDM
3.	<u>Removal</u>						
3.1	Control tube.	Disconnect from elevator control lever.					
3.2	Coupling link.	Disconnect from starboard elevator torque lever.					
3.3	Centre hinge bracket nut)					
	(3 off).)					
3.4	Centre hinge bracket bolt)					
	(3 off).) Remove.					
3.5	Centre hinge bracket.)					
3.6	Balance weight nut.)					
3.7	Balance weight washer.)					
	Before carrying out Sub-item 3.8 the balance weight and arm is to be partially withdrawn from the elevator and moved forward to the tailplane diaphragm.						
3.8	Elevator.	(i) Move outboard to clear outer hinge. (ii) Remove, lifting away from balance weight arm.					
3.9	Balance weight and arm.	Remove from aircraft and retain with removed elevator.					
E0393(46A)							

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

