

Chapter 3

SWITCH STARTING, TYPE 1A, No. 3 (ROTAX U2003)

LIST OF CONTENTS

	Para.	Description	Para.
Introduction	1		2

LIST OF ILLUSTRATIONS

	Fig.	Circuit diagram	Fig.
Starting switch, Type 1A, No. 3	1		2

LEADING PARTICULARS

Switch starting, Type 1A, No. 3	Stores Ref. 5C/4399
Working voltage	108 to 116 volts d.c.
Mean current through starting resistor	173 amp.
Relay operating voltage	65 volts d.c.
Starting resistor (hot)	0.30 ohm.
Relay coil and ballast resistor	442 ohm.
Rating	80 minute
<i>Electrical connections</i>	
Main contacts	Two $\frac{1}{8}$ in. B.S.F. terminals
Coil	Two 2-B.A. terminals
Mounting	Four holes 0.203 in. dia. spaced on rectangle 4.000 in. \times 4.625 in. between centres
Weight	4 lb. 8 oz.




Fig. 1. Starting switch, Type 1A, No. 3

Introduction

1. The Type 1A, No. 3, 112-volt d.c. starting switch is one of the U2000 series of units which has been designed for starting motors, Rotax Type EXP.4014.

DESCRIPTION

2. The U2003 starter panel does not differ materially from the basic type, and reference should be made to A.P.4343, Vol. 1, Sect. 11, Chap. 9, for details of construction, operation, installation and servicing.




Fig. 2. Circuit diagram

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

