

Chapter 4

GRAVINER INDICATOR FUSES

LEADING PARTICULARS

<i>Fuseholder Type E.381</i>	<i>Ref. No. 27N/170</i>
<i>Fuse Type E.301 (one groove)</i>	<i>Ref. No. 27N/171</i>
<i>Fuse Type E.302 (two grooves)</i>	<i>Ref. No. 27N/176</i>
<i>Fuse Type E.303 (three grooves)</i>	<i>Ref. No. 27N/204</i>
<i>Fuse Type E.304 (four grooves)</i>	<i>Ref. No. 27N/177</i>
<i>Operating voltage (nominal)</i>	<i>28 volt d.c.</i>

1. The Graviner indicator fuses used in the Explosion Protection System have a nominal operating voltage of 28 volt and information is given in A.P.107E-0301-1 to which reference should be made.

RESTRICTED

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

