Chapter 90

MAGNETIC SWITCH, TYPE IIB (B.T.H. LBA99-B3/I)

LIST OF CONTENTS

| | | | | | | Para. | | | | | Para. |
|-----------------|--------|-----|-----|---|-------|-------|-----------------|------|-----|-----|---------------|
| ntroduction | | | ••• | | | I | Description | | | | 2 |
| | | | | L | ist c | F ILL | USTRATIONS | | | | |
| Magnetic switch | , Туре | IIB | | | | Fig. | Circuit diagram | | ••• | ••• | Fig. 2 |

LEADING PARTICULARS

| Magnetic switch, 7 | | Stores Ref. 5CW/4785 | | | |
|-----------------------|------|----------------------|----------|-----|------------------------------------|
| Operating voltage | | | | | 28 volts d.c. |
| Continuous rating | | | | 10 | amp. at 28 volts d.c. |
| Coil resistance at 20 | deg. | C. | | | 64 ohms |
| Overall dimensions | | | 5.01 | in. | \times 1.48 in. \times 2.1 in. |
| Weight | | | | | 1b. 11 oz. |

Introduction

1. The magnetic switch, Type 11B, is a single-pole changeover switch for use in circuits where the current does not exceed 10 amp.

DESCRIPTION

2. A sectional view of the switch is given in fig. 1, and the circuit diagram in fig. 2. The armature is linked by pivoted levers to a contact carrier, which carries the spring-loaded moving contact bars bridging

the pairs of fixed contacts. When the coil is energized, the armature is attracted to the core, thus breaking the even-numbered contacts and making the odd-numbered contacts. When the coil is de-energized, the




Fig. I. Magnetic switch, Type IIB

contact carrier returns by spring pressure to the unoperated position.

3. Electrical connection is made to contact posts underneath the base. The unit is mounted by means of four 4 B.A. studs.




Fig. 2. Circuit diagram

(A.L.97, Feb. 57)