

RESTRICTED


1st Edition

A.P. 4347B.—P.N.

# PILOT'S NOTES

# HUNTER

## F.2



Prepared by Direction  
of the  
Minister of Supply

Promulgated by Order  
of the  
Air Council

*J. R. C. Helmore*      *J. H. Barnes*

RESTRICTED

## RESTRICTED

### NOTES TO USERS

These Notes are complementary to A.P.2095 Pilot's Notes General, and assume a thorough knowledge of its contents. All pilots should be in possession of a copy of A.P.2095 (see A.M.O. A178/53).

Additional copies may be obtained by the station publications officer by application on R.A.F. Form 294A, in quadruplicate, to Command Headquarters for onward transmission to A.P.F.S. (see A.P. 113A). The number of this publication must be quoted in full—A.P.4347B—P.N.

Comments and suggestions should be forwarded through the usual channels to the Air Ministry (T.F.2).

### AMENDMENTS

Amendment lists will be issued as necessary and will be gummed for affixing to the inside front cover of these notes.


Each amendment list will, where applicable, be accompanied by gummed slips for sticking in the appropriate places in the text.

Incorporation of an amendment list must be certified by inserting date of incorporation and initials below.

A.L. NO.	INITIALS	DATE	A.L. NO.	INITIALS	DATE
1			4		
2			5		
3			6		

RESTRICTED

MAIN DIMENSIONS:  
HEIGHT, OVERALL 13FT. 4INS.  
LENGTH, OVERALL 45FT. 10½INS.  
SPAN 33FT. 8INS.



HUNTER F.2

## HUNTER F.2

### LIST OF CONTENTS

#### ILLUSTRATIONS IN TEXT

General layout	Frontispiece
Fuel system	Page 8
Flying controls locking gear	Page 18
Cockpit pressurization	Page 23
Ejection seat	Pages 26 & 27
Normal acceleration/speed	Page 52

#### PART I—DESCRIPTIVE

Introduction	Para. 1
--------------	---------

#### FUEL AND OIL SYSTEMS

Fuel tanks and gauges	2
Fuel transfer system	3
Main fuel feed system	4
Booster pumps control	5
H.P. pump	6
H.P. fuel cock	7
L.P. fuel cock	8
Oil system	9

#### ENGINE CONTROLS

Engine starting system	10
Restarting in flight system	11
Throttle control	12
Engine instruments	13
Engine fire-extinguisher	14

#### MAIN SERVICES

Hydraulic system	15
Electrical system	16

## AIRCRAFT CONTROLS

	Para.
Flying controls ... ..	17
Flying controls locking gear ... ..	18
Trimming tab controls ... ..	19
Undercarriage control and position indicator ... ..	20
Undercarriage emergency operation ... ..	21
Flaps control and position indicator ... ..	22
Flaps emergency operation ... ..	23
Airbrake control ... ..	24
Wheel brakes control ... ..	25

## COCKPIT EQUIPMENT

Entry to aircraft ... ..	26
Hood operation ... ..	27
Hood jettisoning ... ..	28
Cockpit pressurization, heating and de-misting ... ..	29
Windscreen de-icing system ... ..	30
Anti-G suit system ... ..	31
Ejection seat Mk. 2H ... ..	32
Oxygen system ... ..	33
Internal lighting ... ..	34
External lighting ... ..	35
Accelerometer ... ..	36
Pitot head heater ... ..	37
Emergency equipment ... ..	38
Electrical supply to flight instruments and radar ranging ... ..	39

## OPERATIONAL CONTROLS

Gyro gunsight Mk. 6 ... ..	40
Radar ranging (ARI5820) ... ..	41
VHF-TR1934/1935 with telebriefing (ARI5490) ... ..	42
IFF Mk. 3 GR (ARI5131) ... ..	43
DME Rebecca Mk. 7 (ARI5849) ... ..	44
G45 and recorder cameras ... ..	45
Guns/RP firing ... ..	46

## PART II—LIMITATIONS

Engine limitations ... ..	47
Flying limitations ... ..	48

## PART III—HANDLING

	Para.
External checks ... ..	49
Management of fuel system ... ..	50
Cockpit and pre-start checks ... ..	51
Starting the engine ... ..	52
Checks after starting ... ..	53
Taxying ... ..	54
Checks before take-off ... ..	55
Take-off ... ..	56
Climbing ... ..	57
Engine handling ... ..	58
General flying ... ..	59
Flying at reduced airspeed ... ..	60
Stalling ... ..	61
High speed stalling ... ..	62
High speed flight ... ..	63
Aerobatics ... ..	64
Spinning ... ..	65
Checks before landing ... ..	66
Landing ... ..	67
Instrument approach ... ..	68
Going round again ... ..	69
Checks after landing ... ..	70
Stopping the engine ... ..	71

## PART IV—EMERGENCY HANDLING

Engine failure and relighting in flight ... ..	72
Action in the event of fire ... ..	73
Electrical system failures ... ..	74
Hydraulic system failures ... ..	75
Undercarriage and flaps emergency operation ... ..	76
Landing with an undercarriage unit not locked down ... ..	77
Practice flying in manual control ... ..	78
Emergency operation of the flying controls ... ..	79
Emergency trimming ... ..	80
Wheel brakes emergency operation ... ..	81
Flapless landing ... ..	82
Forced landing ... ..	83
Landing with a burst tyre ... ..	84
Hood jettisoning ... ..	85
Abandoning the aircraft ... ..	86
Ditching ... ..	87
Toxic fumes ... ..	88
Oxygen failure ... ..	89

## PART V—OPERATING DATA

					<i>Para.</i>
Pressure error corrections	...	...	...	...	90
Endurance	...	...	...	...	91
Flight planning chart	...	...	...	...	92
Fuel consumptions	...	...	...	...	93
Take-off distances	...	...	...	...	94

## PART VI—ILLUSTRATIONS

					<i>Fig.</i>
Cockpit—Port side	...	...	...	...	1
Cockpit—Forward view	...	...	...	...	2
Cockpit—Starboard side	...	...	...	...	3



This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

